

**SMC<sup>®</sup>**

**EtherCard Elite  
Ultra Adapters**  
.....

*User Guide*



**High-performance 16-bit Ethernet LAN adapters**

- *Elite16 Ultra for thin coax wiring*
- *Elite16T Ultra for unshielded twisted-pair wiring*
- *Elite16C Ultra for all coax and unshielded twisted-pair wiring*



**LIMITED WARRANTY**

**HARDWARE:** SMC warrants its hardware products listed below to be free from defects in workmanship and materials, under normal use and service, for the following lengths of time from the date of purchase from SMC or its Authorized Reseller:

EtherCard Plus Elite Adapters	Five years
EtherCard Elite Ultra Adapters	Limited Lifetime (see below – EtherCard Elite Ultra Adapters)
EliteSeries Ethernet Concentrators	Three years
Spare parts and spare kits	90 days
Driver Software	90 days

If a product does not operate as warranted during the applicable warranty period, SMC shall, at its expense, correct any such defect by repairing the defective product or part or, at its option, by delivering to Customer an equivalent product or part to replace the defective item. All products that are replaced will become the property of SMC. Replacement products may be new or reconditioned. Any replaced or repaired product or part has a ninety (90) day warranty or the remainder of the initial warranty period, whichever is longer.

SMC shall not be responsible for any software, firmware, information, or memory data of Customer contained in, stored on, or integrated with any products returned to SMC pursuant to any warranty.

**ETHERCARD ELITE ULTRA ADAPTERS:** EtherCard Elite Ultra Adapters have a standard three-year warranty. If you wish to extend your three-year warranty on these adapters to a lifetime warranty, please complete and return the enclosed product registration card within 90 days of purchase from SMC or its authorized reseller. Be sure to include the type and serial number of the computer in which the adapter was originally installed, and the serial number of the SMC Elite Ultra Adapter (located on the board). Failure to complete and return this card does not affect the standard, three-year warranty. After registration, any defective SMC adapter will be repaired or replaced, at SMC's option, for as long as the adapter continues to be used in its original ISA or EISA computer (all driver software is covered as indicated below).

**SOFTWARE:** SMC warrants that the software programs licensed from it will perform in substantial conformance to the applicable published program specifications for a period of ninety (90) days from the date of purchase from SMC or its Authorized Reseller. SMC warrants the magnetic media containing software against failure during the warranty period. No updates are provided. SMC's sole obligation hereunder shall be (at SMC's discretion) to refund the purchase price paid by Customer for any defective software products, or to replace any defective software products with products which substantially conform to SMC's applicable published specifications. Customer assumes responsibility for the selection of the appropriate applications program and associated reference materials. SMC makes no warranty that its software products will work in combination with any hardware or applications software products provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected. For any third party products listed in the SMC software product documenta-



*EtherCard Elite Ultra Adapters  
User Guide*

- **EtherCard Elite16 Ultra**  
10BASE2 Adapter, (Board Type 8216)
- **EtherCard Elite16T Ultra**  
10BASE-T Adapter, (Board Type 8216T)
- **EtherCard Elite16C Ultra**  
Combo (10BASE-T, 10BASE2, AUI) Adapter  
(Board Type 8216C)

**Standard Microsystems Corporation**  
80 Arkay Drive  
Hauppauge, New York 11788

Information furnished by Standard Microsystems Corporation (SMC) is believed to be accurate and reliable. However, no responsibility is assumed by SMC for its use, nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of SMC. SMC reserves the right to change specifications at any time without notice.

Copyright© 1993 by  
Standard Microsystems Corporation  
Hauppauge, New York.  
All rights reserved. Printed in U.S.A.

**Trademarks:**

SMC and Standard Microsystems are registered trademarks; and EtherCard Elite16 Ultra, EtherCard Elite 16T Ultra, EtherCard Elite 16C Ultra, Elite Series, EliteView, EZStart, SuperDisk, SimulTasking, UMAC/LMAC, and UltraChip are trademarks of Standard Microsystems Corporation. Other products and company names are registered trademarks or trademarks of their respective holders.

# TABLE OF CONTENTS

## 1 INTRODUCTION

Features .....	1-3
Package Contents.....	1-4
What Else You Will Need.....	1-4
Conventions in This User Guide .....	1-5
Adapter Models .....	1-5
Notes.....	1-5
Selecting Menu Items .....	1-5
Key Combinations .....	1-5
Enter Key .....	1-5
User Entries.....	1-6
Variables .....	1-6
EZStart Buttons .....	1-6

## 2 INSTALLING A BOOT ROM

Installation Instructions.....	2-1
--------------------------------	-----

## 3 CHOOSING AN EZSelect CONFIGURATION METHOD

Overview .....	3-1
Using the Soft Configuration Method.....	3-2
Using the Preassigned Configuration Method.....	3-3

## 4 INSTALLING AND CABLING YOUR ADAPTER

Installing Your Adapter.....	4-1
Connecting to the Network .....	4-1
Connecting to a Thin Ethernet Cable .....	4-2
Connecting to a Thick Ethernet Cable.....	4-4
Connecting to a 10BASE-T Concentrator.....	4-5







## **FCC Warning**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.




# INTRODUCTION 1

.....


This user guide contains all the information you need to install, configure, and use the following SMC EtherCard Elite Ultra adapters:

- EtherCard Elite16 Ultra™, 10BASE2 Adapter (Board Type 8216). See Figure 1-1.
- EtherCard Elite16T Ultra™, 10BASE-T Adapter (Board Type 8216T). See Figure 1-2.
- EtherCard Elite16C Ultra™ Combo, 10BASE-T, 10BASE2, AUI Adapter (Board Type 8216C). See Figure 1-3.


All SMC EtherCard Elite Ultra adapters are IEEE 802.3-compatible Ethernet adapters that are ideal for use in network file servers, workstations (with or without local disks), bridges, and gateways.



**Figure 1-1. EtherCard Elite16 Ultra Adapter**



**Figure 1-2. EtherCard Elite16T Ultra Adapter**



**Figure 1-3. EtherCard Elite16C Ultra Adapter**

## Features

SMC's EtherCard Elite Ultra adapters are a new generation of high-performance Ethernet adapters. Their unique design and state-of-the-art technology combine easy installation and configuration with unparalleled high-speed performance.

The EtherCard Elite Ultra adapters are based on SMC's new SMC83C790 UltraChip™ Ethernet controller. The UltraChip Ethernet controller is based on unique SimulTasking™ technology that provides higher performance by increasing the data-transfer speed between the network and the host PC.

The following list describes your adapter's features.

- SimulTasking technology combines top performance with unsurpassed data-transfer speeds. *Parallel Processing. Data is processed as it comes in. Buffer does not function the same as it does in the elite (serial processing) - in line*
- UltraChip technology provides a single-chip Ethernet solution for unsurpassed reliability.
- Complies with FCC Class B standard.
- Advanced UMAC/LMAC™ driver architecture assures the widest driver support available in today's LAN marketplace.
- Driver assurance guarantees that a single driver handles every SMC and Western Digital 8- and 16-bit EtherCard adapter.
- Versatile design permits installation into any computer slot, including 8-bit slots.
- EZSelect configuration method lets you choose a preassigned adapter configuration, or have a conflict-free configuration assigned automatically.
- The EZStart™ utility program provides a Windows-like operation that makes adapter configuration/testing and driver installation fast and easy.
- The PC Agent/SNMP program lets you collect and monitor LAN driver and computer statistics from your PC, without any other software tools.
- Includes lifetime warranty with free technical support.





## User Entries

When you are required to make a keyboard entry, the information you are to enter appears in **bold type**. For example:

1. To run the EZStart program, type **EZSTART** and press the Enter key.

## Variables

When you are required to type a variable, the variable appears in *bold italics* between brackets. For example:

1. If you unloaded PC Agent/SNMP and want to reload it during the current computer session without rebooting, type **PCAGENT [filename.cfg]** at the DOS command line and press the Enter key.

In this example, the variable *[filename.cfg]* means you should type the name of the configuration file, instead of the actual characters filename.cfg. When you type a variable, do not include the brackets; these are provided for reference purposes only.

## EZStart Buttons

EZStart is a Windows-like program that lets you use buttons to perform various functions. For example, there is an **Automatic Setup and Test** button that lets you automatically configure and test your adapter. In this user guide, buttons that appear in EZStart screens are shown in **bold**. For example:

1. From the EZStart main screen, select **Automatic Setup and Test** to initiate EZStart's Automatic Setup and Test.

# INSTALLING A BOOT ROM 2



This chapter describes how to install an optional Boot ROM on your adapter. A Boot ROM allows your PC to load its operating system over the network, instead of from the PC's local hard disk.

☞ If you do not intend to install a Boot ROM, you can skip this chapter.

## Installation Instructions

Your adapter includes a socket that can accommodate a Boot ROM. If you want to install a Boot ROM but do not currently have one, contact the dealer where you purchased your adapter.

Once you obtain a Boot ROM, use the following procedure to install it on your adapter.

- ☞ Use extreme care when handling the Boot ROM and your adapter. In particular, follow electrostatic discharge (ESD) procedures before handling this equipment.
1. Discharge any static electricity from your body.
  2. Find the Boot ROM socket on your adapter.
  3. Orient the Boot ROM so that its notch is on the same side as the notch on the adapter socket. Make sure the Boot ROM is properly oriented. If you install the Boot ROM backwards, you will damage it.
  4. Align the pins on the Boot ROM with the socket on your adapter (see Figure 2-1). Then carefully insert the Boot ROM straight down until it is firmly seated in the socket. Be careful not to bend any Boot ROM pins.



# CHOOSING AN EZSelect CONFIGURATION METHOD 3

.....

The EZSelect configuration method lets you easily select the way you want your adapter to be configured. This chapter describes how to choose an EZSelect configuration method.

## Overview

For ultimate flexibility, your adapter provides two EZSelect configuration methods, a “Soft” method and a preassigned method. Both methods let you use a selector on the adapter to choose how your adapter will be configured.

The Soft method is the default configuration method. With this method, you leave the selector in the **Soft** position on the adapter. You can then install the adapter in a computer and use EZStart’s Automatic Setup and Test feature to automatically select a configuration that does not conflict with any other installed devices — including any other installed adapters. This configuration method is convenient for users who want to install multiple adapters in the same computer, because it guarantees that each adapter will have a unique, conflict-free configuration.

The preassigned method, on the other hand, is convenient for users who want to install a single adapter into many identically configured computers. For example, you can choose a preassigned configuration for one adapter, install it into a computer, and use the Automatic Setup and Test feature to see whether the configuration you chose conflicts with other installed devices. If no conflict is detected, you can configure the other adapters the same way and install them into their respective computers without having to run EZStart for each installation.

The following section describes the Soft configuration method. For information on using the preassigned configuration method, refer to page 3-3.



## Using the Preassigned Configuration Method

The following procedure describes how to choose a preassigned configuration for your adapter.

1. Move the selector to the preassigned configuration you want to use. Figure 3-1 shows the preassigned configurations you can choose.
-  If you installed a Boot ROM, select either configuration 4 or 5. These preassigned configurations set the ROM size to 16KB and the ROM base address to D800. Do not select configuration 2 or 3, because they disable an installed Boot ROM.

	I/O Base Address	IRQ Channel	RAM Base Address	ROM Base Address
 1 (Factory default)				
 2	280	3	D000	NONE
 3	300	10	CC00	NONE
 4	280	3	D000	D800
 5	300	10	CC00	D800

**Figure 3-1. Selecting a Preassigned Configuration**

## CHOOSING AN EZSelect CONFIGURATION METHOD

2. Install the adapter in your computer (refer to Chapter 4).
3. (Optional) Run EZStart's Automatic Setup and Test feature to make sure the preassigned configuration you chose does not conflict with other installed devices (refer to Chapter 5).
4. If you want to install additional adapters into the same computer, repeat steps 1 and 2 (and optionally 3). Make sure you choose a different preassigned configuration for each adapter you install.



# INSTALLING AND CABLING YOUR ADAPTER **4**



This chapter describes how to install your adapter in a computer and how to connect to your network.

## Installing Your Adapter

You can install your adapter in any EISA bus slot or in either an 8-bit or 16-bit ISA bus expansion slot. For maximum performance, a 16-bit slot is recommended; a 16-bit slot also allows IRQ channels above 7 to be used with your adapter.

To install your adapter:

1. Turn off the computer's power.
2. Install the adapter according to the computer manufacturer's instructions. Always handle the adapter by its edges.

## Connecting to the Network

After you install your adapter, you can use the procedures in this section to connect to your network. Topics in this section include:


- Connecting to a thin Ethernet cable — see page 4-2.
  - Connecting to a thick Ethernet cable — see page 4-4.
  - Connecting to a 10BASE-T concentrator — see page 4-5.
- ☞ For information on adapter connector pin assignments and cabling specifications, refer to Appendix C.





## INSTALLING AND CABLING YOUR ADAPTER

---



**Figure 4-2. Terminating the Cable Segment**



### **Connecting to a 10BASE-T Concentrator**

You can use unshielded twisted-pair (UTP) cable to connect your adapter to a 10BASE-T concentrator. This connection can be made directly, or indirectly via a wall outlet that has the proper wiring for an RJ-45 connector. Refer to the following instructions and Figure 4-4 to make these connections.

1. Attach the male RJ-45 connector on one end of an unshielded twisted-pair cable to the adapter's RJ-45 port.
2. Attach the male connector on the other end directly to an RJ-45 port on a 10BASE-T concentrator.

**OR**

Attach the male connector on the other end to a wall outlet with the proper wiring for an RJ-45 connector. Wiring from the wall outlet connection is usually routed to the concentrator through the telephone punch-down block located in a wiring closet.

- ☞ Regulations regarding the connection of equipment to telephone networks vary from country to country. Check with your local telephone company before using existing telephone wiring.



# USING EZStart TO SETUP AND TEST YOUR ADAPTER 5

.....

The EZStart utility program provides an Automatic Setup and Test feature, which you can use to configure your adapter and test its basic functions. This chapter provides an overview of EZStart and describes how to use the Automatic Setup and Test feature.

## EZStart Overview

EZStart provides a familiar Windows-like interface that can be accessed with a mouse. EZStart runs under MS-DOS or PC-DOS, version 3.11 or later, with or without Microsoft Windows. If your computer does not have a mouse, you can use the keys described in Table 5-1 to navigate through EZStart and select functions.

Each EZStart screen has a help line at the bottom that describes the purpose of the screen or selected function (the highlighted button).

**Table 5-1. Keys for Navigating Through EZStart**

To...	Use This Key...
Move to the next field or button	Tab
Move to the previous field or button	Shift+Tab
Select the highlighted function	Enter
Move to the next selection in a list box	Down arrow
Move to the previous selection in a list box	Up arrow
Obtain help	F1
Select a function that is not highlighted	Alt + underscored character For example, Alt + x to Exit
Close the current window (including Help windows)	F3 or Alt+F4

## Loading EZStart

You can run EZStart from the SuperDisk floppy disk or, for improved performance, from your computer's hard disk. You can also run EZStart from Microsoft Windows.

## Running EZStart from a Floppy Disk

To run EZStart from a floppy disk:

1. Insert the SuperDisk into your computer's floppy drive.
2. Change to the floppy drive where you inserted the SuperDisk. For example, if you inserted the SuperDisk in drive A, type A: and press the Enter key.
3. Type EZStart and press Enter. The EZStart main screen appears (see Figure 5-1).

☞ If your computer has more than one adapter, a screen shows each installed adapter and its configuration. Choose one by double-clicking on it, or by highlighting it and either choosing **Select** or pressing Enter. The EZStart main screen then appears.

*Shows information and current configuration for your adapter.*

*Use these buttons to perform EZStart functions.*

*Help line describes purpose of the screen or selected function.*




Figure 5-1. EZStart Main Screen



## USING EZStart TO SETUP AND TEST YOUR ADAPTER

3. If you have not yet copied the compressed driver file, *SMCAnn.EXE*, to the same directory where you copied the EZStart files, do so now (refer to page 6-2).
- ☞ If you obtain an updated *SMCAnn.EXE* file and want to use it in place of the one on your computer's hard disk, copy the *SMCAnn.EXE* file you are currently using from your computer's hard disk to a floppy disk for safekeeping, then delete it from the hard disk. You can now copy the updated *SMCAnn.EXE* file to the same location where your EZStart files reside.
4. Start Microsoft Windows.
5. From the Microsoft Windows Program Manager, select **New** in the **File** menu.
6. Select **Program Item**.
7. Select the **OK** button.
8. For the **Command Line** entry, type the complete path where you copied the EZStart files and the *SMCAnn.EXE* file. For example: **C:\SMC\EZSTART.EXE**
- ☞ You can use the **Browse** button to search for the directory and filename where these files reside.
- ☞ If you prefer, you can use the *EZSTART.ICO* file instead of *EZSTART.EXE* for the **Command Line** entry and gain additional control over the environment in which EZStart loads. For more information on working with *.PIF* files, refer to the Microsoft Windows documentation.
9. Select **Change Icon**.
10. Select **OK**.
11. Select **Browse** and select the directory where you installed EZStart.
12. Select the *EZSTART.ICO* file to install the icon on your Windows desktop.

13. Select **OK** with each window, until you return to your Windows desktop.



14. Double-click on the EZStart icon  to start EZStart.

☛ If you use EZStart with Windows for Workgroups, do not run EZStart from the MS-DOS Prompt in the Main Group. Instead, double-click on the EZStart icon on the Windows Desktop, or exit Windows for Workgroups and run EZStart from the MS-DOS prompt.

## Automatic Setup and Test

EZStart's Automatic Setup and Test feature is comprised of two parts. The first part configures your adapter according to the EZSelect configuration method you chose in Chapter 3.

- If you selected the Soft configuration method — EZStart automatically assigns a nonconflicting configuration to the adapter.
- If you selected a preassigned configuration — EZStart determines whether the configuration you chose conflicts with any other devices installed in the computer, and prompts you if a conflict is detected.

The second part runs the Basic Adapter Test once. This test evaluates your adapter's basic components functions, including I/O port accessibility, LAN address ROM, on-board RAM, network controller registers, Boot ROM (if installed), internal loopback, and interrupt generation.

Before proceeding, note the following information:

- Configuration settings — for a complete list of the configuration settings available for your adapter, including the adapter's default settings, refer to Table A-1 on page A-4.
- Testing individual adapter parameters — you can use EZStart's Manual Test feature to test individual adapter parameters. For more information, refer to Appendix D.
- Multiple adapters — if you work with multiple adapters, refer to page 5-8 for guidelines on how you can use Automatic

## USING EZStart TO SETUP AND TEST YOUR ADAPTER

Setup and Test to configure multiple adapters quickly and easily.

To run EZStart's Automatic Setup and Test feature:

1. From the EZStart main screen, select **Automatic Setup and Test** (see Figure 5-2).

☞ If you do not have a mouse, press Alt+A, or press the Tab key to move to **Automatic Setup and Test** and press the Enter key.




Figure 5-2. Running Automatic Setup and Test

EZStart searches for a nonconflicting configuration (if you selected the Soft configuration method), or verifies that the preassigned configuration does not conflict with any installed devices. Then EZStart tests the adapter's basic functions.

When the Automatic Setup and Test procedure is completed, a screen similar to the one in Figure 5-3 appears, displaying the adapter configuration and test result. If you chose a preassigned configuration that conflicts with another installed de-

## USING EZStart TO SETUP AND TEST YOUR ADAPTER

vice, however, EZStart searches for a nonconflicting configuration and displays it in the screen shown in Figure 5-3.

- ☞ If EZStart is unable to find a nonconflicting configuration for your adapter, an appropriate message appears. For example, if an I/O Base Address setting cannot be found for your adapter, the following message appears: **Could not find any available IO space.** You can then use EZStart's Manual Setup feature (described in Appendix A) to manually select a nonconflicting configuration and the Manual Test feature (described in Appendix D) to test the configuration.




Figure 5-3. Sample Automatic Setup and Test Results

2. To save the displayed configuration, select **Save**. The screen shown in Figure 5-4 then asks whether you want to install a network driver.




Figure 5-4. Saving a Configuration

- ☛ If EZStart finds a conflict with a preassigned configuration, a message prompts you to move the selector to the **Soft** position. If you receive this message, select **OK** to display the message in Figure 5-4 and install network drivers, if desired. However, the nonconflicting configuration will not take effect until you save and exit from EZStart, turn off your PC, move the selector to the **Soft** position on the adapter, and turn on your PC again.
- 3. To install a network driver, select **Yes** and proceed to Chapter 6.

**OR**

Select **No** to return to the EZStart main screen. You can then use the buttons at the lower half of the screen to perform other EZStart functions, or select **Exit** to quit EZStart.

## Multiple Adapter Guidelines

EZStart's Automatic Setup and Test feature offers a significant advantage to users who work with multiple adapters — namely, a fast and easy way of ensuring that adapters do not conflict with other installed devices.

For example, assume you want to install multiple adapters in the same computer. You can choose the **Soft** configuration for each adapter, install the first adapter in the computer, and use Automatic Setup and Test to automatically assign a nonconflicting configuration to that adapter. You can then repeat this procedure for each additional adapter you want to install in the same computer. Each time you run Automatic Setup and Test, the most recently installed

## USING EZStart TO SETUP AND TEST YOUR ADAPTER

adapter is configured with a unique address that will not conflict with any other installed device — including any adapter you previously installed.

EZStart's Automatic Setup and Test feature can also be helpful to users who want to install a single adapter in each one of a group of computers that have the same configuration. For the first adapter, choose a preassigned configuration that you believe will not conflict with other installed devices. Then install the adapter in the computer and use Automatic Setup and Test to verify that the preassigned configuration does not conflict with other installed devices. If it does not conflict, you can use the same preassigned configuration with the other adapters and install them in their respective computer without having to run Automatic Setup and Test after each installation — since you verified that the adapter configuration does not conflict with devices installed in computers that have the same configuration as the first.

If a conflict is detected, choose another preassigned configuration for the adapter and run Automatic Setup and Test again to verify that this configuration will not conflict with another installed device. When you find a nonconflicting configuration, use it for the other adapters you want to install into identically configured computers.





# INSTALLING NETWORK DRIVERS

# 6

.....

EZStart accesses network driver files using the compressed driver file, *SMCAnn.EXE*. The "A" in this filename denotes 8216 Elite Ultra and "nn" denotes the SuperDisk version. This chapter describes how to install network drivers from this compressed file on the SuperDisk.

## Overview

SMC provides a broad range of network operating system drivers and interface software, including NetWare (IPX, DOS, and OS/2 ODI), Microsoft LAN Manager and Windows NT. For optimum performance, most drivers can be loaded into your computer's upper memory area.

All SMC network driver files reside in a compressed file called *SMCAnn.EXE*, located in the root directory of the SuperDisk. There are two ways to install drivers from this compressed file:

- Using EZStart to install selected network drivers to a Destination Directory
- Using a manual method to extract the entire *SMCAnn.EXE* file to a Destination Directory

The following sections describe these methods.

### EZStart Method

Using EZStart, you can automatically copy the network drivers needed for your environment from the compressed file, *SMCAnn.EXE*, to a Destination Directory on your computer's hard disk; to a blank, formatted floppy disk; or to the SuperDisk. The installation instructions on the next page describe this procedure.

When you use EZStart to copy a network driver, you also copy supporting files for that driver, including configuration files, installation instructions, and release information. You can also view these supporting files on the computer screen and print them, if desired.



1. If you just completed the Automatic Setup and Test, proceed to step 2. Otherwise, load EZStart, as described on page 5-2, and select **Drivers** from the EZStart main screen.

The Network Operating System Selection screen appears, with a list of network operating systems (see Figure 6-1).




Figure 6-1. Selecting a Network Operating System

2. Select your network operating system from the list. If you do not see the desired network operating system in the list, use the scroll arrows on the right side of the list box to scroll through the list until you see your network operating system.
- ☞ If you prefer, use the Up and Down Arrow keys to scroll through the list line by line, or use the Page Up and Page Down keys to scroll a page at a time. When you find the desired network operating system, highlight it using the Up and Down Arrow keys and press Enter to select it.

## INSTALLING NETWORK DRIVERS

3. Select OK. A Driver Installation screen for the selected driver appears. Figure 6-2 shows the Driver Installation screen for NetWare DOS ODI Shell.




Figure 6-2. Sample Driver Installation Screen

EZStart suggests a Destination Directory consistent with the installation instructions for the network operating system, and lists the driver program, any supporting files, the installation file (named INSTALL.DOC for most drivers), and RELEASE.DOC file for that network operating system driver. The installation file contains complete instructions for installing the network driver. The RELEASE.DOC file contains release information about the current version of the network driver.

- Some network drivers can be installed simply by using EZStart to copy them from the SuperDisk to the appropriate destination on your computer's hard disk. Other network drivers require an installation disk, which you can create as follows:







**Notes**

# INSTALLING AND USING PC AGENT/SNMP 7

.....

This chapter describes how to install and use PC Agent/SNMP. PC Agent/SNMP is a Simple Network Management Protocol (SNMP) agent that collects valuable statistical and configuration information about your computer, adapter, and network. By analyzing this information, network administrators can keep their networks operating at peak efficiency.

## Overview

PC Agent maintains a database of computer and adapter statistical and configuration information in your computer's RAM. Most of this information— such as memory usage, disk capacity, and disk usage — is obtained directly from the computer and adapter during network operation; additional information — such as the name of the person using the computer and the computer's location, make, and model — is obtained from a user-defined configuration file.

PC Agent/SNMP is a true SNMP agent, allowing your computer and adapter to be directly monitored by any SNMP Manager, such as Hewlett Packard's OpenView, Sun SunNet Manager, and SMC's own EliteView. You can also use the **PC Agent** button on the EZStart main screen to view information collected by PC Agent/SNMP.

In addition, PC Agent/SNMP is network operating system-independent, offering end-to-end management of your entire star or bus network — even if the server is inoperable.



## Installation Instructions

The following procedure describes how to install PC Agent/SNMP. You can install PC Agent/SNMP after installing an agent-compatible driver, or at any time from the EZStart main screen.

After the driver is installed, you can use the instructions in this procedure to view the statistical and configuration information gathered by PC Agent/SNMP.

1. If you just installed an agent-compatible driver, proceed to step 3. Otherwise, load EZStart, as described on page 5-2, and select **PC Agent** from the EZStart main screen. The PC Agent/SNMP screen appears (see Figure 7-1).




Figure 7-1. PC Agent/SNMP Screen



person using the computer and the computer's location, make, and model.

7. If you select **Yes**, a message tells you that the configuration file does not exist. Select **Yes** to create the file or **No** to not create it.
8. Either accept the default filename (pcagent.cfg), or enter a unique name (including the full path) for the configuration file. Note that the PC Agent/SNMP files and the configuration file must reside in the same directory.
- ☞ If you installed PC Agent/SNMP for an adapter previously installed in the same computer, assign a different filename to this configuration file. If you desire, you can change the filename later when you save the file (refer to page 7-9).
9. Select **OK**. A screen similar to the one in Figure 7-3 appears.
10. Complete the fields in the screen shown in Figure 7-3. Refer to Table 7-1 for information on completing these fields.

**Modify/Create PC Agent/SNMP Configuration File**

Filename: C:\PCAGENT\pcagent.cfg

Community:	IP Address:
Contact:	TrapDestAdr.1:
Name:	TrapDestAdr.2:
Location:	TrapDestAdr.3:
Machine:	TrapDestPro.1:
CPU:	TrapDestPro.2:
Bios:	TrapDestPro.3:
Video:	

Help Save File Cancel

Drive path and filename for the PC Agent/SNMP configuration file on your PC

Figure 7-3. Creating a Configuration File







In This Field...	Enter This Information...
<b>ipSubNetMask</b>	IP subnet mask, indicating which bits in IP address field refer to the network address. This information is assigned a value in the form X.X.X.X, where each "X" is a value from 0 to 255. The object name is case-sensitive. (See the Note, below.) <i>Example: 255.255.0.0</i>

Note: The **ipDfGwy** and **ipSubNetMask** fields can be accessed directly in the PC Agent/SNMP configuration file; they cannot be accessed via EZStart.

11. To save the configuration file under a different name, enter this information next to **Filename**. Note that the configuration file must remain in the same directory as PC Agent/SNMP.
12. Select **Save File**. You return to the PC Agent/SNMP Information and Installation screen.
13. To view or print the PCAGENT.DOC file, which explains how to load PC Agent/SNMP with your network operating system and driver, select **Instructions**.
14. Your installation is now complete. To return to the EZStart main screen, select **Cancel** in each screen that appears until you see the EZStart main screen.
15. To perform other EZStart functions, select the appropriate button. To exit EZStart, select **Exit**.

## Loading and Unloading PC Agent/SNMP

The following sections describe how to load and unload PC Agent/SNMP.

### Loading PC Agent/SNMP


PC Agent/SNMP is a TSR program and consists of a single executable file: PCAGENT.EXE. After you install PC Agent/SNMP, you can have it automatically load each time your computer boots by adding the appropriate statements to your computer's AUTO-EXEC.BAT file and rebooting your computer.







The **Display Functions** area at the bottom of the screen provides buttons that let you navigate through other PC Agent/SNMP screens and perform the functions shown in Figure 7-5.



**Figure 7-5. Display Functions**

## PC Information

If you select PC in the **Display Functions** area, a screen similar to the one in Figure 7-6 appears. This screen displays information about the computer. Except for **Machine**, **Video**, and **Comments**, all the information shown in this screen is obtained from PC Agent/SNMP. **Machine** and **Video** information is obtained from the configuration file. Comments are notes that you entered for your own personal reference in the PC Agent/SNMP configuration file.




Figure 7-6. PC Information

### Adapter Information

If you select **Adapter** in the **Display Functions** area, a screen similar to the one in Figure 7-7 appears. This screen displays information about the adapter, including the network driver and the adapter configuration.




Figure 7-7. Adapter Information

## Traffic Information

If you select **Traffic** in the **Display Functions** area, a screen similar to the one in Figure 7-8 appears. This screen displays network traffic information.




Figure 7-8. Network Traffic Information

## Returning to the EZStart Main Screen

When you finish viewing PC Agent/SNMP data, select **Cancel** until the EZStart main screen reappears. You can then perform other EZStart functions by selecting the appropriate button, or exit EZStart by selecting **Exit**.

# USING EZStart FOR MANUAL SETUP

# A

.....

All devices installed in a computer (such as video adapters and disk controllers) or connected to computers (such as printers and modems) use the computer's resources. Configuration options such as IRQ channel, I/O base address, and memory base address determine how a computer's resources are apportioned to each device. If a computer has a number of installed and add-on devices, the devices may be vying for more resources than the computer can provide. As a result, you may encounter a conflict with the devices installed in your computer.

Using EZStart's Manual Setup feature, you can custom-configure your adapter to avoid conflicts with other installed and add-on devices. This appendix describes how to use EZStart's Manual Setup feature to configure your adapter.

## Using the Manual Setup Feature

To use the Manual Setup feature:

1. Make sure the adapter selector is in the default **Soft** position (refer to page 3-2).
2. Install the adapter in your computer (refer to Chapter 4).
3. Load EZStart (refer to page 5-2).
4. From the EZStart main screen, select **Manual Setup** (see Figure A-1). The Manual Setup screen in Figure A-2 appears.






Figure A-2. Manual Setup Screen

6. Under **Other Setup Selections**, you can:
  - Select the network interface.
  - Enable zero wait states — enable this option only with certain LAN servers that experience a heavy processing load, where the reduction of CPU utilization will be significant. Zero wait state capability is not supported by all computers. If you enable this option, use EZStart's Manual Test feature to run the Basic Adapter Test with the Repeat feature and verify that your adapter is working properly with this setting (refer to Appendix D).
7. Select **Save**. You return to the EZStart main screen.








address space used for common devices. The shaded areas represent the range being used.

**Table A-4. Memory Space Used by Various Devices**



☞ If the RAM window overlaps the DFFF - E000 boundary, performance will decrease.



# USING MACROS **B**

.....

This appendix describes EZStart's macro feature, which provides fast relief from repetitive operations. If you perform the same EZStart tasks over and over many times, you can use macros to make a "recording" of the procedure, then "play it back" when needed. Whether it's a simple job like viewing PC Agent/SNMP statistics, or a complex job like configuring and testing multiple adapters, it can probably be done better and faster by a macro.

## Overview

Think of a macro as your personal assistant. For example, you can create a macro to set up and test multiple adapters, run diagnostic tests, view PC Agent/SNMP statistics, or perform any other EZStart function. Once a macro learns the routine, just give the appropriate command and relax while the macro does the work.

The following list summarizes the reasons you should use macros:

- Macros don't make mistakes — once you record a macro, there's no need to worry about inaccuracy. The macro will repeat each time it is activated.
- Macros never forget — it's easier to keep track of a macro than a complicated list of keystrokes. With a macro, you only have to perform the keystrokes once. From then on, the macro will remember them for you.
- Macros don't get bored — if you find yourself performing the same monotonous task frequently, let a macro do it instead. Macros might not make your tasks more exciting, but they'll speed things up so you'll get your work done faster.
- Macros maintain continuity — if you use the same configuration or testing procedure with multiple adapters, you want things done the same way every time. Define your procedures with a macro and they will be performed *exactly* the same way every time.
- Macros are time savers — you can start a macro that will automatically perform the recorded task while you perform other work.



playback. For example, if you create a macro to configure your adapter and install a driver, you can insert a pause where you want the Destination Directory specified. Press Ctrl+F3 at the point where you want macro playback to continue.

5. When you finish recording the macro, press Ctrl+F1.

## Playing Back a Macro

The following sections describe how to play back a macro.

### Playing Back the Default Macro

To play back the default macro, EZSTART.MAC:

1. Load EZStart (refer to page 5-2).
2. Press Ctrl+F2. The message **PLAYING** appears on each screen as EZSTART.MAC is played back.

☞ If you want to stop playback, press Ctrl+F2 again.

### Immediate Macro Playback

To play back a macro immediately:

1. From the DOS command line, type **EZSTART [macro name]**, where *[macro name]* is the name of the macro you want to play back. For example, to play back a macro named TEST.MAC, type **EZSTART TEST**.
2. Press the Enter key. The macro is played back and the message **PLAYING** appears on each screen.

### Delayed Macro Playback

To delay macro playback until EZStart is loaded:

1. From the DOS command line, type **EZSTART [macro name] /D**, where *[macro name]* is the name of the macro you want to play back.
2. Press the Enter key.

The macro will not play back until you load EZStart and press Ctrl+F2. (However, if you press Ctrl+F1 instead of Ctrl+F2, any further keystrokes that you make will overwrite the existing macro of the same name, as described on the previous page.) When the







26. Select **OK** to verify the path and filename.
27. When the "Save Completed" message appears, select **OK**.
28. Select **Cancel** until you return to the EZStart main screen.
29. Press **Ctrl+F1** to stop recording the macro.
30. Select **Exit** to exit the EZStart main screen.

This concludes the macro recording procedure. You can now use the procedure on page B-3 to play back this macro each time you want to use the same scenario with other adapters.

**Notes**

.....

Your adapter can connect to the Ethernet network using a variety of cabling methods. This appendix describes cabling information for your adapter, starting with an overview of Ethernet topologies and cabling methods.

## Overview

Traditionally, the Ethernet cabling system, or topology, conforms to a linear bus consisting of a thick or thin coax cable segment with a terminating resistor at each end and a ground at one end. The linear bus is limited in distance and in the number of devices that can be attached to it. As a result, the linear bus is best suited for small, closely situated networks.

A less expensive alternative to thick and thin Ethernet cabling is twisted pair wiring. Twisted pair networks are configured in a star topology, rather than the linear bus used for Ethernet coax networks, and have a concentrator or multi-port repeater as the central component.

The following sections provide more information on these Ethernet cable types and topologies:

- For thick coax cabling — refer to page C-2.
- For thin coax cabling — refer to page C-4 .
- For twisted pair cabling — refer to page C-6.

## Thick Coax Cabling

Thick coax cable is the original media for Ethernet networks. It is primarily used for connecting workstations to mainframes and minicomputers. Each workstation attaches to the thick coax cable through the AUI connector on your adapter, an Attachment Unit Interface (AUI) drop cable, and a transceiver (see Figure C-1). In addition to providing a way for the workstation to attach to the network, the transceiver also monitors the cable to detect collisions.




Figure C-1. Thick Coax Cable Segment

### Thick Coax Cabling Requirements

Thick coax cabling is limited to 1,640 feet (500 meters) and can have up to 100 transceivers attached to it. The AUI cable can be up to 165 feet (50 meters) long.

Thick coax cabling must be terminated at each end using 50 ohm terminators, and one end must be earth grounded.

### Thick Coax Cabling Lengths

Table C-1 lists the cable lengths for thick coax cabling.

Table C-1. Thick Coax Cable Lengths

Description	Specification
Maximum trunk length	1,640 feet (500 meters)
Maximum number of nodes per trunk	100
Maximum number of trunks	5 (only 3 can have workstations attached)
Maximum length of entire network (all trunks added together)	8,200 feet 2,500 meters
Minimum cable length between taps	8 feet (2.5 meters)
Maximum length of drop cable	165 feet (50 meters)

Thick coax networks can be expanded by joining pairs of segments with repeaters. Repeaters amplify and regenerate the network signal. Up to five trunk segments can be connected using repeaters; however, only three of these segments can have workstations attached.

Repeaters count as workstations, so if you have two repeaters on a segment, a maximum of 98 additional workstations can be connected to the segment.

Thick coax networks can be expanded far beyond these limits by using bridges and routers, such as the SMC ES/1.



**IEEE-Approved and Nonapproved Cables**

Table C-2 lists cables that are approved and not approved by IEEE.

**Table C-2. Approved and Nonapproved Cables**

Cable	Description
<b>Approved Cable Types</b>	
802.3 10Base2	50 ohms, stranded tinned core
RG-58 a/u	50 ohms, stranded tinned core
RG-58 c/u	50 ohms, stranded tinned core
<b>Nonapproved Cable Types</b>	
RG-58	50 ohms, solid center core
RG-58 u	50 ohms, solid center core

**Thin Coax Cabling Lengths**

Table C-3 lists the cable lengths for thin coax cabling.

**Table C-3. Thin Coax Cable Lengths**

Description	Specification
Maximum trunk length	607 feet (185 meters)
Maximum number of nodes per trunk	30
Maximum number of trunks	5 (only 3 can have workstations attacked)
Maximum length of entire network (all trunks added together)	3,035 feet 925 meters
Minimum cable length between nodes	1.5 feet (0.5 meters)






Figure C-3. Twisted Pair Cabling

## Adapter Connectors

Your adapter may have one or more of the following connectors, depending on the model:

- AUI connector — a 15-pin, D-shaped connector for AUI interfaces to external transceivers. Refer to the next section.
- BNC connector — a cylindrical, bayonet-type connector for interfacing to thin Ethernet cables. Refer to page C-11.
- Twisted pair (UTP) connector — a small rectangular, snap-in, connector for interfacing to 10BASE-T cables. Refer to page C-11.

### AUI Connector

Your adapter may be equipped with an AUI connector like the one shown in Figure C-4. To connect to a thick Ethernet installation, connect your adapter's AUI connector to a standard transceiver or AUI cable that conforms to the 10BASE5 specification. An example of a



Table C-4 lists the pin assignments for the adapter's AUI port.


**Table C-4. AUI Port Pin Assignments  
(15-pin D-type)**

Pin	Signal Name	Signal Function
1	Control-in Shield	The shield for the CI twisted pair on the AUI cable.
2	Control-in Circuit A	The positive signal for the CI circuit. This circuit is used to send the mau_available and signal_quality_error messages to the equipment.
3	Data-out Circuit A	The positive signal for the DO circuit.
4	Data-in Shield	The shield for the DI circuit.
5	Data-in Circuit A	The positive signal for the DI circuit.
6	Voltage Common	The ground return for the VP circuit.
7	Not connected	
8	Not connected	
9	Control-in Circuit B	The negative signal for the CI circuit. This circuit sends the same signals listed for pin 2.
10	Data-out Circuit B	The negative signal for the DO circuit.
11	Data-out Shield	The shield for the DO twisted pair in the AUI cable.
12	Data-in Circuit B	The negative signal for the DI circuit.
13	Voltage Plus	The power supply to the transceiver. The supply must remain in the range 12V - 6% to 15V +5%.
14	Voltage Shield	The shield for the VC and VP (pins 6 and 13) twisted pair.
15	Not connected	









**Figure C-6. 8-Pin RJ-45 Connector Pins**



# MANUAL TEST AND TROUBLESHOOTING **D**



This appendix describes the EZStart Manual Tests you can perform in the unlikely event you encounter problems with your adapter. It also describes troubleshooting techniques you can use to resolve common network problems.

## **EZStart Manual Tests**

EZStart provides a Manual Test feature that comprises the following two tests:

- **Basic Adapter Test** — which verifies the operation of the adapter's basic functions.
- **Two Node Test** — which verifies the adapter's ability to communicate over the network with another adapter. The Two Node Test requires that an adapter identical to yours be installed in the network.

## **Running the Basic Adapter Test**

The Basic Adapter Test exercises the following adapter components and functions to verify that they are working properly:

- I/O Port Accessibility
- LAN Address ROM
- Link Integrity (for 10BASE-T connections only)
- On-board RAM
- Network Controller Registers
- On-board ROM (if a boot ROM is installed)
- Internal Loopback
- Interrupt Generation








Figure D-2. Respond To Test Messages Screen

### Setting Up the Initiator

1. On the computer whose adapter you are testing, load EZStart and select **Manual Test** from the EZStart main screen.

2. Select **Initiator** from the **Two Node Test** box. An **Initiate Test Messages** screen similar to the one in Figure D-3 appears.




Figure D-3. Initiate Test Messages Screen

3. Use either of the following methods to select a Responder:
  - If a Responder is set up and waiting to respond to test messages, select **Find Responder** on the **Initiate Test Messages** screen. EZStart automatically finds the computer set up as a Responder. If several computers are set up as Responders, EZStart selects the first one it finds, which eliminates the need to obtain the Responder's node address.

OR

- If a computer is not configured as the Responder, or if you set up several Responders and want to specify a particular one, select **Parameters** in the **Initiate Test Messages** screen and enter that computer's node destination address (for










Figure D-5. Sample Statistics Screen





## MANUAL TEST AND TROUBLESHOOTING

---

If one of the messages reappears, move the selector again, reset the computer, and rerun EZStart's Automatic Setup and Test.

If you tried the Soft configuration method and all of the settings in the preassigned configuration method, and still have an I/O conflict, try one of the following two methods.

### *Method 1:*

This procedure requires that you know or find out the I/O addresses of other adapters installed in your computer.

1. Determine what I/O addresses are being used by other installed adapters. You can find this information in the user manual for each adapter.
2. Turn off the computer's power. Then remove the adapter that is conflicting with your adapter.
3. Run EZStart and select **Manual Setup**. Select an unused I/O base address. (EZStart may tell you to move the selector to **Soft**.) Exit EZStart.
4. Reinstall the adapter that you removed in Step 2.
5. Run EZStart and select **Automatic Setup and Test** to test the configuration. This should resolve the I/O conflict.

### *Method 2:*

This procedure does not require you to know the I/O base addresses of other installed adapters.

1. Turn off the computer's power. Then remove all adapters except the video adapter, disk controller, and your adapter.
2. Run EZStart's Automatic Setup and Test to confirm that there are no I/O conflicts. If there are still I/O conflicts, contact Technical Support at the telephone numbers shown on the back cover of this *User Guide*.
3. Install one of the adapters that you removed, and run EZStart's Automatic Setup and Test.

Repeat this step, one adapter at a time, until one of the messages described on the previous page appears.

4. Remove the last adapter that you installed.
5. Run EZStart and select **Manual Setup**. Select a different I/O base address (refer to page A-4).  
If EZStart directs you to move the selector to the **Soft** position, do so.
6. Reinstall the last adapter that you removed.
7. Run EZStart again, and select **Automatic Setup and Test**. If there is still an I/O conflict, repeat this procedure. Keep a list of the I/O base addresses that you have tried so you don't use them again.

### Using Memory-Management Utilities

If your computer uses a memory-management utility such as EMM386, QEMM, or 386MAX, the utility uses part of the memory space normally allocated to your adapter. To exclude your adapter's 16 KB RAM address space from the memory-management driver, you generally must insert a command line into the CONFIG.SYS file. For example:

```
device=emm386 x=D0000-D3FFF
```

This command line should be placed at the beginning of the CONFIG.SYS file.

A similar situation exists with programs, such as Microsoft Windows, which map memory between 640 KB and 1 MB. Again, the best solution is to exclude your adapter's RAM address space from the memory-management driver.

For details on using a memory-management utility, refer to your utility's documentation.



# SPECIFICATIONS **E**

## *General*

Hardware compatibility .....	IBM-compatible computer with ISA or EISA bus
Standard supported .....	IEEE 802.3
I/O base address.....	200, 220, 240, 260, 280, 2A0, 2C0, 2E0, 300, 320, 340, 360, 380
Interrupt request channel.....	2/9, 3, 5, 7, 10, 11, 15
RAM buffer size .....	16KB
RAM base address.....	C000, C200, C400, C600, C800, CA00, CC00, CE00, D000, D200, D400, D600, D800, DA00, DC00, DE00, E000, E200, E400, E600, E800, EA00, EC00
RAM speed .....	35ns, 0 wait states enabled or
ROM size .....	disabled
RAM speed .....	64KB
ROM window size.....	16KB (SMC Boot ROMs)
ROM base address.....	C000, C200, C400, C600, C800, CA00, CC00, CE00, D000, D200, D400, D600, D800, DA00, DC00, DE00, E000, E200, E400, E600, E800, EA00, EC00, EE00

## *Electrical*

Power (adapter only) .....	+5 VDC, 1.1 Amps, maximum
Power (external transceiver) .....	+12 VDC, 0.5 Amps, maximum



## A

### Adapter

- Expansion slot requirements, 4-1
- Installation, 4-1
- models, 1-5
- optimizing performance, A-7
- Viewing the configuration, 7-12
- Adapter connectors, C-7
- Adapter information
  - PC Agent/SNMP, 7-15
- Approved thin coax cabling, C-5
- AUI connector, C-7
- Automatic Setup and Test, 5-5

## B

### Base address

- of Boot ROM, A-8
- Basic Adapter Test, D-1
- BNC connector, C-11
- Boot ROM
  - base address, A-8
  - installation, 2-1, C-1
  - window size, A-8

## C

### Cabling

- terminating a thin coax segment, 4-2
- thick coax, C-2
- thin coax, C-4
- thin coax connection, 4-2, 4-4, 4-5
- twisted pair, C-6
- Cabling lengths
  - thick coax cabling, C-2
  - thin coax cabling, C-5

- thick coax cabling, C-2
- thin coax cabling, C-5
- Cabling requirements
  - thick coax cabling, C-2
- Coax cabling
  - thick, 4-4
  - thin, 4-2
- Configuration
  - Methods, 3-1
- Configuration method
  - preassigned, 3-3
  - Soft, 3-2
- Configuration options, A-4
  - I/O base address, A-4
  - IRQ channel, A-6
  - RAM base address, A-6
- Configuration overview, 7-12
- Connecting to a network, 4-1
- Connections
  - to a 10BASE-T concentrator, 4-5
  - to a thick Ethernet cable, 4-4
  - to a thin Ethernet cable, 4-2
  - to a wall outlet, 4-5
- Connectors
  - AUI, C-7
  - BNC, C-11
  - twisted pair, C-11
  - unshielded twisted pair, C-11
- Connectors on adapter, C-7
- Contents of package, 1-4
- Conventions in User Guide
  - See User Guide conventions

## D

- Data collected by PC Agent/SNMP, 7-11
- Diagnostics
  - See Test



Memory-management  
utilities, D-13

Models, 1-5

    EtherCard Elite16 Ultra, 1-1

    EtherCard Elite16C Ultra, 1-1

    EtherCard Elite16T Ultra, 1-1

Monitoring LEDs, D-10

## N

Navigating through EZStart,  
5-1, 5-5

Network connection, 4-1

Network drivers

    installing, 6-1, 6-2

Nonapproved thin coax  
cabling, C-5

Notes, 1-5

## O

Optimizing adapter  
performance, A-7

Options for configuring  
adapter, A-4

Overview of macros, B-1

Overview of Manual Setup,  
A-1

## P

Package contents, 1-4

PC Agent/SNMP

    adapter information, 7-15

    configuration overview, 7-12

    installing, 7-3

    loading, 7-9

    overview, 7-1

    PC information, 7-14

    reloaded during current  
    session, 7-11

    requirements, 7-2

    traffic information, 7-16

    unloading, 7-11

    viewing information  
    collected by, 7-11

PC information

    PC Agent/SNMP, 7-14

Playing back a macro, B-3

Preassigned configuration  
method, 3-3

Printing

    driver configuration files, 6-7

    driver documents, 6-7

## Q

QEMM, D-13

## R

RAM base address, A-6

RAM used by various  
devices, A-7

Recording a macro, B-2  
    example of, B-4

Reloading PC Agent/SNMP  
during a session, 7-11

Requirements for using PC  
Agent/SNMP, 7-2

Running EZStart

    from a floppy disk, 5-2

    from a hard disk, 5-3

    from Microsoft Windows, 5-3

## S

Selecting a RAM base  
address, A-6

Selecting an I/O base  
address, A-4

Selecting an IRQ channel, A-6

Selecting configuration  
options, A-4

Selecting menu items, 1-5

Soft configuration method,  
3-2

# INDEX

---

Software requirements, 1-4  
System requirements, 1-4

## T

### Test

Basic Adapter, D-1  
Manual, D-1  
Two Node, D-3  
Thick coax cabling, 4-4, C-2  
cabling lengths, C-2  
cabling requirements, C-2  
Thin coax cabling, 4-2, C-4  
cabling lengths, C-5  
IEEE-approved and not  
approved, C-5  
386MAX, D-13  
Traffic information  
PC Agent/SNMP, 7-16  
Troubleshooting, D-10  
basic procedures, D-10  
I/O conflicts, D-11  
monitoring LEDs, D-10  
Twisted pair  
cabling, 4-5, C-6  
connector, C-11  
Two Node Test, D-3

## U

Unloading PC Agent/SNMP,  
7-11  
Unshielded twisted pair  
cabling, 4-5  
connector, C-11  
User entries, 1-6  
User Guide conventions, 1-5  
adapter models, 1-5  
Enter key, 1-5  
EZStart buttons, 1-6  
key combinations, 1-5  
notes, 1-5  
selecting menu items, 1-5

user entries, 1-6  
variables, 1-6

Using EZStart, 5-1  
Using the Manual Setup  
feature, A-1

## V

Variables, 1-6  
Viewing driver documents,  
6-6  
Viewing PC Agent/SNMP  
data, 7-11

## W

What else you need, 1-4  
Why you should use macros,  
B-1  
Window size  
of Boot ROM, A-8

tion or specifications as being compatible, SMC will make reasonable efforts to provide compatibility, except where the non-compatibility is caused by "bug" or defect in the third party's product.

**WARRANTY SERVICE:** Warranty service for hardware products may be obtained by delivering the defective product, accompanied by a copy of the dated proof of purchase, to SMC's Corporate Service Center or to an Authorized SMC Service Center during the applicable warranty period. Warranty service for software products may be obtained by telephoning SMC's Corporate Service Center or an Authorized SMC Service Center, within the warranty period. Products returned to SMC's Corporate Service Center must be preauthorized by SMC with a Return Material Authorization (RMA) number marked on the outside of the package, and sent prepaid, insured, and packaged appropriately for safe shipment. The repaired or replaced item will be shipped to Customer, at SMC's expense, not later than thirty (30) days after receipt by SMC.

**WARRANTIES EXCLUSIVE:** IF AN SMC PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY SHALL BE REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT SMC'S OPTION. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SMC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS.

SMC SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING. UNAUTHORIZED ATTEMPTS TO REPAIR, OR ANY OTHER CAUSE BEYOND THE RANGE OF INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

**LIMITATION OF LIABILITY:** IN NO EVENT, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) SHALL SMC BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE, LOSS OF BUSINESS, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF SMC OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the exclusion of implied warranties or the limitation of incidental or consequential damages for consumer products, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights which may vary from state to state.

Standard Microsystems Corporation  
80 Arkay Drive  
Hauppauge, New York 11788  
516-273-3100

**FOR TECHNICAL SUPPORT, CALL:**

New York: (8:30 AM - 6:00 PM Eastern Time)

(800) 992-4762 from U.S.A. and Canada

(516) 435-6250

(516) 434-9314 (Fax)

California: (7:00 AM - 5:00 PM Pacific Time)

(800) NET-LEAD (638-5323) from U.S.A. and Canada

(714) 707-5607

(714) 707-2491 (Fax)

**Bulletin Board Services (BBS)**

Modem settings: 2400,8,n,1

California: (714) 707-2481

New York: (516) 434-3162

Germany: 49 (89) 928806-50

France: 33 (1) 39.73.57.00

United Kingdom: 44 (0) 932 350681

INTERNET address is: [techsupt@ccmail.west.smc.com](mailto:techsupt@ccmail.west.smc.com)

Driver updates available from the internet:

Host name [sjf-lwp.novell.com](http://sjf-lwp.novell.com) (IP address: 130.57.11.140)

SMC Forum on CompuServe: at the prompt (!) type: GO SMC.

**FOR LITERATURE OR ADVERTISING RESPONSE CALL:**

(800) SMC-4-YOU from U.S.A. and Canada

(516) 435-6255 in New York

(516) 273-1803 (U.S.A. Fax)

61.2.238.2206 in Australia

61.2.238.2220 (Australia Fax)

33 (1) 30.87.42.42 in France

33 (1) 30.61.41.34 (France Fax)

49 (89) 928806-20 in Germany

49 (89) 928806-30 (Germany Fax)

65-320-8391 in Singapore

65-320-8359 (Singapore Fax)

44 (0) 932 350111 in the United Kingdom

44 (0) 932 350699 (United Kingdom Fax)



**Publication Number: 79-000145-001**