



Switch Settings: SW-1

```

| | | | on |
| 1 | 2 | 3 | 4 | |
| _ | _ | _ | _ | off |      1 = ON, 0 = OFF
| | | |
| | | | _____ Amount_of_Memory_On-board
| | 1 1 64/128K
| | 0 1 192/256 using 64K parts only.
| | 0 0 256K using 256K parts only.
| | 1 0 384K
| |
| | _____ Starting_Address
1 1 128K
1 0 256K
0 1 384K
0 0 512K
    
```

-----  
 Memory Configurations

Amount of Memory	Bank 1	Bank 2	Bank 3	Bank 4
64K	64K	Empty	Empty	Empty
128K	64K	64K	Empty	Empty
192K	64K	64K	64K	Empty
256K or 256K	64K Empty	64K Empty	64K 256K	64K Empty
320K	64K	Empty	256K	Empty
384K	64K	64K	256K	Empty

-----

NOTE : The parity chip order is from the bottom up. That is the parity chip for Bank 1 is on the bottom and the chip for Bank 4 is on the top.

-----