


LUCKY STAR TECHNOLOGY CO., LTD.

6IX-1

Configuration



CONNECTIONS

Purpose	Location	Purpose	Location
ATX power connector	ATX	Serial port 2	CN3
Power LED & keylock	C1/pins 1 - 5	Parallel port	CN4
Speaker	C1/pins 7 - 10	PS/2 mouse port	CN5
Reset switch	C1/pins 12 & 13	Serial port 1	CN6
IDE interface LED	C1/pins 15 & 16	Floppy drive interface	CN7
Turbo LED	C1/pins 18 & 19	IR connector	IR1
Green PC connector	C1/pins 21 & 22	CPU fan power	J1
IDE interface 1	CN1	USB connector	JP2
IDE interface 2	CN2	32-bit PCI slots	PC1 - PC4

USER CONFIGURABLE SETTINGS

Function	Label	Position
» Factory configured - do not alter	J3	Unidentified
» CMOS memory normal operation	JP4	Pins 1 & 2 closed
» CMOS memory clear	JP4	Pins 2 & 3 closed

SIMM CONFIGURATION

Size	Bank 0	Bank 1
8MB	(2) 1M x 36	None
16MB	(2) 2M x 36	None
16MB	(2) 1M x 36	(2) 1M x 36
24MB	(2) 2M x 36	(2) 1M x 36
32MB	(2) 4M x 36	None
32MB	(2) 2M x 36	(2) 2M x 36

40MB	(2) 4M x 36	(2) 1M x 36
48MB	(2) 4M x 36	(2) 2M x 36
64MB	(2) 8M x 36	None
64MB	(2) 4M x 36	(2) 4M x 36
72MB	(2) 8M x 36	(2) 1M x 36
80MB	(2) 8M x 36	(2) 2M x 36
96MB	(2) 8M x 36	(2) 4M x 36
128MB	(2) 8M x 36	(2) 8M x 36
128MB	(2) 16M x 36	None
136MB	(2) 16M x 36	(2) 1M x 36
144MB	(2) 16M x 36	(2) 2M x 36
160MB	(2) 16M x 36	(2) 4M x 36
192MB	(2) 16M x 36	(2) 8M x 36
256MB	(2) 16M x 36	(2) 16M x 36

CACHE CONFIGURATION

Note: 256KB/512KB cache is located on the Pentium II CPU.

CPU SPEED SELECTION

CPU speed	Clock speed	Multiplier	S1/1	S1/2	S1/3	S1/4	S1/5
200MHz	66MHz	3x	Off	Off	On	Off	Off
233MHz	66MHz	3.5x	Off	On	On	Off	Off
266MHz	66MHz	4x	Off	Off	Off	On	Off
300MHz	66MHz	4.5x	Off	On	Off	On	Off