



II. Jumper configuration

I. CPU Type Setting



The following illustrations list the jumper setting for the major Pentium or compatible CPUs.

For Intel Pentium™ 75MHz to 200MHz CPU

Intel Pentium	Jumpers (J14, J17, J19, J20, J24, J26)
200MHz = 3 x 66MHz	
166MHz = 2.5 x 66MHz	
150MHz = 2.5 x 60MHz	
133MHz = 2 x 66MHz	
120MHz = 2 x 60MHz	
100MHz = 1.5 x 66MHz	

Intel Pentium	Jumpers (J14, J17, J19, J20, J24, J26)
90MHz = 1.5 x 60MHz	
75MHz = 1.5 x 50MHz	

For Cyrix 6x86 120MHz to 200MHz CPU

Cyrix 6x86	Jumpers (J14, J17, J19, J20, J24, J26)
P166+ = 2 x 66MHz	
P150+ = 2 x 60MHz	
P133+ = 2 x 55MHz	
P120+ = 2 x 50MHz	


For AMD-K5™ 75MHz to 166MHz CPU

AMD-K5™	Jumpers (J14, J17, J19, J20, J24, J26)
PR166 = 2 x 66MHz	
PR150 = 2 x 60MHz	
PR133 = 1.5 x 66MHz	
PR120 = 1.5 x 60MHz	

AMD-K5™	Jumpers (J14, J17, J19, J20, J24, J26)
PR100 = 1.5 x 66MHz	
PR90 = 1.5 x 60MHz	
PR75 = 1.5 x 50MHz	

These powerful CPUs are designed with clock multiplier concept whereby the CPU core is running at a multiple of the system bus speed. This design technique reduces the requirement on the other system components while making higher performance possible. For example, the Intel 200 Mhz Pentium CPU core is running at 200 Mhz while the system bus is running at 66 Mhz. In other words the CPU core is operating with a 3X internal multiplier


2. Cache Memory Selection



Cache Type	J22		
Pipeline Burst (PB)	Close		
Burst	Open		
Cache Size	J21	J23	
256KB	Close	Open	
512KB	Open	Close	
Cache Size	Cache Data RAM (U2, U5)	Cache Tag RAM (U14)	J33
256KB	32K x 32 SRAM	8K x 8 / 32K x 8 SRAM	2-3
512KB	64K x 32 SRAM	16K x 8 / 32K x 8 SRAM	1-2

The above selection is shown for your reference only as your PCI6503 should have the cache size fixed at the factory.


3. Voltage Selection



AMD CPU

3.45V	3.3V	2.9V	2.7V	2.5V
J38	J38	J38	J38	J38
J39	J39	J39	J39	J39
J36	J36	J36	J36	J36
J37	J37	J37	J37	J37
J6	J6	J6	J6	J6
J7	J7	J7	J7	J7
J8	J8	J8	J8	J8
J9	J9	J9	J9	J9
J35	J35	J35	J35	J35
J34	J34	J34	J34	J34

Check up the voltage requirement of your AMD CPU as below diagram and select the voltage accordingly :




Operating Voltage:
B = 3.45V
C = 3.3V
F = 3.3V
H = 2.9V
J = 2.7V
K = 2.5V

Intel Pentium, Cyrix 6x86 & Cyrix 6x86L CPUs

3.3V (Pentium, Cyrix 6x86)	2.5V (Cyrix 6x86L)	2.8V (P55C)
J38 J39 J36 J37	J38 J39 J36 J37	J38 J39 J36 J37
J6 J7 J8 J9	J6 J7 J8 J9	J6 J7 J8 J9
J35 J34	J35 J34	J35 J34


Caution: Depending on the specific CPU & the clock speed, the temperature of the Heatsink of the Voltage Regulators (2.5v-3.0v, 3.3v-3.4v) might reach 100°C or higher during operation.

4. CMOS Reset




J25: Normal - Open
Clear - Close (briefly)

5. ECP DMA Channel Selector



DMA Channel	J28	J29
1	2-3	2-3
3	1-2	1-2

6. Memory Configuration



The SIMM Module can be installed into Socket 1 and 3 or/and Socket 2 and 4.

RAM Size	Socket 1 (J1)	Socket 2 (J2)	Socket 3 (J3)	Socket 4 (J5)
8MB	4MB	x	4MB	x
	x	4MB	x	4MB
16MB	4MB	4MB	4MB	4MB
	8MB	x	8MB	x
	x	8MB	x	8MB
24MB	4MB	8MB	4MB	8MB
	8MB	4MB	8MB	4MB
32MB	16MB	x	16MB	x
	x	16MB	x	16MB
	8MB	8MB	8MB	8MB
40MB	4MB	16MB	4MB	16MB
	16MB	4MB	16MB	4MB
48MB	8MB	16MB	8MB	16MB
	16MB	8MB	16MB	8MB
64MB	32MB	x	32MB	x
	x	32MB	x	32MB
	16MB	16MB	16MB	16MB
72MB	4MB	32MB	4MB	32MB
	32MB	4MB	32MB	4MB
80MB	8MB	32MB	8MB	32MB
	32MB	8MB	32MB	8MB
96MB	16MB	32MB	16MB	32MB
	32MB	16MB	32MB	16MB
128MB	32MB	32MB	32MB	32MB

Note: x - not used

7. Monochrome/Color Display Selector

Display	J15
COLOR	Close (Default)
MONO	OPEN

8. Flash EPROM Read/Write Selector

	J18
Normal Operation	1-2 (Default)
Programming Enabled	2-3

Set the jumper 2-3 before programming the Flash EPROM. When you finish updating, set the J18 back to the normal operation.

III. Connector Configuration

1. Power Connector (JP1)

Pin Number	Function
1	Power Good
2	+5V
3	+12V
4	-12V
5	GND
6	GND
7	GND
8	GND
9	-5V
10	+5V
11	+5V
12	+5V

2. Keyboard Connector (J4)

Pin Number	Function
1	Clock
2	Data
3	NC
4	Ground
5	+5V

3. Reset Switch Connector (JP10)

Setting	Function
Close	Reset the System
Open (Default)	Normal

4. Keylock Connector (JP9)

Pin Number	Function
1	LED (+)
2	NC
3	LED (-)
4	KeyLock Input
5	GND

5. Speaker Connector (JP7)

Pin Number	Function
1	+5V
2	+5V
3	Speaker Output
4	Speaker Output

6. Hard Disk LED Connector (JP8)

Pin Number	Function
1	LED (+)
2	LED (-)

7. Turbo LED Connector (JP6)

Pin Number	Function
1	LED (+)
2	LED (-)

8. Board Diagram

