
AmazePc® Inc.,

**AM-BX2V
ATX Form Factor
Main Board
User's Manual
Ver. 3.0**

For instant technical support and latest information, please visit www.amazepc.com and talk to us at www.amazepc.com/chat or ICQ56257071

Copyleft

Copyleft ©1999 by Amazepc[®] Inc,. Any part of this document may be reproduced, transmitted, transcribed, stored in a retrievable system, or translated into any natural or computer language, in any form or by any means without prior written permission. This manual and the information contained herein are protected by copyleft. No rights reserved.

Manual version: 3.0
Ref. No. 3053097
Published in 1999

Warning and disclaimer

This manual is designed to provide information about the pentium® II/III system board. Every effort has been made to make this manual as accurate as possible, but no warranty or fitness is implied. All the information is provided on an 'as is' basis. The author and his corresponding publishing company shall have neither liability nor responsibility to any person or entity with respect to any loss or damages arising from the information contained in this manual or from the use of the system board that accompanies it.

Information contained in this manual is subject to change without notice. The manufacturer of the system board will not be held responsible for technical or editorial omissions made herein, nor for the incidental or consequential damages resulting from its furnishing, performance, functionality or use. Subsequent changes to this manual will be incorporated into the next edition. We welcome any suggestion regarding this manual or our computer products.

Trademarks

- Intel and Pentium are registered trademarks of Intel Corporation.
- IBM is a registered trademark of International Business Machines Corporation.
- Microsoft is a registered trademark of Microsoft Corporation.
- PCI is a registered trademark of PCI Special Interest Groups.
- AWARD is a registered trademark of Award Software Inc.

All other trademarks are the property of their respective owners.

Table of contents

Chapter 1. Introduction	1
1-1 The system board overview	1
1-2 Specifications	3
1-3 Notice of Hardware installation	6
1-4 Notice for CD driver installation	7
Chapter 2. Installation	8
2-1 Layout reference	8
2-2 CPU speed setup	9
2-3 Jumper settings	10
2-3-1 TC1 – CMOS Status... ..	10
2-3-2 JP8 – Keyboard Wake up Selector.....	11
2-4 Connectors	12
2-4-1 Front panel.....	12
<i>Suspend mode interrupt(SMI)</i>	13
<i>Turbo LED</i>	14
<i>HD- LED</i>	15
<i>Speaker</i>	15
<i>Reset</i>	16
<i>Keylock</i>	17
<i>Power-LED</i>	18
2-4-2 Back panels.....	19
<i>COM1/COM2</i>	20
<i>LPT</i>	21
<i>USB</i>	22
<i>Keyboard & mouse</i>	22
2-4-3 Expansion slots.....	23
<i>AGP slots</i>	23
<i>PCI slots</i>	24
<i>ISA slots</i>	24

2-4-4	ATX power	25
2-4-5	Soft-PWR(JP5).....	26
2-4-6	CPU fan connectors.....	26
2-4-7	Floppy interface.....	27
2-4-8	IDE1 and IDE2.....	28
2-4-9	IrDA(Infrared) connector.....	29
2-4-10	SB-Link.....	30
2-4-11	Wake on LAN.....	31
2-5	DIMM memory installation.....	32
2-6	CPU RM kit assembling procedures.....	34
2-7	Keyboard password setup.....	36
Chapter 3. BIOS setup		37
3-1	Award BIOS CMOS setup.....	37
3-2	Standard CMOS setup.....	38
3-3	BIOS features setup.....	40
3-4	Chipset features setup.....	44
3-5	Power management setup.....	47
3-6	PNP/PCI configuration setup.....	50
3-7	Integrated peripherals.....	51
3-8	Supervisor/user password.....	54
3-9	IDE HDD auto detection.....	57
Chapter 4. Appendix.....		60
4-1	Memory map.....	60
4-2	I/O map.....	61
4-3	Time & DMA Channels Map.....	62
4-4	Interrupt map.....	63
4-5	RTC & CMOS RAM map.....	64
4-6	Award BIOS hard disk type.....	65
4-7	ISA I/O address map.....	67
Chapter 5. Q & A.....		69

5-1 Errors message during power on self test (POST).....69
5-2 Frequently asked questions.....71

Chapter 1: Introduction

1-1 Overview

AmazePC® BX series

The AmazePC® BX2V/V3 is a new generation Pentium® II/III Main board which integrates the latest advances in processor, memory, I/O technologies into an ATX form factor. The main board utilizes Intel® 82440BX AGP set designed for Pentium II/III CPU, and supports new architects such as high-speed AGP graphic Port, SDRAM, Ultra DMA/33, Bus master IDE and USB port. It has three Dual In-line Memory Modules (DIMM) which can be installed with SDRAM memory. The memory subsystem supports up to 512Mbyte SDRAM of non-buffered 3.3V using standard 168-pin DIMM sockets.

The AmazePC® main board using the slot 1 socket, accepts Intel® Pentium® II (66/100 MHz), Pentium® III(100MHz) processors at speeds from 266MHz to 800 MHz and is able to support faster CPUs upgraded in the future. Built-in second level (L2) cache in CPU, there is no cache necessary in this system board.

The AmazePC® main board has used Winbond high performance I/O Controller utilizes with fully Plug and Play device which supports 2.88 MB Floppy, Dual 16550 Compatible (with 16 bytes FIFO, up to 460K baud rate) Serial Port, ECP (Enhanced Capabilities Port), EPP (Enhanced Parallel Port) parallel port, Infrared IrDA (HPSIR), and Amplitude Shift Keyed IR. (ASKIR) port.

The AmazePC[®] main board supports 1*AGP & 5*PCI & 2*ISA, (four PCI Bus Mastering slots & 1 PCI Bus Slave slot) for highest performance I/O add-on adapter cards. The system board supports four Matrix Independent and one Matrix Dependent PCI Interrupt Routing for complete multiple PCI adapters operation up to 133MB/s data transfer rate on PCI bus compared to 33MB/s on EISA bus, synchronized operation CPU to PCI Interface for best graphical performance, 120MB/s PCI to system DRAM together with utilizing Snoop Ahead Features, and support back to back sequential CPU to PCI Memory writes to PCI Burst Write for full PCI through put.

The AmazePC[®] main board is also strengthened with Power Management Wake up Event such as **“WOL (Wake up on LAN),” “Modem ring on” and “Keyboard password setup,”** which are the new inventions to enable PCs to be turned on over the network or modem. These are also key benefits in PC operation, asset management, new system setup and power conservation.

In addition to the above hardware features, this system board is jumperless design, which allows user to set CPU frequency through BIOS. No jumper or hardware DIP switch is needed. With this design, the disadvantages of setting hardware CPU jumpers are improved to a better and easier procedure through BIOS.

In conclusion, the AmazePC[®] main board is a combination of the highest in performance, flexibility, efficiency, and ease of use that meets a variety of price/performance levels. The main board is an ideal platform for the increasing requirements of today's and future's desktop application.

1-2 Specifications

● **PCB Board size:** 30.5 cm x 18.00 cm

● **PCB layer:** 4 layers

● **Slot 1 socket**

Support Intel® Pentium® II CPU (66 MHz & 100 MHz freq.) or Pentium® III CPU(100 MHz)

****CPU is not enclosed in the package*

● **Memory DIMM:** 3 of 168-pin 3.3V DIMM

! Professional PC

A. 100 MHz freq.: PC 100- DIMM

B. 66 MHz freq. : SDRAM up to 384MB

EDO RAM up to 768MB (3.3v only)

! Basic PC: 66 MHz freq.

A. SDRAM up to 384MB

B. EDO RAM up to 768MB(3.3v only)

● **Expansion Slot :** 2x ISA, 5 x PCI slots (4* BUS Master & 1 Slave slots) and 1x A.G.P. Slot

● **Chipset :** Intel® **i440 BX** chipset---

! Intel® 82443BX CPI and A.G.P controller.

! Intel® 82371EB I/O bridge

● **BIOS:** licenced Award® full **PnP** (plug & play) BIOS, flash EEPROM for BIOS

● **I/O function**

! 2 x PCI IDE devices

! 1 x FDC, 2 x serial ports(16550 fast com)

! 1x parallel port device /EPP/ECP

! 2x USB connector

! IrDA (infrared) connector

● **Green function:** Complied with APM (Advanced Power Management)

● **ATX form factor**

The ATX form factor has been defined to address four major areas of improvement required of today's predominant form factors.

- ! Enhance PC ease-of-use with all built-in I/O connector
- ! Better support for current and future I/O
- ! Reduce total system cost
- ! Better support for future processor technology

ATX is an evolution of the popular Baby-AT form factor. By mounting the power supply on its side, the processor is relocated away from the expansion slots, and the longer side of the board is used to host more on-board I/O connector; this placing of I/O on the board reduces cabling inside the box, lower costs, and improves reliability and ease-of use. A flexible I/O panel allows ATX to support all current and future I/O requirements. The ATX power supply will directly suck the air out of chassis that will save the cost of a secondary fan in the system. System cost is further reduced by the higher integration of PC components onto the system board itself, saving materials, inventory holding, and assembly cost.

● **Electrical--- Typical power supply**

Below is reference for ATX case requirement on power supply.

Voltage	Tolerance	Current
+5V	± 5%	22 Amperes
+3.3V	± 5%	3 Amperes
+12V	± 10%	800 mA
-5V	± 5%	150 mA
-12V	± 5%	100 mA

***5V Trickle Voltage 750mA (to support WOL)

● **Power supply regulation**

Onboard switching voltage that support appropriate power to the CPU and future upgraded CPUs.

● **Over-current protection Circuit**

With AIC 1569CS AH13 (protect CPU from accident short circuit), and a set poly-fuses (protect Keyboard and USB devices from accident short circuit), if system current is over-loaded, the system will break down to protect direct damage of the main board.

● **Special features**

! Jumperless design

! Wake on lan (WOL)

! Modem ring on

! Auto detection of CPU voltage, fan & temperature

! Creative PCI sound Blaster AWE64D header (Support PC/PCI spec.)

! Windows 95 power off

! Keyboard wake up

! PS/2 mouse wake up



1-3 Notice of Hardware Installation

A. Check the package before hardware installation

In the package, there are:

- ! the main board
- ! manual
- ! cables
- ! driver & utility / CD
- ! retention mechanism


If any of these items is missing or damaged, contact the dealer from whom you purchase. Leave this main board in its original package until you are ready to install it.

B. Make sure power is off during hardware installation

C. While working with the main board, wears a grounded wristband or ankle strap to avoid ESD (Electrical Static Discharge).

1-4 Notice for CD driver installation

This CD contains drivers as below:




1. **Main boards:** i440BX®, VIA®, i810 main boards
2. **Solo-1:** ESS-solo-1 sound driver
3. **G1518SM:** CPU voltage/temperature and fan speed detection software
4. **Pccillin:** anti- virus protection software



*Note: Read "index" before installing required drivers.
"Index" file is HTML format.*

Chapter 2. Installation

2-1 Layout reference



TURBO66 is an over-clocking jumper, which enables 66 MHz CPU to run at 100 MHz. TURBO66 is only reserved for internal test only. No support is provided for any desktop.

ROM PCI/ISA BIOS (2A69RL1A)
 CPU FEATURES SETUP
 AWARD SOFTWARE, INC.

CPU Speed	: 233Mhz (66x3.5)
-----------	-------------------

ESC : Quit ↑↓+ : Select Item
 F1 : Help PU/PD/+/- : Modify
 F5 : Old Values (Shift)F2 : Color
 F7 : Load Setup Defaults

“CPU speed” press “+” or “-“ to choose “CPU speed” according to your CPU

Since this is jumperless designed, there is no jumper setting to adjust CPU speed. The user only needs to set speed in BIOS. Please enter BIOS & find “CPU speed” item under “Chipset features setup” and set as above.




When Socket370(CPU Speed 300-500MHz) converts into Slot1, S9 Daughter Card is needed.

2-3 Jumper setting

Benefited from jumperless design of this system board, only jumper “RTC” is required of hardware handling, which especially makes hardware installation an easier thing to achieve.

2-3-1 RTC1-CMOS Status

RTC1 is a 2-pin connector. Clear CMOS if system password is forgotten. Below is details to show how to clear CMOS.



Pin assignment	Operation
1-2	Normal setup (default)
2-3	Clear CMOS

Procedure to clear CMOS:

Step 1: Shut down the system and disconnect the power supply from AC power.

Step 2: Pull out the ATX cable from ATX connector "PS1"

Step 3: Short the CMOS jumper by putting jumper cap on Pin 2-3 for a few seconds.

Step 4: Return to pin 1-2 for normal setup.


Step 5: Link ATX power cable to PS1 connector.

Step 6: Turn on system power.

Note: if you'd like to set password, press "Del" Key during system bootup to enter CMOS Setup to establish a new password.

2-3-2 JP8 - Keyboard Wake up Selector


JP8 is a 3-pin jumper which providing keyboard wake up function.




2-4 Connector

2-4-1 Front panel

Front panel has connectors such as “SMI,” “Turbo-LED,” “HD-LED,” “Reset,” “Speaker,” “Keylock,” and “Power-LED.” Please refer to details as below.



Suspend mode interrupt (SMI)




SMI connector is a 2-pin Berg strip, which is also called “green” or “sleep” connector. When SMI is turned from open to close and back to open, the system will enter sleep mode immediately. This function is to make sure power saving is working well. In PC system, it is used to connect to the push button SMI switch located on the case’s front panel (if there is). The system can be forced to power saving mode by pressing the SMI switch.

Pin assignment	Sleep/green connector
Pin 1	Sleep
Pin 2	Ground (GND)

SMI	Operation
Open	Normal
Close	System will enter sleep mode


TURBO LED



Turbo LED with a 2-pin Berg strip on front panel indicates the current speed status of system. It is used to connect to the Turbo Led on the front panel of the case (if there is).

Pin assignment	Signal
Pin with "+" signal	Anode (+)
Pin 2	Cathode (-)


HD-LED



Marked as “**HD-LED**,” Hard Disk activity LED connector is a 2-pin keyed Berg strip. It is used to connect to front panel Hard Disk LED.

Pin assignment	Signal
Pin 1 with “+” signal	Anode “+”
Pin 2	Cathode


Speaker



Speaker (SPK) connector is a 4-pin keyed Berg strip. It is used to connect to the case speaker to the system board for sound purpose.

Pin assignment	Signal	Pin assignment	Signal
Pin 1	VCC	Pin 3	NC
Pin 2	NC	Pin 4	speaker data out

Reset




Reset connector is a 2 –pin keyed Berg strip, connected to the push button reset switch on the case’s front panel. Shorting both pin 1& pin 2 can effect system reset function, which is similar to the power and then on again.

Pin assignment	Signal
Pin 1	Reset input
Pin 2	GND

Reset	Operation
Open	Normal
Close	Hardware reset

Keylock




Keylock is a 2-pin connector. It is used to connect the key lock on the case front panel (if there is). Keyboard may be disconnected with the system through this function.

Pin assignment	Signal
Pin 1	GND
Pin 2	Keylock

Keylock	Operation
Open	Keyboard works normal
Close	Short the connector to be disconnected with the system

Power-LED




Power LED is 3-pin connector. It is used to connect to the LED on the case front panel. The LED shows the status of the power.


Pin	Signal
Pin 1	VCC
Pin 2	NC
Pin 3	GND

2-4-2 Back panel

There are COM1/ COM2, LPT, USB and keyboard/ mouse on case back panel.
Please refer to more details as below.



COM1/COM2




The onboard serial port 1 and port 2 are the 9-pin D-subminiature male connector COM1 and COM2. COM1 and COM2 can be disabled in BIOS setup. Please refer to Chapter 3 “Integrated Peripherals” for more information.

Pin	Pin signal	Pin	Pin signal
Pin 1	Carrier detect (CD)	Pin 5	Signal ground
Pin 2	Receive data (RXD)	Pin 6	Data set ready
Pin 3	Transmit data (TXD)	Pin 7	Request to send (RTS)
Pin 4	Data terminal ready (DTR)	Pin 8	Clear to send (CTS)
Pin 9	Ring indicator		

LPT


The onboard parallel port is a 25-pin female connector, marked as “LPT”



Pin	Signal	Pin	Signal
Pin 1	Strobe	Pin 14	Auto feed
Pin 2	Data bit 0	Pin 15	Error
Pin 3	Data bit 0	Pin 16	Init
Pin 4	Data bit 0	Pin 17	SLCT in
Pin 5	Data bit 0	Pin 18	Ground
Pin 6	Data bit 0	Pin 19	Ground
Pin 7	Data bit 0	Pin 20	Ground
Pin 8	Data bit 0	Pin 21	Ground
Pin 9	Data bit 0	Pin 22	Ground
Pin 10	ACK	Pin 23	Ground
Pin 11	Busy	Pin 24	Ground
Pin 12	PE	Pin 25	
Pin 13	SLCT		

USB


USB



Universal Serial Bus connector, marked as “USB,” is used to connect USB devices. There are 2 USB connectors on this system board.

Keyboard & Mouse (J1)

J1: Keyboard & Mouse connector



The onboard PS/2 keyboard and mouse connector is 6-pin Mini-Din connectors, marked as “KB” and “Mouse.”


Pin	Description
Pin 1	Data signal
Pin 2	NC
Pin 3	Ground
Pin 4	+5V DC
Pin 5	Clock signal
Pin 6	NC

2-4-3 Expansion slots

Expansion slots contain one A.G.P slot, five PCI slots, and two ISA slots on this system board. Below are details.


AGP slot

AGP (Accelerated Graphic Port) is the new bus standard that allows the bus speed to run at 66 MHz with up to 133 MHz data transfer capabilities, which is four times as fast as that of the PCI bus. At this speed, the AGP graphic cards can transfer data up to 523MB/second. This high transfer capabilities enables 3D graphic applications, multiple media applications, uncompressed to run smoothly and display in broadcasting quality.




PCI slots

There are Five PCI slots on board; 4 are “master” bus and one “slave” bus slave. 133MB/s data transfer rate on PCI bus can be compared to 33MB/s on EISA bus or 8MB/s on ISA bus. Synchronize Operation CPU to PCI interface for good graphic performance.




ISA slots

There are 2 standard 32-bit ISA slots on board. All of them are bus mastering.




2-4-4 ATX power

ATX power connector has 20 pins, which is designed for ATX case especially. The ATX power supply supports the function of the **“Soft Power On Momentary switch”** which connects on the front panel switch to the 2-pin **SOFT-PWR** on the system board. While the power switch on the back of ATX power is turned on, the full power will not go into the system board until the front panel switch is momentarily pressed. Push the switch again to turn off the power to the system board.



Pin	Signal	Pin	Signal
Pin 1	3.3V	Pin 2	3.3V
Pin 3	3.3V	Pin 4	-12V
Pin 5	GND	Pin 6	GND
Pin 7	5V	Pin 8	SOFT-PWR ON
Pin 9	GND	Pin 10	GND
Pin 11	5V	Pin 12	GND
Pin 13	GND	Pin 14	GND
Pin 15	RAWPOWER	Pin 16	-5V
Pin 17	5V	Pin 18	5V
Pin 19	+12V	Pin 20	5V


2-4-5 Soft-PWR (JP5)



ATX soft-PWR switch connector is Soft-PWR with 2 pins.

Pin	Signal
Pin 1	5VSB
Pin 2	PWR in


2-4-6 CPU fan connectors



There are 3 fan connectors on this system board, and they are marked as “**Fan 1**,” “**Fan2**,” and “**Fan3**.” Each fan connector has three pins.

Pin	Signal
Pin 1	Ground
Pin 2	+12V
Pin 3	Sense


2-4-7 Floppy interface



Floppy interface connector with 34 pins is used to attach the floppy drive cable.

Pin	Signal	Pin	Signal
Pin 1	GND	2	Data rate selection
Pin 3	GND	4	NC
Pin 5	GND	6	NC
Pin 7	GND	8	FDC index
Pin 9	GND	10	FDD Motor A enable
Pin 11	GND	12	FDD Drive B enable
Pin 13	GND	14	FDD drive A enable
Pin 15	GND	16	FDD Motor enable
Pin 17	GND	18	FDC head direction
Pin 19	GND	20	FDC step pulse output to the drive during a SEEK operation
Pin 21	GND	22	FDC write enable serial data to the Drive
Pin 23	GND	24	FDC write enable identify
Pin 25	GND	26	Floppy disk track 0. Indicates that the head of the selected drive is on track zero.
Pin 27	GND	28	FDD write protect. Indicates that the disk of the selected drive is write-protected.
Pin 29	GND	30	Read disk data, serial data input input from the FDD
Pin 31	GND	32	Floppy disk side 1 select
Pin 33	GND	34	Floppy disk change. This is an input pin that senses whether the drive door has been opened or a diskette has been changed.


2-4-8 IDE1 and IDE2



IDE 1/ IDE 2 both have 40 pins. There are 2 IDE connectors supported on this system board. IDE1 is primary channel, and IDE2 is secondary channel. Each channel supports 2 IDE devices, and 4 channels in total for this system board.

Pin	Signal	Pin	Signal
Pin 1	IDE reset	Pin 2	Ground
Pin 3	Data 7	Pin 4	Data 8
Pin 5	Data 6	Pin 6	Data 9
Pin 7	Data 5	Pin 8	Data 10
Pin 9	Data 4	Pin 10	Data 11
Pin 11	Data 3	Pin 12	Data 12
Pin 13	Data 2	Pin 14	Data 13
Pin 15	Data 1	Pin 16	Data 14
Pin 17	Data 0	Pin 18	Data 15
Pin 19	Ground	Pin 20	Key (NC)
Pin 21	PDREQ	Pin 22	Ground
Pin 23	I/O write	Pin 24	Ground
Pin 25	I/O read	Pin 26	Ground
Pin 27	NC	Pin 28	ALE
Pin 29	NC	Pin 30	Ground
Pin 31	IDE IRQ 14	Pin 32	IOSC15
Pin 33	Address A1	Pin 34	NC
Pin 35	Address A0	Pin 36	Address A2
Pin 37	IDE chip select 0	Pin 38	IDE chip select 1
Pin 39	IDE active	Pin 40	Ground

2-4-9 IR (Infrared) connector




IR connector supports wireless infrared module. With this module and application software like LAPlink, or WIN95 Direct Cable Connection, user can transfer data to or from laptops, notebooks, PDA and printers. This connector supports **HPSIR**, **ASKIR**, and **Fast IR**.

Attach Infrared module to IR connector and enable BIOS “Infrared function.”
Be sure to put in the right orientation during attachment.

Pin	Signal
Pin 1	RX
Pin 2	GND
Pin 3	TX
Pin 4	+5V
Pin 5	RXH
Pin 6	VCC
Pin 7	GND


2-4-10 SB-Link



SB-LINK is used to attach any “PC/PCI” standard sound card like Creative AWE64D or Yamaha XG...for compatibility under DOS mode.

Pin	Signal
Pin 1	GNT#
Pin 2	GND
Pin 3	NC
Pin 4	REQ#
Pin 5	GND
Pin 6	SIRQ#

2-4-11 Wake on LAN




Wake on LAN, marked as “**WOL**,” is a 3-pin connector. To support this feature, a network card is required for the system. More than that, a network management software must be installed too.

Pin	Signal
Pin 1	5V trickle voltage
Pin 2	Ground
Pin 3	PME signal



Wake on LAN requires 5V Trickle Voltage 750mA to support.

2-5 DIMM memory installation




DIMM1 

DIMM2 

DIMM3 

Insert the module as shown. Due to different number of pins on either side of the breaks, the module will only fit in the orientation as shown. There is no jumper setting for memory configuration.





Note 1: Chipset only allows synchronuos operation for DIMM and CPU. Therefore, to have a stable system, the user must adopt 100 MHz **“PC-100 SDRAM memory DIMM” (3.3V)** for 100 MHz Deschutes CPUs. For 66 MHz CPUs **Klamath™ and Celeron™ (Covington™ & Mendocino™)**, the user may use either 3.3V EDO RAM or SDRAM.




Note 2: Either DIMM 1, DIMM2, or DIMM3 supports 8 MB, 16 MB, 32 MB, 64 MB, and 128MB. Maximum memory for **SDRAM is up to 384MB; EDO RAM is up to 768 MB.**

2-6 CPU RM kit assembling procedure


The enclosed RM kit is the latest model suitable for both Klamath and Celeron. It is not necessary to change different CPU RM kits for different CPU models.

1. Check if the following set of piece parts are included in your package. **4 separate piece parts in total.**

Retention mechanism (R.M.): 2 pcs




RM. Attach Mount (RMAM): 2 pcs



2. Make sure power is off during assembly.


3. Insert the RMAMs through the bottom of the motherboard and attach them to the retention mechanism.



4. Fasten up the screws on the retention mechanism to tighten up retention mechanism and RMAM. Check if all the piece parts are fastened tightly.

5. Put the CPU in the RM kit.(you must push the CPU horizontally into the RM kit.)

 **Note:** Due to different packages of Celeron and Klamath, there are 2 locations to get them locked in the RM kit. Below is notice to unlock the 2 CPUs.



2-7 Keyboard password setup


To give the user more choices on power on setup, the main board adds especially the following options.

Go to BIOS "**Integrated Peripherals,**" and find the item, "**power on function,**" in which there are "**KB power on password, hot key power on, mouse left, mouse right, and button only.**"

Item	Procedure	Special note
KB power on password	1. enter password: 5 spaces allowed. 2. Confirm password: key in the password to confirm again.	The system can only be turned on through KB password. Case button can not work. If password is forgotten, please clear CMOS and reset again.
Hot key power on	12 options: " ctrl+f1...ctrl+f12. " the user may choose either Of them by " page up " or " page down. "	The system can be turned on either by hot key or pushing case power on button.
Mouse left	Mouse left (PS/2 mouse only)	The system can be turned on either by PS/2 mouse or pushing case power on button.
Mouse right	Mouse right (PS/2 mouse only)	The system can be turned on either by PS/2 mouse or pushing case power on button.
Button only	Case button	The system can be turned on by case button.


Chapter 3. BIOS setup

3-1. Award BIOS CMOS setup



The menu displays all the major selection items and allow user to select any of shown item. The selection is made by moving cursor (press any direction key) to the item and press <Enter> key. An on-line help message is displayed at the bottom of the screen as cursor is moving to various items which provides user better understanding of each function. When a selection is made, the menu of selected item will appear. So the user can modify associated configuration parameters.

3-2. Standard CMOS setup



The "Standard CMOS Setup" allows user to configure system setting such as **current date and time, type of hard disk drive** installed in the system, **floppy drive type**, and the type of **display monitor**. Memory size is auto detected by the BIOS and displayed for your reference. When a field is highlighted (direction keys to move cursor and <Enter> key to select). The entries in the field will be changed by pressing <PageDown> or <PageUp> key or user can enter new data directly from the keyboard.

Hard Disk Configurations

TYPE : select from "1" to "45" to fill remaining fields with redefined values of disk drives. Select "USER" to fill the remaining fields. Select "AUTO" to detect the HDD type automatically.

SIZE : the hard disk size. The unit is mega byte(MB).

CYLS : the cylinder number of the hard disk.

HEAD : the read/write head number of hard disk. The range is from "1" to "16".

PRECOMP: the cylinder number at which the disk drive changes the write timing.

LANDZ : the cylinder number that the disk drive heads (read/write) are seated when the disk drive is parked.

SECTOR : the sector number of each track defined on the hard disk. The range is from "1" to "64".

MODE : select "AUTO" to detect the mode type automatically. If your hard disk supports the LBA mode, select "LBA" or "LARGE". However, if your hard disk cylinder is more than 1024 and does not support the lba function, you have to set at "LARGE." Select "NORMAL" if your hard disk supporting cylinder is below 1024.



Note 1: if hard disk primary master/slave and secondary master/slave were set to "auto," the hard disk size and model will be auto detected on display during POST.



Note 2: "halt on" is to determine when to halt the system by the BIOS if error occurred during POST.

3-3. BIOS features setup

Menu below shows all of the manufacturer's default values of this main board. Move the cursor by pressing direction keys and <PageDown> or <PageUp> key to modify the parameters, pressing [F1] key to display help message of the selected item. This setup program also provide 2 convenient ways to load the default parameter data from BIOS [F6] or CMOS [F7] area if shown data is corrupted. This provides the system a capability to recover from any possible error.

```
ROM PCI/ISA BIOS (2A69KL1A)
BIOS FEATURES SETUP
AWARD SOFTWARE, INC.

Virus Warning           : Disabled
CPU Internal Cache     : Enabled
External Cache         : Enabled
CPU L2 Cache ECC Checking : Enabled
Processor Number Feature : Enabled
Quick Power On Self Test : Enabled
Boot Sequence          : A,C,SCSI
Swap Floppy Drive      : Disabled
Boot Up Floppy Seek    : Disabled
Boot Up NumLock Status : On
Gate A20 Option        : Fast
Typematic Rate Setting : Disabled
Typematic Rate (Chars/Sec) : 6
Typematic Delay (Msec) : 250
Security Option        : Setup
PCI/UGA Palette Snoop : Disabled
OS Select For DRAM > 64MB : Non-OS2

Video BIOS Shadow      : Enabled
C8000-CBFFF Shadow    : Disabled
CC000-CFFFF Shadow    : Disabled
D0000-D3FFF Shadow    : Disabled
D4000-D7FFF Shadow    : Disabled
D8000-DBFFF Shadow    : Disabled
DC000-DFFFF Shadow    : Disabled

ESC : Quit           ↑↓←→ : Select Item
F1  : Help           PU/PD/+/- : Modify
F5  : Old Values    (Shift)F2 : Color
F7  : Load Setup Defaults
```

Virus Warning

:Enabled

:Disabled (default)

CPU Internal Cache

Enabled : enable L1 cache

Disabled: disable L1 cache

External Cache

Enabled (default): enable L2 cache

Disabled: disable L2 cache

CPU L2 Cache ECC Checking

Enabled (default): enable L2 cache ECC checking

Disabled: disable L2 cache ECC checking

Quick Power On Self Test

This category speeds up power on self test.

Enabled : BIOS will shorten or skip some check items.

Disabled: normal speed

Boot sequence

This category determines which drive the system searches first. Take “**A,C,SCSI**” for example. System will search in turn for floppy disk drive; second is hard disk drive, and finally SCSI drive. Default value is “**A,C,SCSI**”. Options are as below: **A,C,SCSI; C,A,SCSI, C,CDROM,A; CDROM,C,A; D,A,SCSI; E,A,SCSI; F,A,SCSI; SCSI,A,C; SCSI,C,A; C Only; LS/ZIP,C.**

Swap Floppy Drive

Enabled: floppy A&B will be swapped.

Disabled(default): floppy A&B will be not swapped.

Boot Up Floppy Seek

BIOS will determine if the floppy disk drive is 40 or 80 tracks. 360k type is 40 tracks while 720K/ 1.2M and 1.44M are all 80 tracks. Default value is **disabled**.

Boot Up Numlock Status

:On(default)

:Off



Gate A20 Speed

:Normal

:Fast (default)

Typematic Rate Setting

This determines the typematic rate.

Enabled: enable typematic rate and typematic delay programming.

Disabled: disable typematic rate and typematic delay programming. The system bios will use default value of this 2 items and the default is controlled by keyboard.

Typematic Rate(Chars/Sec)

6: 6 Characters Per Second(default)

8: 8 Characters Per Second

10 : 10 Characters Per Second

12: 12 Characters Per Second

15: 15 Characters Per Second

20: 20 Characters Per Second

24: 24 Characters Per Second

30 : 30 Characters Per Second

.....

Typematic Delay (Msec)

This is the interval between the first and second character displayed.

250 : 250 msec (default)

500 : 500 msec

750 : 750 msec

1000 :1000 msec

Security Option (refer to page 54)

:Setup (default)--- security protection in CMOS setup menu

Setting password in BIOS CMOS “**Supervisor Password**” or **User Password,**” the user needs to key in password if entering BIOS CMOS setup.

:System---security protection in system boot-up & BIOS setup

This function secures the system under system boot-up and BIOS setup.

PCI/VGA Palette Snoop

Enabled: it allows you to install an enhanced graphics adapter card.

Disabled (default): If your graphics adapter card does not support the palette snoop function, please set at **Disabled** to avoid system malfunction.

OS Select For DRAM> 64MB

This option is especially set for OS2 operating system. Set “**Non-OS2**” for RAM memory over 64MB and set “**Non-OS2**” for other operating systems like Windows® 95/98 or NT.

:Non-OS2 (default)

:OS2

Video BIOS Shadow

It determines whether video BIOS will be copied to RAM. However, it is optional from chipset design. Video shadow will increase the video speed.

Enabled : Video Shadow is enabled (default)

Disabled: Video Shadow is disabled

C8000-CBFFF Shadow, CC000-CFFF Shadow, D0000-D3FFF Shadow, D4000-D7FFF Shadow, D8000-DBFFF Shadow, DC000-DFFF Shadow

These are categories determining whether optional ROM will be copied to RAM by 16KB or 32KB per unit and the size depends on chipset.

:Enabled

:Disabled(default)

3-4. Chipset features setup

ROM PCI/ISA BIOS (2A69KL1A) CHIPSET FEATURES SETUP AWARD SOFTWARE, INC.			
Auto Configuration	: Enabled	Auto Detect DIMM/PCI Clk	: Disabled
EDO DRAM Speed Selection	: 60ns	Spread Spectrum	: Disabled
EDO CAS# MA Wait State	: 2	CPU Warning Temperature	: Disabled
EDO RAS# Wait State	: 1	Shutdown Temperature	: 60°C/140°F
SDRAM RAS-to-CAS Delay	: 3	Current CPU Temperature	:
SDRAM RAS Precharge Time	: 3	Current CPUFAN2 Speed	:
SDRAM CAS latency Time	: 3	Current CPUFAN1 Speed	:
SDRAM Precharge Control	: Disabled	Current Vin3(U)	:
DRAM Data Integrity Mode	: Non-ECC	Current Vin1(U)	:
System BIOS Cacheable	: Enabled	Current Vin2(U)	:
Video BIOS Cacheable	: Enabled	Current Vdd(U)	:
Video RAM Cacheable	: Disabled		
8 Bit I/O Recovery Time	: 1		
16 Bit I/O Recovery Time	: 2		
Memory Hole At 15M-16M	: Disabled		
Passive Release	: Enabled	ESC : Quit	↑↓←→ : Select Item
Delayed Transaction	: Disabled	F1 : Help	PU/PD/+/- : Modify
AGP Aperture Size (MB)	: 256	F5 : Old Values (Shift)	F2 : Color
		F7 : Load Setup Defaults	

Auto configuration

BIOS will automatically detect the CPU speed and will auto-configure the bus frequency, DRAM speed, cache and read/write cycle.

Enabled: (default)

Disabled:

SDRAM RAS# precharge time

SDRAM precharge time by RAS.

: 4

: 3 (default)

CDS RAS to CAS delay

This controls the DRAM page miss and row miss leadoff timing.

: 2

: 3 (default)

System BIOS cacheable

define whether system bios area cacheable or not.

:enabled

:disabled (default)

Video BIOS cacheable: to define whether video bios area cacheable or not.

:enabled

:disabled (default)

8 Bit I/O Recovery Time:

This field defines the recovery time from 1 to 8 for 8-bit I/O.

16 Bit I/O Recovery Time:

To define the recovery time from 1 to 4 for 16-bit I/O.

Memory Hole At 15M-16M: this field enable a memory hole in main memory space. CPU cycles matching an enabled hold are passed on to PCI note that a selected can not be changed while the L2 cache is enabled.

:Enabled

:Disabled (default)

Video RAM Cacheable

:Enabled --- allows caching of the video RAM, resulting in better system performance. However, if any program writes to this memory area, a system error may occur.

:Disabled (default)

AGP Aperture Size

To select the size of the Accelerated Graphics Port (AGP) aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation.

:128M(default)

:64M, 32M, 16M, 8M, 4M

CPU speed & CPU ratio

Please refer to page 10 “2-2 CPU speed setup” for details.

Shutdown Temperature

System will shut down automatically when CPU temperature is over-heated. Below is the boundary which system gives alarm.

:60° C/140° F (default)

:65° C/149° F, 70° C/158° F, 75° C/167° F

CPU Warning Temperature

This function is CPU over-heat alarm. Select either of the below temperature will give an alarm when CPU temperature is over-heated.

:Disabled

:50° C/122° F, 53° C/127° F, 56° C/133° F, 60° C/140° F,

63° C/145° F, 66° C/151° F, 70° C/158° F

Current CPU Temperature, Current CPUFan1/CPUFan2/ CPU FAN3 , Current Vin3(V)/ Vin2(V)/VIN(1)/Vdd(V):

System will automatically detect the above items and show the status.

3-5. Power management setup

ROM PCI/ISA BIOS (2A69KL1A) POWER MANAGEMENT SETUP AWARD SOFTWARE, INC.		
ACPI function	: Enabled	** Reload Global Timer Events **
Power Management	: User Define	IRQ[3-7,9-15],NMI : Disabled
PM Control by APM	: Yes	Primary IDE 0 : Disabled
Video Off Method	: U/H SYNC+Blank	Primary IDE 1 : Disabled
Video Off After	: Standby	Secondary IDE 0 : Disabled
MODEM Use IRQ	: 3	Secondary IDE 1 : Disabled
Doze Mode	: Disable	Floppy Disk : Disabled
Standby Mode	: Disable	Serial Port : Enabled
Suspend Mode	: Disable	Parallel Port : Disabled
HDD Power Down	: Disable	
Throttle Duty Cycle	: 62.5%	
PCI/UGA Act-Monitor	: Disabled	
Soft-Off by PWR-BTM	: Instant-Off	
CPUFAN Off In Suspend	: Disabled	
PowerOn by Ring	: Disabled	
Resume by Alarm	: Disabled	
Wake Up On LAN	: Disabled	ESC : Quit ↑↓+ : Select Item
IRQ 8 Break Suspend	: Disabled	F1 : Help PU/PD/+/- : Modify
		F5 : Old Values (Shift)F2 : Color
		F7 : Load Setup Defaults

ACPI function

:Disabled (default)

:Enabled

Power Management

:User Define(default)--users can configure their own power management

:Min Saving

:Max Saving

:Disabled

PM Control By APM

No : system BIOS will ignore APM.

Yes : system BIOS will wait for APM's prompt before it enter any PM mode, e.g. doze, standby or suspend.



Note1: if APM is installed, and there is a task running, even if the timer is time out, the APM will not prompt the BIOS to put the system into any power saving mode!



Note2: If APM is not installed, this option has no effect.

MODEM Use IRQ

:3(default), **4, 5, 7, 9,10,11,NA**

Video Off After:

:Standby(default), **Doze, NA, Suspend**

Video Off Method

:DPMS (default), **Blank Screen, V/H Sync+Blank**

Doze mode

:disabled (default), **1 min --- 1 hour**

Standby mode

:disabled(default) , **1 min --- 1 hour**

Suspend mode

:disabled(default) , **1 min --- 1 hour**

Soft-off by PWRBTN

:Instant-off

:4 seconds

This allows the user to set the soft-off power button to turn off the system or set to "4 second" holding the power and system will shut down in 4 seconds.

Resume by ring

Enabled: modem ring on function--- system can be turned on through modem.



Note: this function only works when the system is turned off from Windows mode, and Doze mode will not function.

Resume by alarm: auto power on at the appointed date and time.

Enabled: key in the date of current month and time of the day. System will turn on then.


Disable: disble this function.



Note: this function only works when the system is turned off in windows mode, and doze mode will not function.



3-6. PNP / PCI configuration setup



PNP OS Installed

:No(default)

OS will not recognize PnP devices.

:Yes

OS will arrange the setup of PnP devices.

Resources Controlled By

:Manual(default)

The table will show the below items: **“Reset Configuration Data, IRQ-3 assigned to, DMA-0 assigned to.”** The user can adjust the shown items as required.

:Auto

The table will not show the above items, and the system will automatically assign the above setup.

Reset Configuration Data

:Disabled(default)

:Enabled--- to reset “**Extended System Configuration Data(ESCD)** when you exit setup if you have installed a new add-on card and the system reconfiguration has caused such a serious conflict that the operating system can not boot up.

IRQ-3 Assigned To---- IRQ-15 Assigned To

: PCI/ISA PnP(default)

: Legacy ISA

DMA-0 Assigned To--- DMA-7 Assigned To

: PCI/ISA PnP(default)

: Legacy ISA

PCI IRQ Activated By

There are 2 modes in activating PCI IRQ.

:Edge (default)

:Level

Assign IRQ for USB

:Enable (default)

:Disable

Assign IRQ for VGA

:Enable (default)

:Disable

3-7. Integrated peripherals

```

ROM PCI/ISA BIOS (2A69KL1A)
INTEGRATED PERIPHERALS
AWARD SOFTWARE, INC.

IDE HDD Block Mode      : Enabled
IDE Primary Master PIO  : Auto
IDE Primary Slave PIO   : Auto
IDE Secondary Master PIO : Auto
IDE Secondary Slave PIO : Auto
IDE Primary Master UDMA : Auto
IDE Primary Slave UDMA  : Auto
IDE Secondary Master UDMA : Auto
IDE Secondary Slave UDMA : Auto
On-Chip Primary PCI IDE : Enabled
On-Chip Secondary PCI IDE : Enabled
USB Keyboard Support    : Disabled
Init Display First     : AGP

POWER ON Function      :
KB Power ON Password   : Enter
Hot Key Power ON       : Ctrl-F1

KBC input clock        : 8 MHz
Onboard FDC Controller : Enabled
Onboard Serial Port 1  : Auto
Onboard Serial Port 2  :
UART Mode Select      :
UART2 Duplex Mode     : Half
RxD , TxD Active      :
IR Transmission delay  : Enabled
Onboard Parallel Port  :
Parallel Port Mode     :
ECP Mode Use DMA      : 3
EPP Mode Select        : EPP1.7

ESC : Quit          ↑↓←→ : Select Item
F1  : Help          PU/PD/+/− : Modify
F5  : Old Values   (Shift)F2 : Color
F7  : Load Setup Defaults

```

IDE HDD Block Mode

This feature enhances hard disk performance by making multi sector transfer instead of one sector per transfer. Most of IDE drivers, except very early designs ,can use this feature.

:Enabled (default)

:Disabled

Primary Master PIO/ Primary Slave PIO

This feature detects your primary master hard disk device.

:Auto (default)

:Mode 0,1,2,3,4

Secondary Master PIO/Secondary Slave PIO

This feature detects your secondary master hard disk device.

:Auto (default)

:Mode 0,1,2,3,4

On-Chip Primary PCI IDE : select use chip support primary PCI IDE.

-
- : **Enabled** (default)
 - : **Disabled**

On-chip secondary PCI IDE:select use chip support secondary PCI IDE.

- : **Enabled** (default)
- : **Disabled**

USB Keyboard support

- : **Enabled**
- : **Disabled** (default)

Onboard FDC Controller

- : **Enabled** (default)
- : **Disabled**

Onboard Serial Port 1/ On-Board Serial Port 2

- : **3F8/IRQ4** (default)
- : **2F8/IRQ3**
- : **3E8/IRQ4**
- : **2E8/IRQ3**
- : **Auto**
- : **Disabled**

Onboard Parallel Port

- : **378/IRQ7** (default)
- : **278H/IRQ5**
- : **Disabled**

3-8. Supervisor/User Password

The "Supervisor/User Password setting" utility sets the security protection. There are two kinds of password functions in the setup menu : one is "Supervisor Password," and the other is "User Password." Their difference is:

Supervisor Password: this function allows you the right to change the options of setup menu.


User Password: this function only allows you to enter the setup menu but not to change the options of the setup menu except "USER PASSWORD," "SAVE & EXIT SETUP," and "EXIT WITHOUT SAVING."

1. How to set "Supervisor Password" & "User Password"

The setup of "Supervisor Password" and "User Password" has the same steps.


Step 1: Enter Password

Press <Enter> after appointing the password.




Step 2: Confirm Password

Typing the password again and pressing <Enter> .



Step 3: Set “Security Option” in “BIOS Features Setup” (refer to page 40).

After setting password, enter “Security Option” in “BIOS Features Setup.” There are 2 options “Setup” & “System.” “Setup” will only secure CMOS setup through password. “System” is to secure PC system and password is required during system boot-up in addition to CMOS setup.



Note: If you forget password, please clear CMOS.
(refer to page11 for **RTC1**)

2. How to Disable “Supervisor Password” & “User Password”

Step 1: **Go to CMOS Setup Menu** (need to key in password first)

Step 2: **Enter “Supervisor Password” or “User Password”**

After enter, it shows “Enter Password.” Press the <Enter> key instead of entering a new password when "ENTER PASSWORD" appears. It will inform “PASSWORD DISABLED PRESS ANY KEY TO CONTINUE.” Thus, press any key as instructed. Password disable this way.



3-9. IDE HDD Auto Detection

**ROM PCI/ISA BIOS
CMOS SETUP UTILITY
AWARD SOFTWARE, INC.**

HARD DISK TYPE SIZE CYLS HEAD PRECOMP LANDZ SECTORMODE
Primary Master:
Primary Slave:
Secondary Master:
Secondary Slave:

Select Primary Master Option (N: Skip): N							
OPTIONS	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE
2 (Y)	4302	523	255	0	8893	63	LBA
1	4303	8894	15	65535	8893	63	NORMAL
3	429	6555	2405	65535	8893	63	LARGE

The "**IDE HDD AUTO DETECTION**" utility is a very useful tool especially when you do not know which kind of hard disk type you are using. You can use this utility to detect the correct disk type installed in the system automatically or you can set hard disk type to auto in the standard CMOS setup. You don't need the "**IDE HDD Aauto Detection**" utility. The BIOS will auto-detect the hard disk size and model on display during post.



HDD modes :

The Award® BIOS supports 3 HDD modes: **NORMAL, LBA & LARGE.**

Normal mode

Generic access mode in which neither the BIOS nor the IDE controller will make any transformations during accessing.

The maximum number of cylinders, head & sectors for normal mode are **1024, 16 & 63.**

	No. Cylinder	(1024)
X	No. Head	(16)
X	No. Sector	(63)
X	No. Per Sector	(512)
		528 MB

If user set this HDD to normal mode, the maximum accessible HDD size will be 528 MB even though its physical size may be greater than that!

LBA (Logical Block Addressing) Mode

A new HDD accessing method to overcome the 528 MB bottleneck. The number of cylinders, heads & sectors shown in setup may not be the number physically contained in the HDD. During HDD accessing, the ide controller will transform the logical address described by sector, head & cylinder into its own physical address inside the HDD.

The maximum HDD size supported by LBA mode is 8.4 GB which is obtained by the following formula:

	No. Cylinder	(1024)
X	No. Head	(255)
X	No. Sector	(63)
X	No. Bytes Per Sector	(512)
		8.4 GB

Large Mode

Extended HDD access mode supported by Award® software. Some IDE HDDs contain more than 1024 cylinder without LBA support (in some cases, user do not want LBA). The Award® BIOS provides another alternative to support these kinds of large mode:

<u>Cyls.</u>	<u>Head</u>	<u>Sector</u>	<u>Mode</u>
1120	16	59	NORMAL
560	32	59	LARGE

BIOS tricks DOS (or other OS) that the number of cylinders is less than 1024 by dividing it by 2. At the same time, the number of heads is multiplied by 2. A reverse transformation process will be made inside int 12h in order to access the right HDD address the right HDD address!

Maximum HDD Size:

	No. Cylinder	(1024)
X	No. Head	(32)
X	No. Sector	(63)
X	No. Bytes Per Sector	(512)
		1 GB



To support LBA or large mode of HDDs, there must be some softwares involved. All these softwares are located in the Award® HDD service routine (int 13h). It may be failed to access a HDD with LBA (large) mode selected if you are running under an operating system which replaces the whole int 13h. Unix operating systems do not support either LBA or large and must utility the standard mode. Unix can support drives larger than 528MB.



Chapter 4. Appendix

4-1 Memory map

Address range	Size	Description
00000-7FFFF	512K	Conventional memory
80000-9FBFF	127K	Extended conventional memory
9FC00-9FFFF	1K	Extended BIOS data area if PS/2 mouse is installed
A0000-C7FFF	160K	Available for hi DOS memory
C8000-DFFFF	96K	Available for hi DOS memory and adapter ROMs
E0000-EEFFF	60K	Available for UMB
EF000-EFFFF	4K	Video service routine for monochrome & CGA adapter
F0000-F7FFF	32K	BIOS CMOS setup utility
F8000-FCFFF	20K	BIOS runtime service routine (2)
FD000-FDFFF	4K	Plug and play escd data area
FE000-FFFFF	8K	BIOS runtime service routine (1)

4-2 I/O map

000-01F	DMA controller (master)
020-021	Interrupt controller (master)
022-023	Chipset control registers. I/o posts
040-05F	Timer control registers
060-06F	Keyboard interface controller (8042)
070-07F	RTC ports & CMOS I/O ports
080-09F	DMA register
0A0-0BF	Interrupt controller (slave)
0C0-0DF	DMA controller (slave)
0F0-0FF	Math coprocessor
1F0-1FB	Hard disk controller
278-27F	Parallel port 2
2B0-2DF	Graphics adapter controller
2F8-2FF	Serial port 2
360-36F	Network ports
378-37F	Parallel port 1
3B0-3BF	Monochrome & parallel port adapter
3C0-3CF	EGA adapter
3D0-3DF	CGA adapter
3F0-3F7	Floppy disk controller
3F8-3FF	Serial port-1

4-3 Time & DMA channels map

Time map:

Timer channel 0 system timer interrupt
Timer channel 1 DRAM refresh request
Timer channel 2 speaker tone generator

Dma channels:

DMA channel 0 available
DMA channel 1 onboard ecp (option)
DMA channel 2 floppy disk (smc chip)
DMA channel 3 onboard ECP (default)
DMA channel 4 cascade for dma controller 1
DMA channel 5 available
DMA channel 6 available
DMA channel 7 available

4-4 Interrupt map

NMI: non-maskable interrupt

IRQ/IV:

- 0 system timer interrupt from timer 0
- 1 keyboard output buffer full
- 2 cascade for IRQ 8-15
- 3 serial port2
- 4 serial port1
- 5 parallel port 2
- 6 floppy disk (smc chip)
- 7 parallel port 1
- 8 RTC clock
- 9 available
- 10 available
- 11 available
- 12 PS/2 mouse
- 13 math coprocessor
- 14 onboard hard disk (ide1) channel
- 15 onboard hard disk (ide2) channel

4-5 RTC & CMOS RAM map

RTC & CMOS :

00 seconds
01 second alarm
02 minutes
03 minutes alarm
04 hours
05 hours alarm
06 day of week
07 day of month
08 month
09 year
0a status register a
0b status register b
0c status register c
0d status register d
0e diagnostic status byte
0f shutdown byte
10 floppy disk drive type byte
12 hard disk type byte
13 reserve
14 equipment type
15 base memory low byte
16 base memory high byte
17 extension memory low byte
18 extension memory high byte
19-2d
2e-2f
30Reserved for extension memory low byte
31 reserved for extension memory high byte
32 date century byte
33 information flag
34-3f reserve
40-7f reserved for chipset setting data

4-6 Award BIOS hard disk type

Type	Cylinder	Heads	Write Pre-comp	Landing Zone	Sectors	Size
1	306	4	128	305	17	10MB
2	615	4	300	615	17	21MB
3	615	6	300	615	17	32MB
4	940	8	512	940	17	65MB
5	940	6	512	940	17	49MB
6	615	4	65535	615	17	21MB
7	462	8	256	511	17	32MB
8	733	5	65535	733	17	31MB
9	900	15	65535	901	17	117MB
10	820	3	65535	820	17	21MB
11	855	5	65535	855	17	37MB
12	855	7	65535	855	17	52MB
13	306	8	128	319	17	21MB
14	733	7	65535	733	17	44MB
16	612	4	0	663	17	21MB
17	977	5	300	977	17	42MB
18	977	7	65535	977	17	59MB
19	1024	7	512	1023	17	62MB
20	733	5	300	732	17	31MB
21	733	7	300	732	17	44MB
22	733	5	300	733	17	31MB
23	306	4	0	336	17	10MB
24	977	5	0	925	17	42MB
25	1024	9	65535	925	17	80MB
26	1224	7	65535	754	17	74MB
27	1224	11	65535	754	17	117MB
28	1224	15	65535	699	17	159MB
29	1024	8	65535	823	17	71MB
30	1024	11	65535	1023	17	98MB
31	918	11	65535	1023	17	87MB
32	925	9	65535	926	17	72MB
33	1024	10	65535	1023	17	89MB
34	1024	12	65535	1023	17	106MB
35	1024	13	65535	1023	17	115MB

Type	Cylinder	Heads	Write Pre-comp	Landing Zone	Sectors	Size
36	1024	14	65535	1023	17	124MB
37	1024	2	65535	1023	17	17MB
38	1024	16	65535	1023	17	142MB
39	918	15	65535	1023	17	119MB
40	820	6	65535	820	17	42MB
41	1024	5	65535	1023	17	44MB
42	1024	8	65535	1023	17	68MB
43	809	6	65535	852	17	42MB
44	809	9	65535	852	17	64MB
45	776	8	65535	775	17	104MB
46	AUTO	0	0	0	0	
47	USER'S	TYPE				

4-7 ISA I/O address map

I/O Address (HEX)	I/O device
000 - 01F	DMA Controller 1, 8237A-5
020 - 03F	Interrupt Controller 1, 8259A
040 - 05F	System Timer, 8254-2
060 - 06F	8742 Keyboard Controller
070 - 07F	real-time Clock/CMOS and NMI Mask
080 - 09F	DMA Page Register, 74LS612
0A0 - 0BF	Interrupt Controller 2, 8259A
0C0 - 0DF	DMA Controller 2, 8237A-5
0F0 - 0FF	i486 Math Coprocessor
1F0 - 1F8	Fixed Disk Drive Adapter
200 - 207	Game I/O
20C - 20D	Reserved
21F	Reserved
278 - 27F	Parallel Printer Port 2
2B0 - 2DF	Alternate Enhanced Graphic Adapter
2E1	GPIB Adapter 0
2E2 - 2E3	Data Acquisition Adapter 0
2F8 - 2FF	Serial Port 2 (RS-232-C)
300 - 31F	Prototype Card
360 - 363	PC Network (Low Address)
364 - 367	Reserved
368 - 36B	PC Network (High Address)
36C - 36F	Reserved
378 - 37F	Parallel Printer Port 1
380 - 38F	SDLC, Bisynchronous 2
390 - 393	Cluster
3A0 - 3AF	Bisynchronous 1
3B0 - 3BF	Monochrome Display and Printer Adapter
3C0 - 3CF	Enhanced Graphics Adapter
3D0 - 3DF	Color/Graphics Monitor Adapter
3F0 - 3F7	Diskette Drive Controller
3F8 - 3FF	Serial Port 1 (RS-232-C)
6E2 - 6E3	Data Acquisition Adapter 1
790 - 793	Cluster Adapter 1
AE2 - AE3	Data Acquisition Adapter 2

I/O Address (HEX)	I/O device
B90 - B93	Cluster Adapter 2
EE2 - EE3	Data Acquisition Adapter 3
1390 - 1393	Cluster Adapter 3
22E1	GPIB Adapter 1
2390 - 2393	Cluster Adapter 4
42E1	GPIB Adapter 2
62E1	GPIB Adapter 3
82E1	GPIB Adapter 4
A2E1	GPIB Adapter 5
C2E1	GPIB Adapter 6
E2E1	GPIB Adapter 7

Chapter 5. Q & A

5-1 Errors messages during power on self test (POST)

During **power on self test (post)**, BIOS will automatically detect the system devices. Below is the question that users may always meet. The user may press “**Esc**” key to skip the full memory test.

1. *Beep sound*

On power on, the system make beep sound to offer different messages. If the system is configured correctly, it prompts a short beep to show correct the devices configuration is done correctly. When VGA card and DIMM modules are not plugged well, the system makes longer and constant beep sounds.

2. *BIOS ROM checksum error*

It indicates the checksum of the BIOS code is not right and system will always halt on power on screen. Contact the dealer to exchange a new BIOS.

3. *CMOS battery fails*

It indicates the CMOS battery does not work. Contact the dealer to exchange a new BIOS.

4. *CMOS checksum error*

It indicates the CMOS checksum is incorrect. Load the default values in BIOS to solve this problem. This error may result from a weak BIOS, so exchange a new BIOS if necessary.

5. *Hard disk initialize*

Please wait a moment...

Some hard drives require more time to initialize.

6. *Hard disk install failure*

The system can not find or initialize the hard drive controller or the drive. Check if the controller is set correctly. If no hard disk is installed, “**Hard drive selection**” must be set to “**none.**”

7. *Keyboard error or no keyboard present*

This means the system can not initialize the keyboard. Check if the keyboard is plugged well and be sure no keys are pressed during POST.

8. *Keyboard is lock out- Unlock the key*

Normally when this message comes out, check if there is anything mis-placed on the keyboard. Be sure nothing touches the keys.

9. *Memory test fails*

There will be more information to specify the type and location of the memory error.

10 *Primary master hard disk fail*

The BIOS find an error in the primary master hard disk drive.

11 *Primary slave hard disk fail*

The BIOS finds an error in the primary slave hard disk drive.

12 *Secondary master hard disk fail*

The BIOS finds an error in the secondary slave master hard disk drive.

13 *Secondary slave hard disk fail*

The BIOS finds an error in the secondary slave IDE hard disk drive.

5-2 Frequently asked questions

Below is the question user always come out with. **Q** is for question. **A** is for answer.

Q: Why can't my AGP card work under Win 95?

A: Windows 95 OSR2.0 does not support AGP function. You must install "USB support" file to enable this function. After installing, choose "enable for **"ASSIGN IRQ FOR USB" in BIOS PNP/PCI configuration setup.**

Q: Why can't the CPU frequency be adjusted to 100 MHz ?

A: The BIOS will automatically detect the CPU frequency (66MHz or 100 MHz). Therefore, if your CPU frequency cannot be adjusted to 100 MHz, then your CPU may be 66 MHz. In BIOS "speed setup," there are other frequencies, like 75 MHz, 83 MHz, 103 MHz, 102 MHz, 112 MHz, 133MHz. These are for internal test only. No guarantee is provided since this is not included in chipset specification.

Q: Why is my system not stable with 100 MHz CPU?

A: There are many reasons for this condition. One of the most common is that SDRAM does not match PC-100 specification. When system is operated under 100 MHz, in addition to 100 MHz CPU, SDRAM must be PC-100 DIMM too.

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.
675 Mass Ave, Cambridge, MA 02139, USA

Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change

free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too. When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive Source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the Rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify It. For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal Permission to copy distributes and/or modifies the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributes of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all. The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language.

(Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a. You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b. You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c. If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a. Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b. Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c. Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.) The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable. If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice. This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8..If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9.The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10.If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11.BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

Zmak Linux Disclaimer

To make this program a greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms. To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

Zmak Linux Version 6.0/Auto installation

January 10 2000

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details. You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 675 Mass Ave, Cambridge, MA 02139, USA. Also add information on how to contact you by electronic and paper mail. If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Zmak Linux version 6.0, 2000

Zmak Linux version 6.0 comes with ABSOLUTELY NO WARRANTY; the terms and conditions of this AmazePC Linux version 6.0 is same as the GNU General Public License vision 2.0, for details please see the GNU contract terms. This is free software, and you are welcome to redistribute it under certain conditions; please see GNU General Public License vision 2.0 for details.

Amazepc, Inc., hereby disclaims all copyright interest in the program
Zmak linux version 6.0 (which makes passes at compilers) written by John Lee

Signature _____, January 10, 2000

This General Public License does not permit incorporating your program into proprietary programs. If your program is subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

For instant technical support and latest information, please visit www.amazepc.com and talk to us at www.amazepc.com/chat or ICQ56257071

