

MP068 USER'S MANUAL
INTEL TRITON FX MOTHERBOARD

Jumpers and Connectors Reference
=====

Before installing the mainboard, make sure that the jumper settings are properly set for your configuration . The fUnction of different jumpere are respectively as follows :

CPU Clock Frequency Selector JP17, JP18
 CPU Internal Clock Multiplier JP31, JP32
 CPU Voltage Selector JP36
 Cache Configuration JP20, JP39
 Flash ROM Voltage Selector JP14
 CMOSCharge/Discharge JP13
 AT Bus Clock Speed Selector JP15

Mainboard Connectors:

Onboard HDD LED Connector J3
 Reset Switch Connector..... J2
 Speaker Connector J1
 Keylock and Power LED Connector..... J4
 PS/2 mouse Connector MS2
 Keyboard Connector KBI
 Power Supply Connector PWI
 Turbo Switch Connector J7
 Turbo LED Connector J6
 SMI Switch Connector JP16

Jumper Caps reference :

Red Jumper for Voltage Selector
 White Jumper for Cpu Type
 Yellow Jumper for Clock Selector
 Blue Jumper for Cache Option
 Black Jumper for Other

CPU JUMPER SETTING
=====

When you look for jumper setting for configuration. Please refer to Mainboard Layout mainboard placement chart.

CPU SPEED	CPU Clock Selector	CPU Internal Clock Selector		CPU Speed	Voltage	JP31	JP32	Multiplier
		Yellow Jumper Cap	White Jumper Cap					
		JP17	JP18					
PP-75	Mhz	CL	CL	50Mhz	OP	OP		x1.5
PP-100	Mhz	CL	CL	50Mhz	OP	CL		x2
PP-90	Mhz	OP	CL	60Mhz	OP	OP		x1.5
PP-120	Mhz	OP	CL	60Mhz	OP	CL		x2
PP-150	Mhz	OP	CL	60Mhz	CL	CL		x2.5
PP-100	Mhz	CL	OP	66Mhz	OP	OP		x1.5
PP-133	Mhz	CL	OP	66Mhz	OP	CL		x2
PP-166	Mhz	CL	OP	66Mhz	CL	CL		x2.5
P54CT-180		OP	CL	60Mhz	CL	OP		x3
P54CST-200		CL	OP	66Mhz	CL	OP		x3

NOTE: Using PP75/90/100/120/133 JP31 must be set to OPEN.

CYRIX 6X86 CPU

CPU Model	Voltage	JP17		JP18		JP31	JP32	Multiplier
		CL	OP	CL	OP			
6X86-P120 (100Mhz)		CL		CL		OP	OP	x2
6X86-P150 (120 Mhz)		OP		CL		OP	OP	x2
6X86-P166 (133 Mhz)		CL		OP		OP	OP	x2

CPU VOLTAGE SELECTOR (Red Jumper Cap)

=====

JP36 1-2 3.38 Volts for Intel P54C Standard CPU Type (for most CPU)
 2-3 3.53 Volts for Intel P54C VRE CPU Type

Cache Configuration

=====

Cache Configuration is used to configure the external cache of the mainboard. External cache can be configured by using 32K * 32 and 64K*32 SRAM / Synchronous cache or Cache module.

A. Onboard Synchronous Cache

256K cache size	JP20	JP39	SRAM(U31,U32)	TAG RAM(U19)
	3-4	1-2	32K* 32	8K*8
512K cache size	JP20	JP39	SRAM(U31,U32)	TAG RAM (U19)
	1-2	1-2	64K*32	16K*8

B. Synchronous Cache on board upgrade to 512K using Win CD012

Synchronous Cache Module
 Onboard 256K Cache plus Win CD012 256K Cache Module = 512K Cache

	JP20	JP39	SRAM(U31,U32)	TAG RAM (U19)
	2-3	2-3	32K*32	8K*8

NOTE: Upgrade function can only be achieved with WIN CD012 Cache Module. Please call Edom International Corporation at (510) 659-8882 for CD012 cache module.

AT Bus Clock Speed Selector (Yellow jumper cap)

JP15 1-2 PCI Clock 1/3
 2-3 PCI Clock 1/4

Flash ROM Voltage Selector (Red jumper cap)

JP14 1-2 Flash ROM 12 Volts (Intel Brand)
 2-3 Flash ROM 5 Volts (SST / WINBOND Brand)

NOTE: Brand name is under ROM BIOS.

Memory Configuration

=====

Bank 0 SIMM 1 & 2	Bank 1 SIMM 3 &4	Total Memory
4MB x2	None	8MB
None	4MB x2	8MB
8MB x2	None	16MB
None	8MB x 2	16MB
4MB x2	4MB x2	16MB
8MB x 2	4MB x 2	24MB
4MB x2	8MB x2	24MB
8MB x 2	8MB x 2	32MB
None	16MB x 2	32MB
16MB x 2	None	32MB
4MB x 2	16MB x 2	40MB
16MB x 2	4MB x 2	40MB
8MB x 2	16MB x 2	48MB
16MBx2	8MBx2	48MB

32MB x 2	None	64MB
None	32MBx2	64MB
16MB x 2	16MB x 2	64MB
32MBx2	4MBx2	72MB
4MB x 2	32MB x 2	72MB
8MB x 2	32MB x 2	80MB
32MB x 2	8MB x 2	80MB
16MB x 2	32MB x 2	96MB
32MB x 2	16MB x 2	96MB
32MB x 2	32MB x 2	128MB

IMPORTANT : Do not use SIMM modules with more than 24 chips per 72 pin and 9 chips per 30 pin module with this mainboard. Module with more than 24 or 9 chips exceeds the design specification of the memory subsystem.

CMOS Charge / Discharge

=====

CMOS Charge / Discharge is used to discharge and charge CMOS. If you discharge the CMOS all the data will be erased. To discharge CMOS just close JP13 without turning on the power supply.

JP13	OPEN	Charge CMOS
	CLOSE	Reset CMOS

Mainboard Connectors

=====

- J1 Speaker connector will be connected to the speaker of your computer case.
- J2 Reset Switch connector will be connected in your computer case front panel. Resetting the system, it will restart the computer from self-test without turning off the power supply. This connection is always at "off" position.
- J3 Onboard HDD LED connector will be connected in your computer case front panel.
- J4 Keylock and Power LED connector will be connected in your computer case front panel. Keylock is used to lock the keyboard. Power LED will light up when you turn on your power supply.
- J7 Turbo Switch Connector will be connected in your computer Case front panel.
- J6 Turbo LED Connector will be connected in your computer Case front panel.
- MS2 PS/2 Mouse connector. this is used for PS/2 mouse. (In mainframe case)
- KB2 Keyboard connector, this is used for inputting signal from the keyboard.
- PW1 Power Supply connector is connected from the output of the power supply. Most of the power supply has two connectors which will be connected to the mainboard. Each connector has six wires, two of the wires are black. To connect to the mainboard, make sure that the black wire is in the middle. Wrong connection will cause damage to the mainboard.

AWARD BIOS SETUP

Award BIOS support plug and play function and has a built-in setup program that allows the users to modify the basic system configuration. This type of

information is stored in CMOS so that it retains the setup information when the power is turned off.

1. Turn on or reboot the system. when the below message appears at the bottom of the screen during the POST (Power On Self Test) press DEL key to enter setup.
 2. Press the DEL key to enter the Award BIOS program and the main menu will appear on the screen. The main menu allows you to select from ten setup functions and two exit choices.
 3. For the safe, please select "LOAD SETUP DEFAULTS" for BIOS setup.
-