

AS-3210

Setup Manual

February 12, 1999
Version 2.12

Yamashita Systems Co., Ltd.
Osaka M.I.S. Co., Ltd.

Item Contents Page

Part 2: How to Use 24 Chapter 1: Setup 24 1.1 Step 1: Setting up the board 25

1.1.1 Installing the CPU 25

1.1.2 Jumper settings 25

1.1.3 Adding Memory (SIMM) 26

1.2 Step 2 Connecting Peripheral Devices 27 1.2.1 Notes on PS2 Mouse 27

1.2.2 Setting Parallel Port Mode 28 1.3 Step 3 Powering On 28 1.4 Step 4

BIOS Setup 29 1.4.1 Starting BIOS Setup 29

1.4.2 <STANDARD CMOS SETUP> 30

1.4.3 <BIOS FEATURES SETUP> 31

1.4.4 <CHIPSET FEATURES SETUP> 31

1.4.5 <POWER MANAGEMENT SETUP> 32

Chapter 2 About the VGA driver 33 Chapter 3 About the flash disk tool 34

Chapter 4 Notes on using interrupts on the I/O board 35 Appendix A Board component layout diagram 36

~ Part 1: Hardware ~

Part 1 explains the hardware of the AS-3210, including the board's hardware configuration and various built-in functions (video, multi-I/O, watchdog timer, flash disk).

This is about.

Chapter 1 Hardware Configuration

1.1 Overview

MIS AS-3210 uses the IBM PC/AT architecture.

It is an AT-compatible single-board computer. It is an all-in-one CPU card with a half-size ISA bus, equipped with various functions such as a CPU, multi-I/O, SVGA, Flash-Disk, and watchdog timer, and comes pre-installed with 4MB of system memory.

The CPU can be selected from 486 series CPUs installed in a PGA socket.

Multi-I/O function for keyboard, PS2 mouse, serial, parallel,

It is equipped with interfaces such as IDE (HDD) and FDD.

In addition, SVGA (CRT/LCD compatible) with VESA VL-BUS connection

This board is equipped with a 2MB or 4MB flash disk that emulates a hard disk, making it extremely useful for embedded applications.

This allows for the construction of a compact system.

1.2 Specifications

- Processor (33MHz standard) 486SX, DX, DX2, DX4
- System memory

Implementation: 4MByte, Expansion: 72-pin SIMM x 1 (Max 32MByte)

- System BIOS Award BIOS •Supports power management function
- Serial port 2 channels

RS232C (with 16 Byte FIFO) Parallel port 1 channel

Centronics compliant (SPP/EPP/ECP compatible) •Hard disk I/F (Local Bus IDE) •Floppy disk I/F

- Keyboard & PS2 mouse I/F
- Video I/F (VESA VL-BUS connection)

CRT 1024x768 16 colors

LCD 640 x 480 256 colors

Equipped with Flash-Disk function 2M/

4MB implementation Hard

disk emulation (used in C:/D:) Floppy disk emulation (used in A:/ B:) ROM-DISK (write-protected floppy disk emulation) Select one of the above

- Equipped with a watchdog timer function

Timeout 1.6 seconds, used with IRQ15 or RESET


- Card dimensions: length 185.00mm, width 122.00mm

Operating power supply voltage: +5V±5% (+12V may be required when using an LCD)

- Operating temperature range: 0 to


60°C. No condensation. Separate heat dissipation measures for the CPU.

1.3 Block Diagram



1.4 Memory Map

The memory map for the AS-3210 is as follows:



Total Memory=4MB(On Board)+SIMM(MAX 32MB)=MAX 36MB

1.5 I/O Map

The I/O map for the AS-3210 is as follows:


Address	Device
000 - 00F	DMA controller 1
020 - 03F	Interrupt Controller 1
040 - 05F	Timer 043(read)
	Watchdog timer En/Di
060 - 06F	Keyboard Controller
070 - 07F	RTC/RAM, NMI mask
080 - 09F	DMA page register
0A0 - 0BF	Interrupt Controller 2
0C0 - 0DF	DMA Controller 2
0F0 - 0FF	Coprocessor
1F0 - 1F7	HDD/Controller
1F8 - 1FF	Flash-Disk
278 - 27F	Parallel Port 2
2F8 - 2FF	Serial port 2
378 - 37F	Parallel Port 1
3F0 - 3F7	FDD Controller
3F8 - 3FF	Serial port 1 443(read) Watchdog timer REFRESH

About I/O space The I/O space of the ISA bus is 64K bytes. The CPU board selects I/O by 10-bit decoding.

Because it generates signals, it is an I/O space There are phantoms every 1024 bytes in 63 will appear.

For example, 100 of the 24-byte space The 240 bytes of addresses 1EF are unused space, so by decoding in 16 bits, 240 x 63 bytes of I/O space can be used, although it is broken up into small pieces.


It is also possible to do this.



1.6 Interrupt

"AS-3210" is an 82C59A compatible interrupt controller

The block diagram and usage are as follows:




	Vector	usage		Vector	usage
IRQ0	08H	Timer	IRQ8	70H	RTC
IRQ1	09H	Keyboard	IRQ9	71H	Software Unused
IRQ2	0AH	Cascade	IRQ10	72H	Unused
IRQ3	0BH	COM2	IRQ11	73H	(PS2
IRQ4	0CH	COM1	IRQ12	74H	Mouse) Coprocessor
IRQ5	0DH	Unused	IRQ13	75H	Hard Disk Unused
IRQ6	0EH	floppy parallel	IRQ14	76H	(WDT)
IRQ7	0FH		IRQ15	77H	

*1 IRQ15 can also be used with WDT

1.7 DMA

The AS-3210 is equipped with two 82C37A compatible DMA controllers (cascade connected). The block diagram and usage are as follows:



Controller Channel Usage		
MASTER	0	Unused
	1	Unused (Parallel) Floppy
	2	Unused
	3	(Parallel) Cascade
SLAVE	4	Unused
	5	Unused
	6	Unused
	7	Unused

*Channels 1 and 3 can also be used as parallel ports.

Chapter 2 Video Functions

The AS-3210 is equipped with an SVGA controller that also supports LCD display functions as a video function, allowing you to connect a CRT monitor and an LCD panel.


~ Specifications ~

- SVGA controller: F65535 manufactured by CHIPS&TECNOLOGY
- Video BIOS: Made by CHIPS&TECNOLOGY
- Video RAM: 512KB DRAM •Resolution CRT monitor:
1024 x 768 16 colors
: 640 x 480 256 colors
LCD panel: 640 x 480 256 colors
- I/F connector: 15-pin Dsub (CRT) : 50-pin header socket (LCD)
- The controller is connected via VESA VL-BUS.

2.1 Connecting a CRT monitor

When using a CRT monitor, connect the cable to connector J11 (15-pin Dsub).
Connect the cable from the CRT.

J11: Connector arrangement and pin assignment




Pin 1	Signal name	Pin 9	Signal
	RED		name
2	GREEN BLUE	10	NC
3	NC GND	11	GND
4	GND	12	NC
5	GND	13	NC HSYNC
6	GND	14	VSYNC NC
7		15	
8			

2.2 Connecting the LCD panel

When using an LCD panel, connect the signal cable from the LCD panel to connector J4 (50-pin header socket).

J4: Connector arrangement and pin assignment



Jumper post: P10 is the control signal for each LCD panel.

This is for selecting the desired setting.

Do not change the setting.

Jumper post: P10 setting (factory setting)

1-12 2-11 3-10 4-9 5-8 6-7

SHORT OPEN SHORT OPEN SHORT OPEN

2.3 LCD panel connection circuit

Connector: J4 has all the signals corresponding to various LCD panels assigned to it, but to actually use an LCD panel, the following is required: *


A dedicated cable to connect J4 to the LCD panel connector * An external power supply to drive the LCD and its control circuit.

Particular attention should be paid to the power-on sequence (logic) for the LCD panel. This procedure is performed by the LCD panel.


Therefore, prepare a power control circuit according to the LCD panel you are using. Our PANEL-LCD series (sold separately) requires this power supply.

It is recommended to use this product as it is equipped with a control circuit and cable conversion function.

Power-on sequence



Power-on circuit (image)



2.4 About the PANEL-LCD series


As explained in Sections 2 and 3, using an LCD panel is a very time-consuming task. Our PANEL-LCD series (sold separately) is a dedicated relay board that comes with the power control circuit, cable conversion mechanism, and VidoBIOS that are required to use an LCD panel. There are two types of PANEL-LCD, LCD3 and LCD4, which can be connected.

The LCD panels that can be used are as follows. If you use an LCD panel other than these, If you have any questions, please be sure to consult us.

- PANEL-LCD3 (color TFT compatible)

NEC: NL6448AC30-10 PANEL-LCD4 (monochrome STN compatible) Sharp: LM64P839 Optrex: DMF-50260-NFU-FW-5

LCD panel connection diagram (image)



Chapter 3 Multi-I/O Function

The AS-3210 is equipped with the following I/F as a multi-I/O function. Use it according to your system configuration.

- Keyboard & PS2 mouse I/F
- Floppy disk drive I/F
- Hard disk I/F

- Parallel port I/F
- Serial port I/F
- Attached auxiliary terminal


3.1 Keyboard and PS2 mouse

Connect the keyboard to connector J8 (6-pin mini-DIN) and the PS2 mouse to connector J9 (6-pin mini-DIN). Connector J7 (5-pin socket) is an auxiliary keyboard connector for expansion.

For details on using a PS2 mouse, please refer to page 24.


See the service notes.

J8, 9: Connector arrangement and pin assignment



pin	Signal name
1	Data (DATA)
2	NC
3	GND
4	+5V
5	Clock (CLK)
6	NC

J7: Connector arrangement and pin assignment




pin	Signal name
1	Clock (CLK)
2	Data (DATA)
3	NC
4	GND
5	+5V

3.2 Floppy Disk Drive I/F Up to two floppy disk drives can be used (connector: J1). Note that a special I/F cable, as shown in the diagram below, is required for the floppy disk drives.

Interface cable specifications: **10-pin to**

16-pin cable is twisted




AS-3210: J1

Drive B Drive A * Cable sold

separately by our company 9300064

J1: Connector arrangement and pin assignment




Pin	Signal Name	Pin	Signal Name
	GND	2	PWC*/RPM*
1	GND	4	NC
3	GND	6	NC
5	GND	8	INDEX*
7	GND	10	MTR1*
9	GND	12	DRVSEL2*
11	GND	14	DRVSEL1*
13	GND	16	MTR2*
15	GND	18	DIRSEL
17	GND	20	STEP
19	GND	22	WD
21	GND	24	WG
23	GND	26	TRK00*
25	GND	28	WP
27	GND	30	WD
29	GND	32	HDSEL*
31 33	GND	34	DSKCHG*

3.3 Hard Disk Drive I/F Up to two hard disk

drives can be cascaded (connector: J2). Since this IDE is a local bus connection, it is also possible to use hard disks that support E-IDE.


Interface Cable Specifications



Note: Drives can be set as master or slave using jumper settings.

*Our separately sold cable 9300066

J2: Connector arrangement and pin assignment




Pin	Signal Name	Pin	Signal Name
	RESET*	2	GND
1	DATA 7	4	DATA 8
3	DATA 6	6	DATA 9
5	DATA 5	8	DATA 10
7	DATA 4	10	DATA 11
9	DATA 3	12	DATA 12
11	DATA 2	14	DATA 13
13	DATA 1	16	DATA 14
15	DATA 0	18	DATA 15
17	GND	20	KEY
19		22	GND
21	(Reserved)	24	GND
23	IOW* IOR*	26	GND
25		28	BALE
27		30	GND
29		32	IOCS16*
31		34	PDIAG*
33		36	A2
35	(Reserved)	38	ACCS0*
37	IDEACT*	40	GND

3.4 Serial Port I/F The AS-3210 is equipped with two RS232C serial ports with 16-byte FIFO. The serial port connectors are COM1 (9-pin Dsub (J10)) and COM2 (10-pin header socket).


It is now (J5).

J10 (COM 1): Connector arrangement and pin assignment



pin	Signal Name	Pin	Signal Name
1	DCD	6	DSR
2	RD	7	RTS
3	TD	8	CTS
4	DTR	9	RI
5	GND		

J5 (COM 2): Connector Layout & Pin Assignment



pin	Signal Name	Pin	Signal Name
1	DCD	6	DSR
2	RD	7	RTS
3	TD	8	CTS
4	DTR	9	RI
5	GND	10	NC

Serial port I/O address


	address	Interrupt Level
COM1	03F8~03FF:H	IRQ4
COM2	02F8~02FF:H	IRQ3

3.5 Parallel Port I/F The AS-3210 is


equipped with one parallel (printer) port channel that supports three modes: SPP, EPP, and ECP. The connector is a 26-pin header socket (J3), so if you want to use it with a 25-pin Dsub connector, please use the included conversion cable. For information on how to change the mode, see p. 25 Parallel Port Mode

See the Node Settings.

J3: Connector arrangement and pin assignment



25-pin Dsub connector pin layout



Note: Pin assignment is the same as J3


Parallel port I/O address

data	Status Control Interrupts
0378h 0379h 037Ah	IRQ7


3.6 Attached auxiliary terminals

The AS-3210 has four auxiliary terminals on board for additional functions: HD access LED (JP1), speaker output (JP2), keyboard lock & power LED (JP3), and reset switch (JP4). The following diagram shows examples of how to use each auxiliary terminal.


JP1: HD access LED




JP2: Speaker output



JP3: Keyboard Lock & Power LED



JP4: Reset SW



Chapter 4 Watchdog Timer

The watchdog timer function specifications are as follows:

- Time-out 1.6 Sec
- Use IRQ15 or reset (set by P8)

Jumper post: P8 setting

1-4	2-3	Usage status
OPEN	SHORT	Reset
SHORT	OPEN	IRQ15
OPEN	OPEN	Unused

The usage of the watchdog timer (hereinafter referred to as WDT) is as follows:

ÿ Read address 443H...WDT refresh

ÿ Read address 043H...WDT operation starts

ÿ Read address 443H...WDT refresh

(While the WDT is operating, step ÿ is executed every 1.6 seconds.)

ÿ Read address 043H...WDT operation complete

Program reference example

```

WDT_SW dw 043H           ;Enable or Disable Address WDT
WDT_REF dw 443H         ;Refresh Address WDT

MAIN:
    CALL    WDTREF       ;Dummy Refresh
    CALL    WDTGATE      ;Enable WDT
    ;
    ;
    <User program within 1.6 seconds>
    ;
    CALL    WDTREF       ;Refresh
    ;
    <Repeat *1 below>
    ;
    CALL    WDTGATE      ;Disable WDT

END:
WDTGATE:MOV    DX,WDT_SW ;Enable or Disable WDT PROG.
           IN     AX,DX
           RET
WDTREF:MOV    DX,WDT_REF ;Refresh WDT PROG.
           IN     AX,DX
           RET
  
```

Chapter 5 About Flash Disks

The AS-3210 is equipped with a Flash-Disk function that emulates a hard disk/floppy disk drive. This disk emulates a hard disk drive or floppy disk using emulation software (extended BIOS), and can be used as drive C:/D: (hard disk emulation) or drive A:/drive B: (floppy disk emulation).

When using drive C: or drive A:, the drive will be written to the drive in the same way as a normal disk. S boot is also possible.

The specifications of the Flash Disk are as follows:

•Memory capacity: 2MB/4MB •Memory used:

SUMSUNG KM29N16000TS (2MB)

SUMSUNG KM29N32000TS (4MB)

•Disk capacity...

When hard disk emulation is selected

1.92MB (2M), 3.84MB (4M)

When floppy disk emulation is selected

1.44MB (2M), 2.88MB (4M) When ROM disk

function is selected •BIOS ...

1.44MB

Yamashita Systems original

•Memory area used: C8000-CFFFF 32KB

•Used I/O area... 1F8 to 1FF: h (fixed)

•Interrupt vector used: 61h, 62h

How to use: Hard disk emulation

Use on drive C: or D:

Floppy Disk Emulation

Or when using ROM-DISK function, use

drive A: or B: •Write lifespan

••••• 10**8 times/block (512 bytes) write

•Retention life: 10 years

5.1 How to use Flash Disk

The Flash-Disk is designed to be used in the same way as a hard disk or floppy disk. When hard disk emulation is selected, the Flash-Disk is automatically assigned to the free area of the physical drive C: or D:. For example, if both drives C: and D: are free (None) in the BIOS settings, the Flash-Disk will be assigned to drive C:, and both will be used as hard disks.

If a floppy disk is connected, it will be unused.

If you select the simulation (floppy disk, ROM-DISK function), it will be automatically allocated to a free area on the physical drive A: or B:.

It can be attached.

Detailed instructions are provided on the floppy disk that comes with the product.

Please be sure to read the instructions before use.

(Reference) ¥F_DISK¥README.TXT

Jumper Settings

The Flash disk is enabled/disabled by hardware (jumper: P

9) can be performed. Jumper P7 is used to select the power supply voltage supplied to the Flash Memory, so please use it as shipped (1-2 shorted). Jumper post

P9 setting Open: Enable Short:

Disable


~ Part 2: How to use ~

Part 2 describes the various settings and usage methods required when using the AS-3210.

Chapter 1: Setup

This chapter explains the necessary steps to use the AS-3210 (to start up DOS). It describes various work procedures.

~ Work procedure flow ~



1.1 Step 1: Setting up the board

Step 1 explains the board settings required before using the AS-3210. The required tasks can be broadly divided into the following three items.

- Installation of CPU
- Setting of each jumper
- Memory (SIMM) expansion

1.1.1 Installing the CPU

The AS-3210 can be equipped with four types of CPU (486SX to DX4). The CPU is a PGA socket (U3), so please check the position and direction. Be careful not to make a mistake and make sure to insert it firmly. For the location and orientation of the CPU socket, refer to Appendix A, Board Layout Diagram.

1.1.2 Jumper settings

Among the jumper setting items of AS-3210, P1 to P6 are the jumper setting items related to the CPU.

and set the jumpers as follows:

Jumper: P1, P2, P3 setting (open unless otherwise specified) Note:

This setting differs depending on the CPU manufacturer. •Intel series & AMD Enhanced-DX4

P1: 1-2, 3-4, 5-6, 7-8, 9-10 SHORT


•Cyril series

P2: 1-2, 3-4, 5-6, 7-8, 9-10 SHORT

•AMD, UMC series

P3: 1-2, 3-4, 5-6, 7-8, 9-10 SHORT

Jumper: P1, P2, P3 arrangement



Jumper: P4, P5, P6 settings

Note: This setting varies depending on the CPU type.

	P4	P5	P6
486SX 2-3 OPEN 1-2			
486DX 1-2		2-3	1-2
486DX2 1-2		2-3	1-2
486DX4 1-2		2-3	2-3

1.1.3 Adding memory (SIMM)

The AS-3210 comes pre-installed with 4MB of system memory.

However, there is also one 72-pin SIMM socket available for expansion.

If you need to add more memory, you can install a SIMM up to 32MB.

The specifications of the SIMM that can be installed are as follows:

- SIMM type: 72-pin SIMM
- Bit count: 36 bits or 32 bits
(However, the AS-3210 does not support memory parity.)
- Access time: 70ns or less

1.2 Step 2 Connecting Peripheral Devices

The following devices can be connected to the AS-3210 according to the system configuration.

- CRT/LCD

- Keyboard & PS2 mouse
- Floppy disk
- Hard disk

- Serial port

Parallel port

- Attached auxiliary terminal

Note: For details about each peripheral device, please refer to Chapters 2 and 3 of Part 1.

1.2.1 Notes on PS2 mouse AS-3210

supports PS2 mouse.

When using, please note the following:

Use the mouse driver that comes with the mouse if possible.

* When using the driver that comes with the OS, other drivers

Do not install

Particular attention should be paid to drivers that come with the OS, for example:

If the DOS MOUSE driver is installed, Windows

If you are using Windows 3.1, you may not be able to use the mouse. In this case, do not install the DOS MOUSE driver.

1.2.2 Parallel port mode setting

The parallel port of the AS-3210 supports three modes: SPP, EPP, and ECP.
Each mode is set using jumpers P12 and P13.

Jumper: P12, P13 settings (for short pins) SPP (standard) mode

P12:1-2,12-11

- EPP mode

P12:2-3,12-11

- ECP mode (when using DMA channel 1)

P12: 1-2, 11-10, 4-5, 9-8


P13: SHORT

- ECP mode (when using DMA channel 3)

P12: 1-2, 11-10, 5-6, 8-7

P13: SHORT

Jumper: P12 layout




1.3 Step 3 Power On The AS-3210

is powered on via the edge terminal on the board or the power connector: J6.
Then, you can turn on the power.

Use only when using the S-3210 alone.

J6: Connector arrangement and pin assignment



pin	Signal name
1	+5V DC +5V DC
2	GND
3	GND
4	GND
5 6	+12V DC

1.4 Step 4: BIOS Setup

When using the AS-3210 for the first time or when the connected peripheral devices are changed, please set up the BIOS and update the BIOS setting information. The following

sections explain how to set up the BIOS, showing actual screens. The setting values described in this document are the same as those at the time of shipping the board.

This is the initial state, so basically use this value.

1.4.1 Starting the BIOS setup

When you turn on the system, the first thing it does is check the memory.

During this time, the message "Hit DEL" will be displayed at the bottom of the screen, so press the DEL key. The BIOS setup screen will appear as shown below.

STANDARD CMOS SETUP	PASSWORD SETTING
BIOS FEATURES SETUP	IDE HDD AUTO DETECTION
CHIPSET FEATURES SETUP	SAVE & EXIT SETUP
POWER MANAGEMENT SETUP	EXIT WITHOUT SAVING
LOAD BIOS DEFAULTS	
LOAD SETUP DEFAULTS	
ESC : QUIT	ÿÿÿÿ : Select Item
F10: Save & Exit Setup	(Shift)F2 : Change Color

When this screen appears, select each item and set it.

Among these, <STANDARD CMOS SETUP>, <BIOS FEATURES SETUP>, <CHIPSET FEATURES SETUP> and <POWER MANAGEMENT SETUP> are the items for actually changing the settings.

1.4.2 <STANDARD CMOS SETUP>

This item configures the basic configuration of the system.

Date (mm:dd:yy) : MON,DEC,25,1995												
Time (hh:mm:ss) : 22: 5:40												
<u>HARD DISKS TYPE SIZE CYLS HEAD PRECOMP LANDZ SECTOR MODE</u>												
Drive C: None	0	0	0	0	0	0	0 ----					
Drive D: None	0	0	0	0	0	0	0 ----					
Drive A: None	<table border="1"> <tr> <td>Base Memory: 640K</td> </tr> <tr> <td>Extended Memory: 7168K</td> </tr> <tr> <td>Other Memory: 384K</td> </tr> <tr> <td>-----</td> </tr> <tr> <td>Total Memory: 8192K</td> </tr> </table>							Base Memory: 640K	Extended Memory: 7168K	Other Memory: 384K	-----	Total Memory: 8192K
Base Memory: 640K												
Extended Memory: 7168K												
Other Memory: 384K												

Total Memory: 8192K												
Drive A: None												
Video: EGA/VGA												
Halt On: All Errors												
Esc : Quit	ÿÿÿÿ : Select Item	Pu/Pd/+/- : Modify										
F1 : Help	(Shift)F2: Change Color											

Hard disk settings

Type: 1 to 46 have fixed parameters, but the hardware you use

If the parameters of the hard disk do not match, change to Type: 47 User.

Set it and enter the required parameters.

In addition, <IDE HDD AUTO DETECTION> automatically reads the HDD parameters.

This is also a useful function.

1.4.3 <BIOS FEATURES SETUP>

Please use the contents of this item as shipped (settings in the diagram).

Virus Warning	:Disabled	Video BIOS Shadow	:Enabled
CPU Internal Cache	:Enabled	C8000-CBFFF Shadow	:Enabled
		CC000-CFFFF Shadow	:Disabled
Quick Power On Self TEST	:Enabled	D0000-D3FFF Shadow	:Disabled
Boot Sequence	:A,C	D4000-D7FFF Shadow	:Disabled
Swap Floppy Drive	:Disabled	D8000-DBFFF Shadow	:Disabled
Boot Up Floppy Seek	:Enabled	DC000-DFFFF Shadow	:Disabled
Boot Up Numlock Status:	ON	E0000-E3FFF Shadow	:Disabled
Boot Up System Speed	:High	E4000-E7FFF Shadow	:Disabled
		E8000-EBFFF Shadow	:Disabled
Gate A20 Option	:Fast	EC000-EFFFF Shadow	:Disabled
Typematic Rate Setting	:Disabled		
Typematic Rate(Chars/Sec):	6		
Typematic Delay(Msec):	250		
Security Option	:Setup		
		Esc: Quit yyy : Select Item	
		F1 : Help Pu/Pd/+- : Modify	
		F5: Old Valuse (Shift)F2: Color	
		F6: Load BIOS Defaults	
		F7 : Load Setup Defaults	

1.4.4 <CHIPSET FEATURES SETUP>

Please use the contents of this item as shipped (settings in the diagram).

Auto Configuration	:Disabled	Onboard local bus IDE	:Enabled
Decoupled Refresh	:Disabled	IDE Primary Master PIO:Auto	
Relocate 256K/384K	:Disabled	IDE Primary Slave PIO	:Auto
Video BIOS Cacheable	:Enabled		
System BIOS Cacheable	:Enabled		
CHRDY for ISA Master	:Enabled		
Memory Hole At 15MB Addr	:Disabled		
Cache Timing Control	:Normal		
DRAM Timing Control	:Normal		
Fast DRAM	:Disabled		
Burst Write	:Disabled		
CPU Write Back Cache	:Disabled		
Set Turbo Pin Function:Turbo			
Set Mouse Lock	:Disabled		
		Esc: Quit yyy : Select Item	
		F1 : Help Pu/Pd/+- : Modify	
		F5: Old Valuse (Shift)F2: Color	
		F6: Load BIOS Defaults	
		F7 : Load Setup Defaults	

1.4.5 <POWER MANAGEMENT SETUP>

This item should only be set when using the power management function.

This function also supports the power management function.

This is effective when using a CPU that supports this feature.

Power Management	:Disabled	IRQ3 Activity	:Primary
Doze Timer	:32 sec	IRQ4 Activity	:Primary
		IRQ5 Activity	:Primary
Sleep Time	:2 min	IRQ7 Activity	:Primary
Sleep Mode	:Suspend	IRQ8 Activity	:Secondary
HDD Power Management	:Disabled	IRQ10 Activity	:Primary
VGA Activity Wakeup	:Disabled	IRQ11 Activity	:Primary
		IRQ12 Activity	:Primary
I/O Activity	:Disabled	Esc: Quit ȳȳȳ : Select Item	
		F1 : Help Pu/Pd/+/- : Modify	
		F5: Old Valuse (Shift)F2: Color	
		F6: Load BIOS Defaults	
		F7 : Load Setup Defaults	

The main operating states of this function are as follows:

- The CPU itself goes into Low Power mode.
- * VGA signal is shut down (screen goes blank temporarily)
- The HDD motor is shut down.

In addition, the conditions for switching from Low Power mode to normal mode are

Each interrupt (IRQ1, 3, 4, 5, 6, 7, 9, 10, 11, 12, 14,

15) occurs, for example, when a keyboard button is pressed or the mouse is

When it works, etc.

Chapter 2 VGA Drivers

The AS-3210 comes with a VGA-related utility disk. This disk contains programs such as the Windows display driver. The README.DOC on the diskette contains explanations of each program, installation methods, and important points to note, so be sure to read it before use. We will explain the most important programs below.

- CHGVGA.EXE - CRT/LCD switching program

When the AS-3210 starts up, it is in simultaneous display mode, displaying both the CRT and LCD. CHGVGA.EXE switches this display mode.

If you are using Windows with a resolution of 800x600 or higher, you must use the CRT display mode.

Please use it in mode.

CHGVGA /S [Enter] (Simultaneous display mode)

CHGVGA /C[Enter] (CRT display mode) CHGVGA /L[Enter]

(LCD display mode)

Chapter 3: Flash Disk Tools

The AS-3210 has a utility tool for flash disks.

These are contained in the \F_DISK directory on the flash disk. README.TXT in the directory contains information on the flash disk's specifications, how to set it up, and how to use the tool programs, so be sure to read it before using the flash disk. The following explains some particularly important programs.

- FCLEAR.EXE. Flash Clear Tool

Clear the flash memory and emulate a flash disk.

Set the application type.

```
FCLEAR [Enter] Flash clear,  
hard disk type setting  
FCLEAR f [Enter]  
Flash clear, floppy disk type setting
```

If it is a hard disk type, then use the FDISK and FORMAT tools that come with DOS to make it an accessible volume. If it is a floppy disk type, use the FORMAT tool to initialize it into an accessible volume.

- FD2RFSD.EXE.ROM-DISK creation tool

Clear the flash memory and save it to a floppy disk (1.44M)

Copy the entire data to flash memory to create a ROM disk.

vinegar.

```
FD2RFSD A: [Enter]
```

The entire A: floppy disk is written to the flash memory. When you reboot, the flash memory will be treated as a ROM-DISK volume (A: or B:).

It will be.

Chapter 4: Precautions when using interrupts on an I/O board

AS-3210 supports PS2 mice.

The data signal line for the mouse and IRQ12 are multi-function pins. Depending on the board, the

interrupt to be used may be set by software rather than by hardware (jumper pins, etc.).

(For example,

Ethernet board)

For such boards, set the PS2 mouse function before running the program.

It is necessary to disable it so that IRQ12 can be used.

To do this, change the controller register on the board to disable the PS2 mouse and enable IRQ12.

The specific methodology is to write 11 to I/O port: A8h,

Write 1A to A9h.

Below is a method using the DOS command DEBUG.

```
C:\>DEBUG
O A8 11
O A9 1A
Q
C:yy
```

With the above settings, PS2 mouse is disabled and IRQ12 is enabled.

I will.

Appendix A: Board Component Layout

