


## SETUP GUIDE

### MAINBOARD LAYOUT DRAWING:



## SETUP GUIDE

### MEMORY INSTALLATION

No jumper setting is necessary for DRAM setting, BIOS will check DRAM type and size automatically. 586TB main board contains four by 72-pin SIMM sockets (SIMM1, SIMM2, SIMM3 and SIMM4) to support 4MB, 8MB, 16MB, 32MB, or 64MB to from a memory size between 8MB to 256MB, support both FAST PAGE MODE (FPM) and EXTENDED DATA OUTPUT (EDO) SIMMs.

Two by 168-pin DIMM sockets (DIMM1, DIMM2) to support 8MB, 16MB, 32MB, 64MB, 128MB or 256MB to from a memory size between 8MB to 512MB, support FAST PAGE MODE (FPM), EXTENDED DATA OUTPUT (EDO/3.3V) and SYNCHRONOUS DYNAMIC RANDOM ACCESS MEMORY (SDRAM) DIMMs.

SIMM module sockets are divided in two bank; SIMM1 and SIMM2 in BANK 1, SIMM3 and SIMM4 in BANK 2. Minimum user has to install two DRAM SIMMs. DIMM module sockets are divided in three banks: DIMM1 in BANK 1, DIMM2 in BANK 2 and DIMM3 in BANK 3. 586TB main board has table-free (or auto-bank) feature and user can install DIMM into any bank.

NOTE: DIMM 1 BANK - (SIMM 1 + SIMM 2) BANK

DIMM 2 BANK - (SIMM 3 + SIMM 4) BANK

But cannot mix up SIMM with DIMM since chips limitation.

# SETUP GUIDE

## CPU QUICK INSTALLED TABLE


INTEL CPU	CPU CLK			CPU RATIO (JP1)			CPU VOLT (JP16)			
	JP2	JP3	JP4	1-2	3-4	5-6	1-2	3-4	5-6	
P (MOTX) - 233MHz	1-2	1-2	1-2	0	0	0	S	0	0	0
P (MOTX) - 200MHz	1-2	1-2	1-2	0	0	0	S	0	0	0
P (MOTX) - 166MHz	1-2	1-2	1-2	S	S	0	S	0	0	0
PENTIUM - 200MHz	1-2	1-2	1-2	0	S	0	S	S	S	0
PENTIUM - 166MHz	1-2	1-2	1-2	S	S	0	S	S	S	0
PENTIUM - 133MHz	1-2	1-2	2-3	S	S	0	S	S	S	0
PENTIUM - 120MHz	1-2	1-2	1-2	S	0	0	S	S	S	0
PENTIUM - 100MHz	1-2	1-2	1-2	0	0	0	S	S	S	0
PENTIUM - 90MHz	1-2	1-2	2-3	0	0	0	S	S	S	0
PENTIUM - 75MHz	2-3	2-3	2-3	0	0	0	S	S	S	0
AMD CPU	CPU CLK			CPU RATIO (JP1)			CPU VOLT (JP16)			
	JP2	JP3	JP4	1-2	3-4	5-6	1-2	3-4	5-6	7-8
K6 - 200MHz	1-2	1-2	1-2	S	0	S	0	0	S	0
K6 - 166MHz	1-2	1-2	1-2	S	S	S	0	0	S	0
K6 - 133MHz	1-2	1-2	1-2	S	0	S	0	0	S	0
K6 - 100MHz	1-2	1-2	1-2	0	0	0	S	S	0	0
K6 - 90MHz	1-2	1-2	1-2	0	S	0	S	0	0	S
K6 - 66MHz	1-2	1-2	1-2	S	S	0	S	0	0	S
K5 - PR160	1-2	1-2	1-2	S	S	0	S	S	S	S
K5 - PR150	1-2	1-2	2-3	S	S	0	S	S	S	S
K5 - PR133	1-2	1-2	1-2	S	0	0	S	S	S	S
CYRIX CPU	CPU CLK			CPU RATIO (JP1)			CPU VOLT (JP16)			
	JP2	JP3	JP4	1-2	3-4	5-6	1-2	3-4	5-6	7-8
6x86MX - 300MHz	1-2	2-3	1-2	0	S	0	S	0	0	S
6x86MX - 233MHz	1-2	2-3	1-2	S	S	0	S	0	0	S
6x86MX - 200MHz	1-2	2-3	1-2	S	0	0	S	0	0	S
6x86MX - 166MHz	1-2	1-2	1-2	S	S	0	S	0	0	S
6x86MX - 133MHz	1-2	1-2	1-2	S	0	0	S	0	0	S
6x86L - P200 (150MHz)	1-2	2-3	1-2	S	0	0	S	0	0	0
6x86L - P166 (133MHz)	1-2	1-2	1-2	S	0	0	S	0	0	0
6x86L - P150 (120MHz)	1-2	1-2	2-3	S	0	0	S	0	0	0
6x86 - P166 (133MHz)	1-2	1-2	1-2	S	0	0	S	S	S	0
6x86 - P150 (120MHz)	1-2	1-2	2-3	S	0	0	S	S	S	0

Note: 0 - OPEN S - SHORT


# SETUP GUIDE

## JUMPER SETTING

### 1. CPU TO BUS FREQUENCY RATIO JUMPER SETTING (JP1) :




### 2. CPU CLOCK JUMPER SETTING (JP2,JP3,JP4) :



## SETUP GUIDE

### 3. CPU VOLTAGE JUMPER SETTING (JP16)



## SETUP GUIDE

### QUICK TO SETTING CPU TYPE

#### PENTIUM - 75 MHz

5K86 - P75

#### PENTIUM - 90 MHz

5K86 - P90

#### PENTIUM - 100 MHz

5K86 - P100

#### PENTIUM - 120 MHz

#### PENTIUM - 133 MHz

#### PENTIUM - 150 MHz

#### PENTIUM - 166 MHz

#### PENTIUM - 200 MHz

#### PENTIUM - 166 MHz

( MMX )

#### PENTIUM - 200 MHz


( MMX )

#### PENTIUM - 233 MHz

( MMX )

#### AMD K5 - PR133

#### AMD K5 - PR150




## SETUP GUIDE


AMD K5 - PR166		JP2 JP3 JP4  66 MHz	
AMD K6 - PR166		JP2 JP3 JP4  66 MHz	
AMD K6 - PR200		JP2 JP3 JP4  66 MHz	
AMD K6 - PR233		JP2 JP3 JP4  66 MHz	
6X86 - P150(120MHz)		JP2 JP3 JP4  60 MHz	
6X86 - P166(133MHz)		JP2 JP3 JP4  66 MHz	
6X86L - P150(120MHz)		JP2 JP3 JP4  60 MHz	
6X86L - P166(133MHz)		JP2 JP3 JP4  66 MHz	
6X86L - P200(150MHz)		JP2 JP3 JP4  75 MHz	
6X86MX - 166MHz		JP2 JP3 JP4  66 MHz	
6X86MX - 200MHz		JP2 JP3 JP4  66 MHz	
6X86MX - 200MHz		JP2 JP3 JP4  75 MHz	

## SETUP GUIDE

### 4. 168-pin DIMM VOLTAGE JUMPER SETTING (J1, J2) :




### 5. BIOS VOLTAGE JUMPER SETTING (JP10) :




## SETUP GUIDE

### 6. CMOS CLEAR (J7) :




### 7. BATTERY :




## SETUP GUIDE

### 8. AT POWER SUPPLY CONNECTOR :




### 9. ATX POWER SUPPLY CONNECTOR (CN3) :




## SETUP GUIDE

### 10. SYSTEM PANEL CONNECTORS (JP19) :



### 11. IR CONNECTOR (IR1) :



## SETUP GUIDE

### BIOS SETTING

#### Introduction

This manual discusses Award's Setup program built into the ROM BIOS. The Setup program allows users to modify the basic system configuration. This special information is then stored in battery back-up RAM so that it retains the Setup information when the power is turned off.

The Award BIOS installed in your computer system ROM (Read Only Memory) is a custom version of an industry standard BIOS. This means that it supports Intel/Cyrix/AMD/ C6 processors in a standard IBM-AT compatible Input/output system. The BIOS provides critical low-level support for standard devices such as disk drives, serial and parallel ports.

The Award BIOS has been customized by adding important, but non-standard, features such as virus and password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

The rest of this manual is intended to guide you through the process of configuring your system using Setup.

#### Starting Setup

The Award BIOS is immediately activated when you first power on the computer. The BIOS reads the system information contained in the CMOS and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

1. By pressing <Del> immediately after switching the system on, or
2. by pressing the <Del> key when the following message appears briefly at the bottom of the screen during the POST (Power On Self Test).

Press <DEL> to enter SETUP.

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing

# SETUP GUIDE

## MAINBOARD LAYOUT DRAWING:

