```
Jumper setting for KW559b

JP1:    HDD indicator
JP3:    Select the IDE drive speed grade

        2 4 6
        1 3 5

        4-6 and 3-5 close :        Speed 0 (default)
        4-6 and 1-3 close :        Speed 1
        2-4 and 1-3 close :        Speed 2

JP4: used to select the IRQ level corresponding to COMA, COMB and PARALLEL

        2   4   6   8   10  12  14  16  18  20
        1   3   5   7    9  11  13  15  17  19

        COMA    :
                1-2     close:           IRQ3
                3-4     close:           IRQ4    (default)
                5-6     close:           IRQ5
                7-8     close:           IRQ9
        COMB    :
                9-10    close:           IRQ3    (default)
                11-12   close:           IRQ4
                13-14   close:           IRQ5
                15-16   close:           IRQ9
        PARALLEL:
                17-18   close:           IRQ7    (default)
                19-20   close:           IRQ5

JP5:Parallel port direction select.
        1
        2
        3

        1-2     close:  input/output mode (default)
        2-3     close:  output only

JP6: Game port enable
        2   4
        1   3

        1-2 and 3-4 close:        enable game port (default)
        all open:                 disable game port

JP7: used to select the I/O address of COMA , COMB and parallel port.

        2   4   6   8   10  12  14  16  18  20  22
        1   3   5   7    9  11  13  15  17  19  21

        COMA    :
                1-2     close:           3F8H    (default)
                3-4     close:           2F8H
                5-6     close:           3E8H
                7-8     close:           2E8H
        COMB    :
                9-10    close:           3F8H
                11-12   close:           2F8H    (default)
                13-14   close:           3E8H
                15-16   close:           2E8H
        PARALLEL:
                17-18   close:           3BCH
                19-20   close:           378H    (default)
                21-22   close:           278H

JP8: used to enable (disable) and select corresponding I/O address of FDC.
```

```
       6  5
       4  3
          2  1

    1-3 close:         disable FDC
    2-4 and 3-5 close:        enable FDC and select 3F0-7H (default)
    4-6 and 3-5 close:        enable FDC and select 370-7H

--- Fin --
```