DFI BIOSecure Application user guideline :

Please Building in the SPI link with USB Cable.

A. Please refer to the captures as below for install the driver of SPI BIOS Programmer.

1. Please update the “SPI flash” driver in “Device manager”.

2. Please click the “Install the software automatically.[Recommended].

Please refer to the subdirectory of DVD Driver as below for get the SPI flash writer Driver.

Please click the “Continue Anyway” .

3. To click the “finish”.

4. New you can program the SPI BIOS.

B. Build in with SPI_Link Application by DVD Driver.

Please click below logo to run the BIOSecure application.

Flash BIOS from bin file:

Please load the bin file to the system memory buffer in “Load from file”.

Please Choose correct bin file.

Show the Checksum of bin file.

Please click the “Program to device” for flash new version BIOS.

The AP will program the BIOS.

The AP will show below message when the BIOS flash success.

Backup BIOS file from device:

Please click the “Read from device” to read the BIOS file from SPI device to the system memory buffer.

The AP will show below message when read the BIOS data success.

Please click the “Save to file” for backup the BIOS data.

Please enter a file name to save it.

To double check the BIOS file.