

PERSYST UNI-PORT - ASSY # 12-10063-XX

JUMPER SETTINGS

E1-E2 ON SELECTS PRIMARY CLOCK ADDRESS
OFF SELECTS SECONDARY CLOCK ADDRESS

E3-E4 ON SELECTS PRIMARY PARALLEL PORT ADDRESS (378H)
OFF SELECTS SECONDARY PORT ADDRESS (278H)

E18-E20 SELECTS CENTRONICS INTREFACE (IBM STANDARD)

E23-E26 SELECTS INTERNAL UNIDIRECTIONAL CONTROL

E22-E25 SELECTS EXTERNAL BI-DIRECTIONAL CONTROL

E21-E24 SELECTS INTERNAL BI-DIRECTIONAL CONTROL

INTERRUPT LEVEL SELECTION FOR CAL/CLOCK

E5-E6 IRQ 2

E11-E12 IRQ 3

E6-E7 IRQ 4

E12-E13 IRQ 7

NOTES: The Persyst CLOCK.COM program does not require any interrupt levels with the Calendar/Clock port.

INTERRUPT LEVEL SELECTION FOR PARALLEL PRINTER PORT

E8-E9 IRQ 2

E14-E15 IRQ 3

E15-E16 IRQ 5

E9-E10 IRQ 7 IBM Parallel Port standard interrupt level

□