

BoB DISPLAY ADAPTER

Assy. # 12-10078-xx

There are no switches to set on BoB.

Set the PC's motherboard switches for an 80-column color display.

Jumper E1-E2 and E4-E5 for complete IBM Color/Graphics software compatibility.

Jumper E2-E3 and E5-E6 for 'flicker-free' operation.