


Quick Reference Guide

1570 Rev. C.1 VGA Card

No manual is required with this video adapter. Insert the utility diskette into your computer floppy drive and run: README [Return].

The jumper JP2 and JP4 on the board are firmly set by factory, so they are not provided for user's selection. And, you can change the setting of the jumper JP1 when using a SVGA/VESA monitor and jumper JP3 when using a mono/color monitor.



JP1	ON OFF	VESA SVGA (default)
JP3	ON OFF	Mono Color (default)

Note:

1. The video memory size is 1MB on board.
2. For the detailed description of VESA's function, please refer to the README.DOC file of the 77VESA subdirectory in the diskette #1.

Version 1.00
Jan. 30, 1993
Printed In Taiwan
3100503046