


EIDE2300PLUS (Goldstar)

- [All current drivers](#)
- [General layout](#)
- [LBA enable/disable](#)
- [VL/ISA enable/disable and primary/secondary](#)
- [External BIOS address settings](#)
- [VL-IDE speed select](#)
- [I/O and game port enable/disable](#)
- [I/O port settings](#)
- [EPP/ECP select](#)
- [ECP DMA settings](#)

EIDE2300PLUS (LGS) General Layout



Jumpers JP1 - JP5

JP1: VL BUS IDE LBA On/Off



Default Settings

Default



JP2: VL ENABLE & Primary/Secondary Select



Default Settings

Default




JP3: External BIOS Address Select



Default Settings

Default




JP4: VL-IDE Speed Select



Default Settings

Default





JP6: RESERVED



Default Settings

Jumpers of JP5 have been set at factory. Please do not change.

Jumpers JP6 - JP8



EIDE2300PLUS Drivers

Filename	Size	Description
2300EIDE.EXE	366,845	Drivers & Utilities V3.31
EIDEW95.ZIP	12,416	Drivers for Windows 95
EIDENT35.ZIP	28,475	Drivers for NT 3.5
EIDEWARP.ZIP	22,446	Drivers for OS/2 WARP & DMA/ATAPI CD v1.0
EIDE_331.ZIP	135,409	ONLY - Drivers DOS/Windows v3.31
DRVSPD.TXT	4.942	Driver settings for various harddrives