



• Default Settings

ASYN1	J9	J10
*COM1 (3F8)	2-3	1-2
COM3 (3E8)	1-2	2-3
COM4 (2E8)	2-3	2-3
Disable	1-2	1-2

ASYN2	J7	J8
*COM2 (2F8)	2-3	1-2
COM3 (3E8)	2-3	2-3
COM4 (2E8)	1-2	2-3
Disable	1-2	1-2

Printer Mode	J13	J14
* EPP/ECP	1-2	2-3
EPP	2-3	1-2
SPP	2-3	2-3
Reserved	1-2	1-2

Printer Port	J11	J12
* LPT1 (378)	1-2	2-3
LPT2 (278)	2-3	1-2
LPT3 (3BC)	2-3	2-3
Disable	1-2	1-2

JMP	Function	1-2/ON	2-3/OFF
J2	ASYN2 Mode	* Serial	IrDA
J3	FDD A/B Swap	* A/B Swap	* Normal
J4	FDC Enable	Disabled	* Enabled
J5	IDE Address	* Primary	Secondary
J6	IDE Enable	Disabled	* Enabled
J15	Game Port	* Enabled	Disabled
J17	IDE IRQ	* IRQ 14	IRQ 15

ESIO-V2.1