

```
1  jp1 fdd enable/disable - 2-3/1-2
2  jp2 hdd en/dis - 2-3/1-2
3
4  jp3 & jp4 - port address serial 1:
5  1-2 1-2 disabled
6  2-3 1-2 3f8
7  1-2 2-3 3e8
8  2-3 2-3 2e8
9
10 jp5 & jp6 - port address serial 2
11 1-2 1-2 disabled
12 2-3 1-2 2f8
13 1-2 2-3 2e8
14 2-3 2-3 3e8
15
16
17 jp7 & jp8 - port address LPT:
18 1-2 1-2 disable
19 2-3 1-2 278
20 1-3 2-3 378
21 2-3 2-3 3bc
22
23 jp9 serial 1 irq 4/3 - 2-3/1-2
24 jp10 serial 2 irq 4/3 - 2-3/1-2
25 jp11 LPT irq 7/5 - 1-2/2-3
```