

PANTEK PIO-001

JP2	1-2 ENABLE 2-3 DISABLE	SERIAL 1 SERIAL 1
JP4	1-2 ENABLE 2-3 DISABLE	PRINTER PORT PRINTER PORT
JP5	1-2 SELECT 2-3 SELECT	COM1 (3F8) ON SERIAL 1 COM3 (3E8)
JP6	1-2 SELECT 2-3 SELECT	COM2 (2F8) ON SERIAL 2 COM4 (2E8)
JP7	1-2 ENABLE 2-3 DISABLE	SERIAL 2 SERIAL 2
JP8	1-2 LOW 2-3 FAST	SPEED IDE HARD DISK SPEED IDE HARD DISK
JP9	1-2 ENABLE 2-3 DISABLE	HARD DISK CONTROLLER HARD DISK CONTROLLER
JP10	1-2 SELECT 2-3 SELECT	PRINTER PORT LPT2 (378) PRINTER PORT LPT3 (278)
JP11	1-2 ENABLE 2-3 DISABL	GAME PORT GAME PORT
JP12	1-2 ENABLE 2-3 DISABLE	FLOPPY CONTROLLER FLOPPY CONTROLLER

J1	-	DB25S PARALLEL PRINTER PORT CONNECTOR
P1	-	DB15S GAME PORT CONNECTOR
P2	-	2 PINS WINCHESTER ACTIVITY LED CONNECTOR
P3	-	40 PINS AT-BUS HARD DISK CONNECTOR
P4	-	34 PINS FLOPPY DISKETTE DRIVE CONNECTOR
P5	-	10 PINS PRIMARY SERIAL PORT CONNECTOR
P6	-	10 PINS SECONDARY SERIAL PORT CONNECTOR

***** END