


# AST RESEARCH, INC. ADVANTAGE+ (CHINA) 486 (202676-F08)

|                          |   |
|--------------------------|---|
| <b>Processor</b>         | 80486SX/80486DX/CX486DX2/80486DX2/CX5X86  |
| <b>Processor Speed</b>   | 25/33/50(internal)/66(internal)MHz  |
| <b>Chip Set</b>          | Unidentified  |
| <b>Max. Onboard DRAM</b> | 20MB  |
| <b>Cache</b>             | None  |
| <b>BIOS</b>              | Unidentified  |
| <b>Dimensions</b>        | 220mm x 220mm   |
| <b>I/O Options</b>       | Floppy drive interface, IDE interface, parallel port, PS/2 mouse port, serial port, VGA feature connector, VGA port, riser slot |
| <b>NPU Options</b>       | None  |



| CONNECTIONS     |          |                        |          |
|-----------------|----------|------------------------|----------|
| Purpose         | Location | Purpose                | Location |
| VGA port        | CN1      | IDE interface LED      | E13      |
| Parallel port   | CN2      | VGA feature connector  | J19      |
| Serial port     | CN3      | IDE interface          | J22      |
| PS/2 mouse port | CN4      | Floppy drive interface | J24      |
| Reset switch    | E11      | Chassis fan power      | J28      |
| Power LED       | E12      | Riser slot             | SL1      |

Continued on next page. . .

# AST RESEARCH, INC.

## ADVANTAGE+ (CHINA) 486 (202676-F08)

... continued from previous page

| USER CONFIGURABLE SETTINGS          |        |          |
|-------------------------------------|--------|----------|
| Function                            | Jumper | Position |
| í Factory configured - do not alter | E1     | Open     |
| í Factory configured - do not alter | E2     | Open     |
| í On board video enabled            | E3     | Closed   |
| On board video disabled             | E3     | Open     |
| í Monitor type select color         | E4     | Open     |
| Monitor type select monochrome      | E4     | Closed   |
| í Password enabled                  | E5     | Open     |
| Password disabled                   | E5     | Closed   |
| í Factory configured - do not alter | E8     | Open     |
| í Flash BIOS normal operation       | E14    | Open     |
| Flash BIOS force update at boot     | E14    | Closed   |
| í Factory configured - do not alter | E16    | Open     |

| DRAM CONFIGURATION   |        |               |
|--|--------|---------------|
| Size   | Bank 0 | Bank 1        |
| 4MB  | 4MB    | NONE          |
| 5MB  | 4MB    | (1) 256K x 32 |
| 8MB  | 4MB    | (1) 4M x 32   |
| 20MB   | 4MB    | (1) 4M x 32   |
| Note: Bank 0 is factory installed and is not configurable. |        |               |

| CPU TYPE CONFIGURATION   |                   |        |                   |                   |
|--|-------------------|--------|-------------------|-------------------|
| Type   | E6                | E7     | E9                | E10               |
| 80486SX  | pins 1 & 2 closed | Open   | pins 2 & 3 closed | pins 1 & 2 closed |
| 80486DX  | pins 1 & 2 closed | Closed | pins 2 & 3 closed | pins 2 & 3 closed |
| 80486DX2   | pins 1 & 2 closed | Closed | pins 2 & 3 closed | pins 2 & 3 closed |
| Note: Upgrades are not supported. These settings are for reference only. |                   |        |                   |                   |