

Multiplier & BUS select - Lucky Star 5IX-VX

BUS	JP2	JP3	JP4
50 MHz	1-2	1-2	1-2
55 MHz	2-3	1-2	1-2
60 MHz	1-2	1-2	2-3
66 MHz	1-2	2-3	1-2
75 MHz	2-3	1-2	2-3
83 MHz	2-3	2-3	1-2

JP6	JP7	K5-PR75	P54C/CS	P55C
1-2	1-2	1.5	1.5	2.5
1-2	2-3	1.5	3	3
2-3	1-2	2	2	2
2-3	2-3	2	2.5	2.5