


User Manual

AC8-N MINI PC



Overview



1. ON/OFF button

2. USB 3.0 x 2

3. USB 3.0 x 2

8. HDMI video output

9. DP port

10. VGA port or Com Port

-
- | | |
|-----------------------------|------------------------|
| 4. Micro SD slot | 11. LAN RJ45 Port |
| 5. MIC port | 12. LAN RJ45 Port |
| 6. Audio port | 13. Power supply DC IN |
| 7. Slot for Kensington Lock | |

TURNING ON

Press and hold the ON/OFF Button for a couple of seconds to turn on your computer

Power Supply

Connect the provided charger (12V2.5A or 12V2.0A) to the power supply port, do not use other than the provided charger.

ON/OFF button

You can see computer status by looking at the ON/OFF button.


Blue light: computer is turn on.

No light: computer is turn off or sleeping.

Installing SSD STORAGE or replace the SSD

You need to install an SSD drive and windows before you use the computer, You can replace the SSD driver with more big capacity, if find the storage is not enough. **Important:** The m.2 SSD could be **SATA/NVME** type, the supported length of m.2 SATA/NVME SSD is 2280.

If you replace the SSD driver, driver is needed for using windows OS, it can be downloaded from website www.newsmaytech.com or contact us



- a. Unscrew the screw on the hatch on the bottom
- b. Insert or replace the m.2 SATA/NVME SSD in the orientation as on the picture above
- c. Screw the security screw to hold the SSD in place
- d. Screw back the protection hatch

SAFETY INFORMATION

Operating temperature: 10°C to 35°C, **storage temperature:** 30°C to 70°C, **relative humidity:** 0% to 90%(noncondensing).

Built-in battery: Do not attempt to replace or remove the battery yourself. You may damage the battery, which could cause overheating and injury, The battery should be replaced by an authorized service provider, and must be recycled or disposed of separately from household waste.

Liquid exposure: Keep your computer away from sources of liquid, such as drinks, oils, lotions, sinks, bathtubs, shower stalls, and so on. Protect your computer from dampness, humidity, or wet weather, such as rain, snow and fog.

Charging: charge only with the included power adapter, other power adapters might not meet safety standards, and using such power adapters could pose a risk of death or injury, using damaged power adapters or cables, or charging when moisture is present, can cause fire, electric shock, injury, or damage to your computer or other property. Do not use a power adapter in wet locations, such as near a sink, bathtub, or shower stall, or connect or disconnect the power adapter with wet hands.

Manufacture: Newsmay Technology Co.,Ltd

Web: www.newsmaytech.com

Phone: +86-0755-89456786

Email: info@newsmaytech.com