

• Quick Guide

■ ON (or Closed) □ off (or Open)

FUNCTION SELECTION		SW1				SW2								SW4		JP1	JP2	JP3				
		1	2	3	4	1	2	3	4	5	6	7	8	COLOR	MONO	1	3	1	3	1	3	
BANK WINDOW ADDRESS FOR EMS		□	□	■	□																	
8087-1	ENABLE																					
	DISABLE																					
MEMORY SIZE	256KB																					
	512KB																					
	640KB																					
	768KB																					
	1MB																					
DISPLAY TYPE	DISABLE																					
	COLOR																					
	MONOCHROME																					
DRIVE NUMBER	0 DISK DRIVE																					
	1 DISK DRIVE																					
	2 DISK DRIVES																					
RTC ADDRESS	RTC 0																					
	RTC 1																					
RTC INTERRUPT	ENABLE																					
	DISABLE																					

Bank Window Address Please Take Reference of Manual for Adjustment.

• Switch Position

