



**E9, E6, E8**  
**External Clock/CMOS Battery (Jumper E9)**  
 Replace Clock/CMOS battery with Compaq Spares P/N 160274-001 only. (4.5V alkaline computer battery)

**Allow Power-On Password (Jumper E6)**  
 Pins 5-6 enable  
 Pins 6-7 disable/clear

**CMOS Erase (Jumper E8)**  
 Remove Jumper E8 for 60 seconds and reinstall to clear CMOS.

Memory Module Slots (Add memory in pairs: A&B or D&C)

SW1 Bus Speed / CPU Core Speed				
S1	S2	S3	S4	Configuration
ON	ON	OFF	OFF	P54C-50/75
ON	ON	ON	OFF	P54C-50/100
ON	ON	ON	ON	P54C-50/125
ON	ON	OFF	ON	P54C-50/150
OFF	ON	OFF	OFF	P54C-66/100
OFF	ON	ON	OFF	P54C-66/133
OFF	ON	ON	ON	P54C-66/166
OFF	ON	OFF	ON	P54C-66/200
ON	OFF	OFF	OFF	P54C-60/90
ON	OFF	ON	OFF	P54C-60/120
ON	OFF	ON	ON	P54C-60/150

**CAUTION:**  
 Do not operate the computer with the system unit cover removed.

**WARNING:**  
  
 Drive and Component Surfaces may be hot. Allow to cool before touching.