

The 80386 I-Cache board is a full-sized (13.8" x 12.025") motherboard which took all of its memory as DRAM plugged into a proprietary 32-bit memory card. There are two versions of the I-Cache board, identified by part numbers 09-00010, and 09-00021, which are silk-screened on the component (top) side of the motherboard.

The most common memory card used with the I-Cache board is the M500. This is part number 09-00011. The upper left corner has "385 Memory Board" silk-screened on many M500 cards.

```

+=====+
+               +
+ MOTHERBOARD SWITCH SETTINGS +
+               +
+ * = Default setting          +
+=====+

1  Reserved                               *On

2  80387 Coprocessor installed            On
   80387 Coprocessor not installed       *Off

3  Bus speed selection (see below)

4  Bios relocation enabled                *On
   Bios relocation disabled                Off

5  Reserved                               *Off

6  Color video adapter                    *On
   Monochrome video adapter                Off

7  Cache enabled                          *On
   Cache disabled                          Off

8  Bus speed selection (see below)

```

Bus speed selection

	Switch settings -- * = default			
Board	SW1.3=OFF	SW1.3=ON	SW1.3=ON	SW1.3=OFF
Speed	SW1.8=OFF	SW1.8=OFF	SW1.8=ON	SW1.8=ON
20MHz	5 Mhz	6.66 Mhz	10 Mhz *	Undefined
25MHz	6.25 Mhz	8.33 Mhz*	12.5 Mhz	Undefined
33MHz	8.33 Mhz*	11.33 Mhz	16.66 Mhz	Undefined

```

+=====+
+               +
+ MOTHERBOARD JUMPER SETTINGS +
+               +
+=====+

```

- J1 Keyboard connector
- J2 External 6-volt battery connector
 - Pin 1 - Battery Positive
 - Pin 2 - no connector
 - Pin 3 - Ground

Pin 4 - Ground

J21 Keylock / Power LED

Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

J22 External speaker

Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts

J25 External Keyboard connector

Pin 1 - Keyboard clock
Pin 2 - Keyboard data
Pin 3 - no connector
Pin 4 - Ground
Pin 5 - +5V DC

W1 Reset switch

Pin 1 - Signal
Pin 2 - Ground

W7 Co-processor configuration

Pins 1-2 Asynchronous Operation
No connection Synchronous Operation

W8 Co-processor configuration

Pins 1-2 Asynchronous Operation
No connection Synchronous Operation

W9 Turbo light connector

Pin 1 - Signal
Pin 2 - Ground

W12 Cache configuration

Pins 1-2 Direct mapped (32KB)
No connection Two-way set associative (64KB)

W13 Cache configuration

Pins 1-2 Direct mapped (32KB)
Pins 2-3 Two-way set associative (64KB)

W15 Turbo switch

Pin 1 - Signal
Pin 2 - Ground

W22 Non-cacheable region selection

Pins 1-2 E00000 - EFFFFFF non-cacheable
No connection D00000 - DFFFFFF non-cacheable

W23 Reserved

No connection

W30 Reserved

Pins 2-3

```
+=====+  
+           +  
+ MEMORY CARDS +  
+           +  
+=====+
```

M500 memory card:
=====

There is a bank of eight (8) switches in the upper left corner of the M500 memory card. They should be set as follows:

	SW1.1	SW1.2	SW1.3	SW1.4	SW1.5	SW1.6	SW1.7	SW1.8	
1MB	ON	OFF	ON	ON	ON	OFF	OFF	OFF	
2MB	OFF	ON	ON	ON	ON	OFF	OFF	OFF	
4MB	ON	ON	OFF	OFF	ON	OFF	OFF	OFF	
5MB	OFF	OFF	OFF	ON	ON	OFF	OFF	OFF	
8MB	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF	
12MB	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF	(with 4M-08)
16MB	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF	(with 4M-08)

Recommended memory chips

Hyundai	HY53C256LS-80	256Kx1 page mode DRAM
Toshiba	TC511000P-85	1Mx1 page mode DRAM
Samsung	KM41C1000P-80	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Intel	P21010-08	1Mx1 page mode DRAM
Samsung	KM41C1000P-80	1Mx1 page mode DRAM

4M-08 memory expansion board:
=====

The 4M-08 provides an additional 4MB (expandable to 8MB) for the M500 memory card. There is a bank of four (4) switches on the card. The M500 must be filled with 8MB before the 4M-08 will function.

With the M500:

	S1	S2	S3	S4
12MB	OFF	ON	OFF	OFF
16MB	OFF	ON	ON	OFF

This document is for the full-sized (13.8" x 12.025") 80386-16 motherboard. It's identifying features are: an LED between expansion slots #5 and #6; a proprietary memory card slot #7; a bank of eight switches between slot #1 and the keyboard connector; four ROM sockets; 8-bit slots for #2 and #6; 16-bit slots for #1, #3, #4, #5, and #8; and a socket for an 80287 math coprocessor next to the CPU.

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+                                     +
+ MOTHERBOARD SWITCH SETTINGS +
+                                     +
+ * = Default setting           +
+=====+

```

- 1 Reserved *On
- 2 80287 Coprocessor installed On
- 80287 Coprocessor not installed *Off
- 80387 Coprocessor installed On
- 3 4 Mhz 80287 Coprocessor installed On
- 8 Mhz 80287 Coprocessor installed *Off
- 10 Mhz 80287 Coprocessor installed Off

4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	See below	---
8	Reserved	*Off

If the M100C, or M400C memory card is installed, then switch 7 is defined as follows:

7	Cache enabled	*On
	Cache disabled	Off

If the M100, M200, or M300 memory card is installed, then switch 7 is defined as follows:

7	Reserved	*Off
---	----------	------

```

+=====+
+                               +
+ MOTHERBOARD JUMPER SETTINGS +
+                               +
+=====+

```

J1 External 6-volt battery connector

Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J21 Keylock / Power LED

Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

J22 External speaker

Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts

W1 Reset switch

Pin 1 - Signal
Pin 2 - Ground

W4 ROM size

Pin 1-2 128KB
Pin 2-3 256KB

W5 Reserved - always installed

W6 Memory card type

Pin 1-2 Static column memory card
Pin 2-3 Cache memory card

```

+=====+

```

```

+           +
+ MEMORY CARDS +
+           +
+=====+

```

M100 memory card:
=====

The M100 memory card can hold 1MB or 2MB. The first MB is usually soldered on the board. This is the card that was most commonly used by CompuAdd.

NOTE: All of the memory on the M100 must be static column DRAM (as opposed to page mode DRAM) in order for the 2M-08, or 4M-08 to operate.

There is a row of nine (9) jumper pins in the lower left corner of the M100 memory card. They should be positioned as follows:

```

1MB  Pin 2-3, Pin 4-5, Pin 7-8
2MB  Pin 1-2, Pin 4-5, Pin 7-8
4MB  Pin 1-2, Pin 4-5, Pin 7-8 (with 2M-08)
6MB  Pin 1-2, Pin 4-5, Pin 7-8 (with 4M-08)
10MB Pin 1-2, Pin 4-5, Pin 7-8 (with 4M-08)

```

Recommended memory chips for the second MB

```

-----
Hitachi   HM51258P-8   256Kx1 static column DRAM
Hitachi   HM51258P-10  256Kx1 static column DRAM
Hitachi   HM51258P-12  256Kx1 static column DRAM
NMB       AAA2800P-07   256Kx1 static column DRAM
NMB       AAA2800P-08  256Kx1 static column DRAM
NMB       AAA2800P-10  256Kx1 static column DRAM
Panasonic MN41256A-08  256Kx1 page mode DRAM (see note above)
Hyundai   HY53C256LS-80 256Kx1 page mode DRAM (see note above)
NMB       AAA2801P-08  256Kx1 page mode DRAM (see note above)
NMB       AAA2801P-10  256Kx1 page mode DRAM (see note above)

```

M200 memory card:
=====

The M200 memory card can hold 4MB or 8MB using 1Mx1 DRAM. The top two rows of chips make up bank 0, and the bottom two rows make up bank 1.

There is a set of five (5) two-pin jumpers in the lower left corner of the M200 memory card. They should be set as follows:

```

      W1  W2  W3  W4  W5
4MB  ON   ON   OFF OFF OFF
8MB  OFF  ON   OFF OFF OFF
12MB OFF  OFF  OFF OFF OFF (with 4M-08)
16MB OFF  OFF  OFF OFF OFF (with 4M-08)

```

Recommended memory chips

```

-----
Toshiba   TC511000P-85  1Mx1 page mode DRAM
Toshiba   TC511000P-10  1Mx1 page mode DRAM
Samsung   KM41C1000P-10  1Mx1 page mode DRAM
Samsung   KM41C1000P-80  1Mx1 page mode DRAM
Mitsubishi M5M4100AP    1Mx1 page mode DRAM
Motorola  MCM511000P-10  1Mx1 page mode DRAM
Motorola  MCM511000P-85  1Mx1 page mode DRAM
Siemens   HYB511000-85   1Mx1 page mode DRAM
Siemens   HYB511000-70   1Mx1 page mode DRAM
Intel     P21010-08      1Mx1 page mode DRAM
Intel     P21010-10      1Mx1 page mode DRAM

```

M300 memory card:

=====

The M300 memory card can hold 1MB, 2MB, or 6MB. Each of the first two MB is made up of four (4) 256Kx1, and eight (8) 256Kx4 chips. The lower four rows of chips hold 1Mx1 chips, and must be filled in completely. It is not possible to partially fill the lower bank of memory.

There is a bank of eight (8) switches in the upper left corner of the M300 memory card. They should be set as follows:

	SW1.1	SW1.2	SW1.3	SW1.4	SW1.5	SW1.6	SW1.7	SW1.8	
1MB	OFF	OFF	OFF	OFF	ON	ON	OFF	ON	
2MB	OFF	OFF	ON	OFF	ON	ON	OFF	ON	
6MB	OFF	ON	ON	OFF	ON	ON	OFF	ON	
10MB	ON	ON	ON	OFF	ON	ON	OFF	ON	(with 4M-08)
14MB	ON	ON	ON	OFF	ON	ON	OFF	ON	(with 4M-08)

Recommended memory chips

Hyundai	HY53C256LS-10	256Kx1 page mode DRAM
Hyundai	HY53C256LS-80	256Kx1 page mode DRAM
NMB	AAA2801P-07	256Kx1 page mode DRAM
NMB	AAA2801P-08	256Kx1 page mode DRAM
OKI	M514256-10	256Kx4 page mode DRAM
Fujitsu	MB81C4256-10P	256Kx4 page mode DRAM
Siemens	HYB514256A-80	256Kx4 page mode DRAM
Samsung	KM44C256AP-80	256Kx4 page mode DRAM
Toshiba	TC511000P-10	1Mx1 page mode DRAM
Toshiba	TC511000P-85	1Mx1 page mode DRAM
NEC	D421000C-80	1Mx1 page mode DRAM
Motorola	MCM511000P-10	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Samsung	KM41C1000P-10	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Mitsubishi	M5M4100AP	1Mx1 page mode DRAM

M100C memory card:

=====

The M100C memory card can hold 1MB or 2MB. It has an Austek cache controller in the lower left corner of the card. It accommodates either the 2M-08, or the 4M-08.

NOTE: Static column DRAM (as opposed to page mode DRAM) is recommended when using either the 2M-08, or the 4M-08.

There are two jumpers on the M100C memory card. W1 is in the upper left corner, and W3 is in the lower left corner. They should be set as follows:

	W1	W3	
1MB	Pin 1-2	ON	
2MB	Pin 2-3	ON	
4MB	Pin 2-3	ON	(with 2M-08)
6MB	Pin 2-3	ON	(with 4M-08)
10MB	Pin 2-3	ON	(with 4M-08)

Recommended memory chips

Hitachi	HM51258P-8	256Kx1 static column DRAM
NMB	AAA2800P-07	256Kx1 static column DRAM
NMB	AAA2800P-08	256Kx1 static column DRAM
Panasonic	MN41256A-08	256Kx1 page mode DRAM (see note above)
Sharp	LH21256-08	256Kx1 page mode DRAM (see note above)

NMB AAA2801P-06 256Kx1 page mode DRAM (see note above)
NMB AAA2801P-08 256Kx1 page mode DRAM (see note above)

M400C memory card:
=====

The M400C memory card can hold 4MB or 8MB. It has an Austek cache controller in the lower left corner. The M400C cannot accommodate either of the memory expansion cards, as it has no connectors.

There are two jumpers on the M400C memory card. W1 is in the upper left corner, and W3 is in the lower left corner. They should be set as follows:

	W1	W3
4MB	Pin 1-2	ON
8MB	Pin 2-3	ON

Recommended memory chips

NEC	D421000C-80	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Intel	P21010-08	1Mx1 page mode DRAM
Samsung	KM41C1000P-80	1Mx1 page mode DRAM

2M-08 memory expansion board:
=====

The 2M-08 provides an additional 2MB, and is compatible with the M100, and M100C memory cards. It is not compatible with the M200, the M300, or the M400C. The 2M-08 comes populated, and has no jumpers or switches to set.

4M-08 memory expansion board:
=====

The 4M-08 provides an additional 4MB (expandable to 8MB) for the M100, M200, M300, and M100C memory cards. It is not compatible with the M400C. There is a bank of four (4) switches on the card. The settings differ for each of the main memory boards.

Recommended memory chips

Use the tables above for the 1Mx1 page mode DRAM used for the appropriate main memory card.

With the M100:

	S1	S2	S3	S4
6MB	ON	OFF	OFF	OFF
10MB	ON	OFF	ON	OFF

With the M200:

	S1	S2	S3	S4
12MB	OFF	ON	OFF	OFF
16MB	OFF	ON	ON	OFF

With the M300:

	S1	S2	S3	S4
10MB	ON	ON	OFF	OFF
14MB	ON	ON	ON	OFF

With the M100C:

	S1	S2	S3	S4
6MB	ON	OFF	OFF	OFF
10MB	ON	OFF	ON	OFF

This document is for the full-sized (13.8" x 12.025") 80386-20 motherboard. It's identifying features are: an LED between expansion slots 5 and 6; a proprietary memory card slot as the seventh slot; a bank of eight switches between slot 1 and the keyboard connector; four ROM sockets; 8-bit slots for #2 and #6; 16-bit slots for #1, #3, #4, #5, and #8; and a socket for an 80287 math coprocessor next to the CPU.

The bus speed for this motherboard is fixed at 10MHz. Peripherals which do not support this higher bus speed may have difficulties running on this 20MHz motherboard.

```

+=====+
+           +
+ MOTHERBOARD SWITCH SETTINGS +
+           +
+ * = Default setting          +
+=====+

1  Reserved                      *On

2  80287 Coprocessor installed    On
   80287 Coprocessor not installed *Off
   80387 Coprocessor installed    On

3  4 Mhz 80287 Coprocessor installed On
   8 Mhz 80287 Coprocessor installed *Off
   10 Mhz 80287 Coprocessor installed Off

4  Bios relocation enabled        *On
   Bios relocation disabled       Off

5  Reserved                      *Off

6  Color video adapter            *On
   Monochrome video adapter       Off

7  See below                      ---

8  Reserved                      *Off

```

If the M100C, or M400C memory card is installed, then switch 7 is defined as follows:

```

7  Cache enabled *On
   Cache disabled Off

```

If the M100, M200, or M300 memory card is installed, then switch 7 is defined as follows:

```

7  Reserved *Off

```

```

+=====+
+           +

```

+ MOTHERBOARD JUMPER SETTINGS +
+ +
+=====+

J1 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J21 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

J22 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts

W1 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W4 ROM size
Pin 1-2 128KB
Pin 2-3 256KB

W5 Reserved - always installed

W6 Memory card type
Pin 1-2 Static column memory card
Pin 2-3 Cache memory card

+=====+
+ +
+ MEMORY CARDS +
+ +
+=====+

M100 memory card:
=====

The M100 memory card can hold 1MB or 2MB. The first MB is usually soldered on the board. This is the card that was most commonly used by CompuAdd.

NOTE: All of the memory on the M100 must be static column DRAM (as opposed to page mode DRAM) in order for the 2M-08, or 4M-08 to operate.

There is a row of nine (9) jumper pins in the lower left corner of the M100 memory card. They should be positioned as follows:

1MB Pin 2-3, Pin 4-5, Pin 7-8
2MB Pin 1-2, Pin 4-5, Pin 7-8
4MB Pin 1-2, Pin 4-5, Pin 7-8 (with 2M-08)
6MB Pin 1-2, Pin 4-5, Pin 7-8 (with 4M-08)
10MB Pin 1-2, Pin 4-5, Pin 7-8 (with 4M-08)

Recommended memory chips for the second MB

Hitachi HM51258P-8 256Kx1 static column DRAM
NMB AAA2800P-07 256Kx1 static column DRAM

NMB AAA2800P-08 256Kx1 static column DRAM
 NMB AAA2801P-06 256Kx1 page mode DRAM (see note above)

M200 memory card:
 =====

The M200 memory card can hold 4MB or 8MB using 1Mx1 DRAM. The top two rows of chips make up bank 0, and the bottom two rows make up bank 1.

There is a set of five (5) two-pin jumpers in the lower left corner of the M200 memory card. They should be set as follows:

	W1	W2	W3	W4	W5	
4MB	ON	ON	OFF	OFF	OFF	
8MB	OFF	ON	OFF	OFF	OFF	
12MB	OFF	OFF	OFF	OFF	OFF	(with 4M-08)
16MB	OFF	OFF	OFF	OFF	OFF	(with 4M-08)

Recommended memory chips

Toshiba	TC511000P-85	1Mx1 page mode DRAM
NEC	D421000C-80	1Mx1 page mode DRAM
Samsung	KM41C1000P-80	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Intel	P21010-08	1Mx1 page mode DRAM

M300 memory card:
 =====

The M300 memory card can hold 1MB, 2MB, or 6MB. Each of the first two MB is made up of four (4) 256Kx1, and eight (8) 256Kx4 chips. The lower four rows of chips hold 1Mx1 chips, and must be filled in completely. It is not possible to partially fill the lower bank of memory.

There is a bank of eight (8) switches in the upper left corner of the M300 memory card. They should be set as follows:

	SW1.1	SW1.2	SW1.3	SW1.4	SW1.5	SW1.6	SW1.7	SW1.8	
1MB	OFF	OFF	OFF	OFF	ON	ON	OFF	ON	
2MB	OFF	OFF	ON	OFF	ON	ON	OFF	ON	
6MB	OFF	ON	ON	OFF	ON	ON	OFF	ON	
10MB	ON	ON	ON	OFF	ON	ON	OFF	ON	(with 4M-08)
14MB	ON	ON	ON	OFF	ON	ON	OFF	ON	(with 4M-08)

Recommended memory chips

Hyundai	HY53C256LS-80	256Kx1 page mode DRAM
NMB	AAA2801P-07	256Kx1 page mode DRAM
NMB	AAA2801P-08	256Kx1 page mode DRAM
Siemens	HYB514256A-80	256Kx4 page mode DRAM
Samsung	KM44C256AP-80	256Kx4 page mode DRAM
Toshiba	TC511000P-85	1Mx1 page mode DRAM
NEC	D421000C-80	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Intel	P21010-08	1Mx1 page mode DRAM

M100C memory card:
 =====

The M100C memory card can hold 1MB or 2MB. It has an Austek cache controller in the lower left corner of the card. It accommodates either the 2M-08, or the 4M-08.

NOTE: Static column DRAM (as opposed to page mode DRAM) is recommended when using either the 2M-08, or the 4M-08.

There are two jumpers on the M100C memory card. W1 is in the upper left corner, and W3 is in the lower left corner. They should be set as follows:

	W1	W3
1MB	Pin 1-2	ON
2MB	Pin 2-3	ON
4MB	Pin 2-3	ON (with 2M-08)
6MB	Pin 2-3	ON (with 4M-08)
10MB	Pin 2-3	ON (with 4M-08)

Recommended memory chips

```
-----  
Hitachi      HM51258P-8   256Kx1 static column DRAM  
NMB          AAA2800P-07  256Kx1 static column DRAM  
NMB          AAA2800P-08  256Kx1 static column DRAM  
Panasonic    MN41256A-08  256Kx1 page mode DRAM (see note above)  
Sharp        LH21256-08   256Kx1 page mode DRAM (see note above)  
NMB          AAA2801P-06  256Kx1 page mode DRAM (see note above)  
NMB          AAA2801P-08  256Kx1 page mode DRAM (see note above)
```

M400C memory card:

=====

The M400C memory card can hold 4MB or 8MB. It has an Austek cache controller in the lower left corner. The M400C cannot accommodate either of the memory expansion cards, as it has no connectors.

There are two jumpers on the M400C memory card. W1 is in the upper left corner, and W3 is in the lower left corner. They should be set as follows:

	W1	W3
4MB	Pin 1-2	ON
8MB	Pin 2-3	ON

Recommended memory chips

```
-----  
NEC          D421000C-80   1Mx1 page mode DRAM  
Motorola     MCM511000P-85 1Mx1 page mode DRAM  
Siemens      HYB511000-70   1Mx1 page mode DRAM  
Siemens      HYB511000-85   1Mx1 page mode DRAM  
Intel        P21010-08     1Mx1 page mode DRAM  
Samsung      KM41C1000P-80 1Mx1 page mode DRAM
```

2M-08 memory expansion board:

=====

The 2M-08 provides an additional 2MB, and is compatible with the M100, and M100C memory cards. It is not compatible with the M200, the M300, or the M400C. The 2M-08 comes populated, and has no jumpers or switches to set.

4M-08 memory expansion board:

=====

The 4M-08 provides an additional 4MB (expandable to 8MB) for the M100, M200, M300, and M100C memory cards. It is not compatible with the M400C. There is a bank of four (4) switches on the card. The settings differ for each of the main memory boards.

Recommended memory chips

Use the tables above for the 1Mx1 page mode DRAM chips used for the appropriate main memory card.

With the M100:

	S1	S2	S3	S4
6MB	ON	OFF	OFF	OFF
10MB	ON	OFF	ON	OFF

With the M200:

	S1	S2	S3	S4
12MB	OFF	ON	OFF	OFF
16MB	OFF	ON	ON	OFF

With the M300:

	S1	S2	S3	S4
10MB	ON	ON	OFF	OFF
14MB	ON	ON	ON	OFF

With the M100C:

	S1	S2	S3	S4
6MB	ON	OFF	OFF	OFF
10MB	ON	OFF	ON	OFF

This document is for the baby-sized (13.3" x 8.5") 80386-16 motherboard. It's identifying features are: an LED between expansion slots #5 and #6; a proprietary memory card slot #7; a bank of eight switches between slot #1 and the keyboard connector; two ROM sockets; 8-bit slots for #2 and #5; 16-bit slots for #1, #3, #4, #6, and #8; and a socket for an 80387 math coprocessor.

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+               +
+ MOTHERBOARD SWITCH SETTINGS +
+               +
+ * = Default setting          +
+=====+

```

Settings for Award Bios version C3.04

1	Reserved	*On
2	80387 Coprocessor installed	On
	80387 Coprocessor not installed	*Off
3	Reserved	*Off
4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On

	Monochrome video adapter	Off
7	Reserved	*Off
8	Cache enabled (w/M100C or M400C)	On
	Cache disabled	Off

Settings for Phoenix Bios version 1.10 03

1	Reserved	*On
2	80387 Coprocessor installed	On
	80387 Coprocessor not installed	*Off
3	Cache enabled (w/M100C or M400C)	On
	Cache disabled	Off
4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	Reserved	*Off
8	Reserved	*Off

Settings for Phoenix Bios version 1.10 05 and later

1	Reserved	*On
2	80387 Coprocessor installed	On
	80387 Coprocessor not installed	*Off
3	Reserved	*Off
4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	Cache enabled (w/M100C or M400C)	On
	Cache disabled	*Off
8	Reserved	*Off

```

+=====+
+               +
+ MOTHERBOARD JUMPER SETTINGS +
+               +
+=====+

```

J1 External 6-volt battery connector
 Pin 1 - Battery Positive
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Ground

J21 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

J22 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts

W1 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W3 Reserved
Pins 1-2

W9 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W10 Reserved
No connector

```
+=====+
+         +
+ MEMORY CARDS +
+         +
+=====+
```

M100 memory card:
=====

The M100 memory card can hold 1MB or 2MB. The first MB is usually soldered on the board.

NOTE: All of the memory on the M100 must be static column DRAM (as opposed to page mode DRAM) in order for the 2M-08, or 4M-08 to operate.

There is a row of nine (9) jumper pins in the lower left corner of the M100 memory card. They should be positioned as follows:

1MB Pin 2-3, Pin 4-5, Pin 7-8
2MB Pin 1-2, Pin 4-5, Pin 7-8
4MB Pin 1-2, Pin 4-5, Pin 7-8 (with 2M-08)
6MB Pin 1-2, Pin 4-5, Pin 7-8 (with 4M-08)
10MB Pin 1-2, Pin 4-5, Pin 7-8 (with 4M-08)

Recommended memory chips for the second MB

```
-----
```

Hitachi	HM51258P-8	256Kx1 static column DRAM
Hitachi	HM51258P-10	256Kx1 static column DRAM
Hitachi	HM51258P-12	256Kx1 static column DRAM
NMB	AAA2800P-07	256Kx1 static column DRAM
NMB	AAA2800P-08	256Kx1 static column DRAM
NMB	AAA2800P-10	256Kx1 static column DRAM
Panasonic	MN41256A-08	256Kx1 page mode DRAM (see note above)
Hyundai	HY53C256LS-80	256Kx1 page mode DRAM (see note above)
NMB	AAA2801P-08	256Kx1 page mode DRAM (see note above)
NMB	AAA2801P-10	256Kx1 page mode DRAM (see note above)

M200 memory card:

=====

The M200 memory card can hold 4MB or 8MB using 1Mx1 DRAM. The top two rows of chips make up bank 0, and the bottom two rows make up bank 1.

There is a set of five (5) two-pin jumpers in the lower left corner of the M200 memory card. They should be set as follows:

	W1	W2	W3	W4	W5	
4MB	ON	ON	OFF	OFF	OFF	
8MB	OFF	ON	OFF	OFF	OFF	
12MB	OFF	OFF	OFF	OFF	OFF	(with 4M-08)
16MB	OFF	OFF	OFF	OFF	OFF	(with 4M-08)

Recommended memory chips

Toshiba	TC511000P-85	1Mx1 page mode DRAM
Toshiba	TC511000P-10	1Mx1 page mode DRAM
Samsung	KM41C1000P-10	1Mx1 page mode DRAM
Samsung	KM41C1000P-80	1Mx1 page mode DRAM
Mitsubishi	M5M4100AP	1Mx1 page mode DRAM
Motorola	MCM511000P-10	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Intel	P21010-08	1Mx1 page mode DRAM
Intel	P21010-10	1Mx1 page mode DRAM

M300 memory card:

=====

The M300 memory card can hold 1MB, 2MB, or 6MB. Each of the first two MB is made up of four (4) 256Kx1, and eight (8) 256Kx4 chips. The lower four rows of chips hold 1Mx1 chips, and must be filled in completely. It is not possible to partially fill the lower bank of memory.

There is a bank of eight (8) switches in the upper left corner of the M300 memory card. They should be set as follows:

	SW1.1	SW1.2	SW1.3	SW1.4	SW1.5	SW1.6	SW1.7	SW1.8	
1MB	OFF	OFF	OFF	OFF	ON	ON	OFF	ON	
2MB	OFF	OFF	ON	OFF	ON	ON	OFF	ON	
6MB	OFF	ON	ON	OFF	ON	ON	OFF	ON	
10MB	ON	ON	ON	OFF	ON	ON	OFF	ON	(with 4M-08)
14MB	ON	ON	ON	OFF	ON	ON	OFF	ON	(with 4M-08)

Recommended memory chips

Hyundai	HY53C256LS-10	256Kx1 page mode DRAM
Hyundai	HY53C256LS-80	256Kx1 page mode DRAM
NMB	AAA2801P-07	256Kx1 page mode DRAM
NMB	AAA2801P-08	256Kx1 page mode DRAM
OKI	M514256-10	256Kx4 page mode DRAM
Fujitsu	MB81C4256-10P	256Kx4 page mode DRAM
Siemens	HYB514256A-80	256Kx4 page mode DRAM
Samsung	KM44C256AP-80	256Kx4 page mode DRAM
Toshiba	TC511000P-10	1Mx1 page mode DRAM
Toshiba	TC511000P-85	1Mx1 page mode DRAM
NEC	D421000C-80	1Mx1 page mode DRAM
Motorola	MCM511000P-10	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Samsung	KM41C1000P-10	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Mitsubishi	M5M4100AP	1Mx1 page mode DRAM

M100C memory card:
=====

The M100C memory card can hold 1MB or 2MB. It has an Austek cache controller in the lower left corner of the card. It accommodates either the 2M-08, or the 4M-08.

NOTE: Static column DRAM (as opposed to page mode DRAM) is recommended when using either the 2M-08, or the 4M-08.

There are two jumpers on the M100C memory card. W1 is in the upper left corner, and W3 is in the lower left corner. They should be set as follows:

	W1	W3
1MB	Pin 1-2	ON
2MB	Pin 2-3	ON
4MB	Pin 2-3	ON (with 2M-08)
6MB	Pin 2-3	ON (with 4M-08)
10MB	Pin 2-3	ON (with 4M-08)

Recommended memory chips

Hitachi	HM51258P-8	256Kx1 static column DRAM
NMB	AAA2800P-07	256Kx1 static column DRAM
NMB	AAA2800P-08	256Kx1 static column DRAM
Panasonic	MN41256A-08	256Kx1 page mode DRAM (see note above)
Sharp	LH21256-08	256Kx1 page mode DRAM (see note above)
NMB	AAA2801P-06	256Kx1 page mode DRAM (see note above)
NMB	AAA2801P-08	256Kx1 page mode DRAM (see note above)

M400C memory card:
=====

The M400C memory card can hold 4MB or 8MB. It has an Austek cache controller in the lower left corner. The M400C cannot accommodate either of the memory expansion cards, as it has no connectors.

There are two jumpers on the M400C memory card. W1 is in the upper left corner, and W3 is in the lower left corner. They should be set as follows:

	W1	W3
4MB	Pin 1-2	ON
8MB	Pin 2-3	ON

Recommended memory chips

NEC	D421000C-80	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Intel	P21010-08	1Mx1 page mode DRAM
Samsung	KM41C1000P-80	1Mx1 page mode DRAM

2M-08 memory expansion board:
=====

The 2M-08 provides an additional 2MB, and is compatible with the M100, and M100C memory cards. It is not compatible with the M200, the M300, or the M400C. The 2M-08 comes populated, and has no jumpers or switches to set.

4M-08 memory expansion board:
=====

The 4M-08 provides an additional 4MB (expandable to 8MB) for the M100, M200, M300, and M100C memory cards. It is not compatible with the M400C. There is a bank of four (4) switches on the card. The settings differ for each of the main memory boards.

Recommended memory chips

Use the tables above for the 1Mx1 page mode DRAM used for the appropriate main memory card.

With the M100:

	S1	S2	S3	S4
6MB	ON	OFF	OFF	OFF
10MB	ON	OFF	ON	OFF

With the M200:

	S1	S2	S3	S4
12MB	OFF	ON	OFF	OFF
16MB	OFF	ON	ON	OFF

With the M300:

	S1	S2	S3	S4
10MB	ON	ON	OFF	OFF
14MB	ON	ON	ON	OFF

With the M100C:

	S1	S2	S3	S4
6MB	ON	OFF	OFF	OFF
10MB	ON	OFF	ON	OFF

This document is for the baby-sized (13.3" x 8.5") 80386-16 motherboard. It's identifying features are: an LED between expansion slots #5 and #6; a proprietary memory card slot #7; a bank of eight switches between slot #1 and the keyboard connector; two ROM sockets; 8-bit slots for #2 and #5; 16-bit slots for #1, #3, #4, #6, and #8; and a socket for an 80387 math coprocessor.

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+                               +
+ MOTHERBOARD SWITCH SETTINGS +
+                               +
+ * = Default setting         +
+=====+

```

Settings for Award Bios version C3.04

1	Reserved	*On
2	80387 Coprocessor installed	On
	80387 Coprocessor not installed	*Off
3	Reserved	*Off
4	Bios relocation enabled	*On

	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	Reserved	*Off
8	Cache enabled (w/M100C or M400C)	On
	Cache disabled	Off

Settings for Phoenix Bios version 1.10 03

1	Reserved	*On
2	80387 Coprocessor installed	On
	80387 Coprocessor not installed	*Off
3	Cache enabled (w/M100C or M400C)	On
	Cache disabled	Off
4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	Reserved	*Off
8	Reserved	*Off

Settings for Phoenix Bios version 1.10 05 and later

1	Reserved	*On
2	80387 Coprocessor installed	On
	80387 Coprocessor not installed	*Off
3	Reserved	*Off
4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	Cache enabled (w/M100C or M400C)	On
	Cache disabled	*Off
8	Reserved	*Off

```

+=====+
+               +
+ MOTHERBOARD JUMPER SETTINGS +
+               +
+=====+

```

J1 External 6-volt battery connector

Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J21 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

J22 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts

W1 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W3 Reserved
Pins 1-2

W9 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W10 Reserved
No connector

```
+=====+  
+           +  
+ MEMORY CARDS +  
+           +  
+=====+
```

M100 memory card:
=====

The M100 memory card can hold 1MB or 2MB. The first MB is usually soldered on the board.

NOTE: All of the memory on the M100 must be static column DRAM (as opposed to page mode DRAM) in order for the 2M-08, or 4M-08 to operate.

There is a row of nine (9) jumper pins in the lower left corner of the M100 memory card. They should be positioned as follows:

1MB Pin 2-3, Pin 4-5, Pin 7-8
2MB Pin 1-2, Pin 4-5, Pin 7-8
4MB Pin 1-2, Pin 4-5, Pin 7-8 (with 2M-08)
6MB Pin 1-2, Pin 4-5, Pin 7-8 (with 4M-08)
10MB Pin 1-2, Pin 4-5, Pin 7-8 (with 4M-08)

Recommended memory chips for the second MB

```
-----  
Hitachi    HM51258P-8    256Kx1 static column DRAM  
Hitachi    HM51258P-10  256Kx1 static column DRAM  
Hitachi    HM51258P-12  256Kx1 static column DRAM  
NMB        AAA2800P-07    256Kx1 static column DRAM  
NMB        AAA2800P-08    256Kx1 static column DRAM  
NMB        AAA2800P-10    256Kx1 static column DRAM  
Panasonic  MN41256A-08    256Kx1 page mode DRAM (see note above)  
Hyundai    HY53C256LS-80  256Kx1 page mode DRAM (see note above)
```

NMB AAA2801P-08 256Kx1 page mode DRAM (see note above)
 NMB AAA2801P-10 256Kx1 page mode DRAM (see note above)

M200 memory card:
 =====

The M200 memory card can hold 4MB or 8MB using 1Mx1 DRAM. The top two rows of chips make up bank 0, and the bottom two rows make up bank 1.

There is a set of five (5) two-pin jumpers in the lower left corner of the M200 memory card. They should be set as follows:

	W1	W2	W3	W4	W5	
4MB	ON	ON	OFF	OFF	OFF	
8MB	OFF	ON	OFF	OFF	OFF	
12MB	OFF	OFF	OFF	OFF	OFF	(with 4M-08)
16MB	OFF	OFF	OFF	OFF	OFF	(with 4M-08)

Recommended memory chips

Toshiba	TC511000P-85	1Mx1 page mode DRAM
Toshiba	TC511000P-10	1Mx1 page mode DRAM
Samsung	KM41C1000P-10	1Mx1 page mode DRAM
Samsung	KM41C1000P-80	1Mx1 page mode DRAM
Mitsubishi	M5M4100AP	1Mx1 page mode DRAM
Motorola	MCM511000P-10	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Intel	P21010-08	1Mx1 page mode DRAM
Intel	P21010-10	1Mx1 page mode DRAM

M300 memory card:
 =====

The M300 memory card can hold 1MB, 2MB, or 6MB. Each of the first two MB is made up of four (4) 256Kx1, and eight (8) 256Kx4 chips. The lower four rows of chips hold 1Mx1 chips, and must be filled in completely. It is not possible to partially fill the lower bank of memory.

There is a bank of eight (8) switches in the upper left corner of the M300 memory card. They should be set as follows:

	SW1.1	SW1.2	SW1.3	SW1.4	SW1.5	SW1.6	SW1.7	SW1.8	
1MB	OFF	OFF	OFF	OFF	ON	ON	OFF	ON	
2MB	OFF	OFF	ON	OFF	ON	ON	OFF	ON	
6MB	OFF	ON	ON	OFF	ON	ON	OFF	ON	
10MB	ON	ON	ON	OFF	ON	ON	OFF	ON	(with 4M-08)
14MB	ON	ON	ON	OFF	ON	ON	OFF	ON	(with 4M-08)

Recommended memory chips

Hyundai	HY53C256LS-10	256Kx1 page mode DRAM
Hyundai	HY53C256LS-80	256Kx1 page mode DRAM
NMB	AAA2801P-07	256Kx1 page mode DRAM
NMB	AAA2801P-08	256Kx1 page mode DRAM
OKI	M514256-10	256Kx4 page mode DRAM
Fujitsu	MB81C4256-10P	256Kx4 page mode DRAM
Siemens	HYB514256A-80	256Kx4 page mode DRAM
Samsung	KM44C256AP-80	256Kx4 page mode DRAM
Toshiba	TC511000P-10	1Mx1 page mode DRAM
Toshiba	TC511000P-85	1Mx1 page mode DRAM
NEC	D421000C-80	1Mx1 page mode DRAM
Motorola	MCM511000P-10	1Mx1 page mode DRAM

Motorola	MCM511000P-85	1Mx1 page mode DRAM
Samsung	KM41C1000P-10	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Mitsubishi	M5M4100AP	1Mx1 page mode DRAM

M100C memory card:
 =====

The M100C memory card can hold 1MB or 2MB. It has an Austek cache controller in the lower left corner of the card. It accommodates either the 2M-08, or the 4M-08.

NOTE: Static column DRAM (as opposed to page mode DRAM) is recommended when using either the 2M-08, or the 4M-08.

There are two jumpers on the M100C memory card. W1 is in the upper left corner, and W3 is in the lower left corner. They should be set as follows:

	W1	W3	
1MB	Pin 1-2	ON	
2MB	Pin 2-3	ON	
4MB	Pin 2-3	ON	(with 2M-08)
6MB	Pin 2-3	ON	(with 4M-08)
10MB	Pin 2-3	ON	(with 4M-08)

Recommended memory chips

Hitachi	HM51258P-8	256Kx1 static column DRAM
NMB	AAA2800P-07	256Kx1 static column DRAM
NMB	AAA2800P-08	256Kx1 static column DRAM
Panasonic	MN41256A-08	256Kx1 page mode DRAM (see note above)
Sharp	LH21256-08	256Kx1 page mode DRAM (see note above)
NMB	AAA2801P-06	256Kx1 page mode DRAM (see note above)
NMB	AAA2801P-08	256Kx1 page mode DRAM (see note above)

M400C memory card:
 =====

The M400C memory card can hold 4MB or 8MB. It has an Austek cache controller in the lower left corner. The M400C cannot accommodate either of the memory expansion cards, as it has no connectors.

There are two jumpers on the M400C memory card. W1 is in the upper left corner, and W3 is in the lower left corner. They should be set as follows:

	W1	W3
4MB	Pin 1-2	ON
8MB	Pin 2-3	ON

Recommended memory chips

NEC	D421000C-80	1Mx1 page mode DRAM
Motorola	MCM511000P-85	1Mx1 page mode DRAM
Siemens	HYB511000-70	1Mx1 page mode DRAM
Siemens	HYB511000-85	1Mx1 page mode DRAM
Intel	P21010-08	1Mx1 page mode DRAM
Samsung	KM41C1000P-80	1Mx1 page mode DRAM

2M-08 memory expansion board:
 =====

The 2M-08 provides an additional 2MB, and is compatible with the M100, and M100C memory cards. It is not compatible with the M200, the M300, or the M400C. The 2M-08 comes populated, and has no jumpers or switches to set.

4M-08 memory expansion board:

=====

The 4M-08 provides an additional 4MB (expandable to 8MB) for the M100, M200, M300, and M100C memory cards. It is not compatible with the M400C. There is a bank of four (4) switches on the card. The settings differ for each of the main memory boards.

Recommended memory chips

Use the tables above for the 1Mx1 page mode DRAM used for the appropriate main memory card.

With the M100:

	S1	S2	S3	S4
6MB	ON	OFF	OFF	OFF
10MB	ON	OFF	ON	OFF

With the M200:

	S1	S2	S3	S4
12MB	OFF	ON	OFF	OFF
16MB	OFF	ON	ON	OFF

With the M300:

	S1	S2	S3	S4
10MB	ON	ON	OFF	OFF
14MB	ON	ON	ON	OFF

With the M100C:

	S1	S2	S3	S4
6MB	ON	OFF	OFF	OFF
10MB	ON	OFF	ON	OFF

This document is for the baby-sized (13.3" x 8.5") 80386-25 non-caching motherboard. It's identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; eight sockets for SIMMs (two banks of 4 each); a socket for an 80387 coprocessor; one 32-bit memory expansion slot (to be used with the M800 or M810 memory expansion card); the Micronics ASIC chipset (four chips).

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+                                     +
+ MOTHERBOARD SWITCH SETTINGS +
+                                     +
+   * = Default setting           +
+=====+

```

- 1 Reserved *Off
- 2 80387 Coprocessor installed On
80387 Coprocessor not installed *Off
- 3 Reserved *On

4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	Reserved	*Off
8	Reserved	*Off

```

+=====+
+               +
+ MOTHERBOARD JUMPER SETTINGS +
+               +
+=====+

```

J5 Keylock / Power LED
 Pin 1 - Power LED signal
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Keyboard lock signal
 Pin 5 - Ground

J9 External 6-volt battery connector
 Pin 1 - Battery Positive
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Ground

J701 External speaker
 Pin 1 - Speaker
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - +5 volts

W1 Reset switch
 Pin 1 - Signal
 Pin 2 - Ground

W4 Turbo LED
 Pin 1 - Signal
 Pin 2 - Ground

W5 Turbo switch
 Pin 1 - Signal
 Pin 2 - Ground

W98 Memory configuration
 Pin 1-2 Four 256Kx9 SIMMs installed in bank 0
 Pin 2-3 Four 1Mx9 SIMMs installed in bank 0

W100 Memory configuration
 Pin 1-2 Four 256Kx9 SIMMs installed in bank 1
 Pin 2-3 Four 1Mx9 SIMMs installed in bank 1

```

+=====+
+               +
+ MEMORY CARDS +
+               +
+=====+

```

M800 and M810 memory card:
=====

Either of these memory cards may be used on this motherboard to allow 4MB or 8MB to be added to the memory already installed on the motherboard. There are eight SIMM sockets on the memory card (two banks of 4 sockets), that will accept only 1Mx9 SIMMs. There are no switches or jumpers on the M800 or M810 to set.

This document is for the full-sized (13.3" x 12.025") 80386-33 caching motherboard.

It's identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; sixteen sockets for SIMMs (four banks of 4); a socket for a Weitek 3167 or Intel 80387 coprocessor; the Micronics ASIC chipset (four chips); two 9-pin serial port connectors; one 25-pin parallel port connector; one 16-bit IDE connector; one floppy connector.

The bus speed for this motherboard is fixed at 8MHz.

```
+=====+
+               +
+ MOTHERBOARD SWITCH SETTINGS +
+               +
+   * = Default setting       +
+=====+
```

SW1

1	Reserved	*On
2	80387 Coprocessor installed	On
	80387 Coprocessor not installed	*Off
3	Reserved	Off
4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	Cache enabled	*On
	Cache disabled	Off
8	Reserved	Off

SW2

1	COM1 Enabled (3F8-3FF)	*On
	COM1 Disabled	Off
2	COM2 Enabled (2F8-2FF)	*On
	COM2 Disabled	Off
3	IDE interface enabled	*On
	IDE interface disabled	Off
4	Floppy controller enabled	*On
	Floppy controller disabled	Off
5	Primary Floppy address (3F0-3F7)	*On
	Secondary Floppy address (2F0-2F7)	Off

- 6 Parallel port setting (See below)
- 7 Parallel port setting (See below)
- 8 Reserved *On

Parallel port settings

SW2.6	SW2.7	Parallel Port	Address	IRQ
ON	ON	LPT1	378-37F	7
OFF	ON	LPT2	278-27F	5
ON	OFF	LPT1	3B8-3BF	7
OFF	OFF	Port disabled		

```

+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+

```

J5 Keylock / Power LED
 Pin 1 - Power LED signal
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Keyboard lock signal
 Pin 5 - Ground

J6 External keyboard connector
 Pin 1 - Keyboard clock
 Pin 2 - Keyboard data
 Pin 3 - no connector
 Pin 4 - Ground
 Pin 5 - +5 volts DC

J8 External speaker
 Pin 1 - Speaker
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - +5 volts DC

J9 External 6-volt battery connector
 Pin 1 - Battery Positive
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Ground

J60 - Hard drive LED
 Pin 1 - Signal
 Pin 2 - Ground
 Pin 3 - Ground
 Pin 4 - Signal

W1 Reset switch
 Pin 1 - Signal
 Pin 2 - Ground

W2 Bios size
 Pin 1-2 512K
 Pin 2-3 256K (default)

W4 Turbo LED
 Pin 1 - Signal
 Pin 2 - Ground

W5 Turbo switch
 Pin 1 - Signal
 Pin 2 - Ground

W9 Non-cacheable region
 Pin 1-2 D00000-DFFFFFF
 No connection E00000-EFFFFFF

W10 Base memory size
 Pin 1-2 512KB
 No connection 640KB (default)

W14 Cache configuration
 Pin 1-2 Direct map (32KB)
 No connection Two-way set associative (64KB)

W15 Cache configuration
 Pin 1-2 Direct map (32KB)
 Pin 2-3 Two-way set associative (64KB)

W20 Reserved
 No connection

W500 Memory configuration
 Pin 1-2 256Kx9 SIMMs in Bank 0
 Pin 2-3 1Mx9 SIMMs in Bank 0

W501 Video BIOS cache
 No connection Video BIOS non-cacheable
 Pin 1-2 Video BIOS cacheable


W510 Memory configuration
 Pin 1-2 256Kx9 SIMMs in Bank 1
 Pin 2-3 1Mx9 SIMMs in Bank 1

W603 Reserved
 Not installed

W604 Reserved
 Pin 1-2

A note on the Serial port connectors:

=====
 There are two common pin-outs for 9-pin serial connectors. It is important to use the cables supplied with this board. If you do not have these original cables, make sure the cable is configured as follows:



The tenth pin is normally removed from the motherboard connector. This document is for the Mport 325 and Mport 333 Portable computers. This system is based on the Intel 80386-25 and 80386-33 CPUs respectively. It has a built-on video system based on the Cirrus Logic video chipset. It supports an external monitor, and has one 16-bit slot, which can accommodate a 2/3 length card. The backplane connector is exposed, to allow access like a desktop case for the card.

Up to 8MB is supported inside the unit, using 1Mx9 SIMMs. There are two serial and one parallel port. The parallel port connector can be used for a parallel device, or can be used to connect an external floppy drive.

The units come with either a 40MB Alps drive, or a 120MB Conner drive installed. One 3.5" 1.44MB floppy drive comes installed.

The video card comes with drivers for Windows 3.0, but not Windows 3.1. The drivers were written by Cirrus Logic. There are also drivers for AutoCAD release 10, GEM 3.x, Ventura 2.0, Lotus 1-2-3 version 2.xx, and Lotus Symphony. The built-in display has a 640x480 VGA Monochrome screen supporting 16 levels of gray.

```

+=====+
+          +
+ SWITCH SETTINGS      +
+          +
+ * = Default setting +
+=====+

SW1  Serial A enabled      *UP
      Serial A disabled    DOWN

SW2  Serial B enabled      *UP
      Serial B disabled    DOWN

SW3  PRT (parallel) enabled *UP
      PRT (parallel) disabled DOWN

SW4  Turns on LCD display  *UP
      Turns off LCD display DOWN

SW5  80387 not installed   *UP
      80387 installed      DOWN

SW6  Video controller disable *DOWN

SW7  Speaker volume high   UP
      Speaker volume low   *DOWN

```

A/B/PRT switch settings

```

=====
Switch      Drive A:   Drive B:   Printer
-----
LEFT        External  Internal   Disabled
            Floppy    Floppy
-----
MIDDLE      Internal  External   Disabled
            Floppy    Floppy
-----
RIGHT       Internal  N/A        Enabled  *!!!! DEFAULT
(Default)   Floppy
-----

```

Serial A and B Pin-outs

```

=====
Pin  Signal  Description
----  -
1    DCD     Data carrier detect
2    RXD     Receive data
3    TXD     Transmit data
4    DTR     Data terminal ready
5    GND     Signal ground
6    DSR     Data set ready
7    RTS     Request to send
8    CTS     Clear to send
9    RI     Ring initiate

```

Parallel Port Pin-out

```
=====
Pin   Signal   Description
----  -
1     STBP*     Strobe
2     DP0       Data bit 0
3     DP1       Data bit 1
4     DP2       Data bit 2
5     DP3       Data bit 3
6     DP4       Data bit 4
7     DP5       Data bit 5
8     DP6       Data bit 6
9     DP7       Data bit 7
10    ACKP*     Acknowledge
11    BUSYP     Busy
12    PEP       Out of paper
13    SLCTP     Printer selected
14    AFDP*     Auto feed
15    ERRD*     Error
16    INITP*    Initialize
17    SLINP     Select input
18    GND       Ground
19    GND       Ground
20    GND       Ground
21    GND       Ground
22    GND       Ground
23    GND       Ground
24    GND       Ground
25    GND       Ground
```

External Floppy Disk Drive Port

```
=====
Pin   Signal           Description
----  -
1     N/C               No connection
2     INDEX
3     TRACK-00
4     WR-PROTECT       Write protect
5     RD-DATA           Read data
6     DSKCHANG          Diskette change
7     N/C               No connection
8     N/C               No connection
9     N/C               No connection
10    DRV2             Drive select 2
11    MOTOR2           Motor enable 2
12    WR-DATA           Write data
13    WR-GATE           Write enable
14    NLL              High density select
15    SIDE-1-SEL       Head 1 select
16    DIRECTION
17    STEP
18    GND              Ground
19    GND              Ground
20    GND              Ground
21    GND              Ground
22    GND              Ground
23    GND              Ground
24    GND              Ground
25    GND              Ground
```

External VGA Port

```
=====
Pin   Signal   Description
----  -
```

1	AR	Red
2	AG	Green
3	AB	Blue
4	MS2	Monitor sense 2
5	GND	Ground
6	GND	Ground
7	GND	Ground
8	GND	Ground
9	N/C	No connection
10	GND	Ground
11	MS0	Monitor sense 0
12	MS1	Monitor sense 1
13	HSYNC	Horizontal sync
14	VSYNC	Vertical sync
15	N/C	No connection

External Keyboard Port

=====

Pin	Signal	Description
---	-----	-----
1	KBCLK	Keyboard clock
2	KEYDAT	Keyboard data
3	N/C	No connection
4	GND	Ground
5	+5V	Power +5V
Shield	GND	Case ground

Game Port

=====

Pin	Signal	Description
---	-----	-----
1	+5VDC	+5V DC
2	Button4	Button1 / Joystick1
3	Position0	X-axis / Joystick1
4	GND	Ground
5		
6	Position1	Y-axis / Joystick1
7	Button5	Button2 / Joystick1
8	+5VDC	+5V DC
9	+5VDC	+5V DC
10	Button6	Button1 / Joystick2
11	Position2	X-axis / Joystick2
12	GND	Ground
13	Position3	Y-axis / Joystick2
14	Button7	Button2 / Joystick2
15	+5VDC	+5V DC

Hot-key combinations

=====

Keystroke	Description
-----	-----
<Ctrl><Alt>	Warm boots the system
<Fn><F3> or <Ctrl><Alt><F3>	Enters CMOS setup
<Fn><F4> or <Ctrl><Alt><F4>	Toggles reverse video
<Fn><F6> or <Ctrl><Alt><F6>	Toggles text mode attribute emulation
<Fn><F7> or <Ctrl><Alt><F7>	Toggles bold font for intensified text

<Fn><F8> or
 <Ctrl><Alt><F8> Toggles expanded mode

<Fn><F9> or
 <Ctrl><Alt><F9> Toggles CPU speed between 6MHz, 8MHz, and Full-speed

<Fn><F10> or
 <Ctrl><Alt><F10> Toggles internal VGA add-in board

<Ctrl><Break> Stops a software operation

<Ctrl><C> Stops a software operation that you are currently performing

<Ctrl><S> Pauses the screen output. Press any other key to resume.

<Fn> Enables keypad overlay when held down

<Fn><Numlock> Toggles numeric keypad on/off

This document is for the baby-sized (13.3" x 8.5") 80386SX-25 caching motherboard. It's identifying features are: an LED between expansion slots #5 and #6; six 16-bit expansion slots; eight sockets for SIMMs (four banks of 2); a socket for an 80387SX coprocessor.

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+                               +
+ MOTHERBOARD JUMPER SETTINGS +
+                               +
+=====+
  
```

J6 COM2

J8 COM1

J9 Parallel port

J19 IDE interface

J20 Floppy interface

J21 Hard disk LED

W1 Monitor type
 Not connected Monochrome video card
 Pins 1-2 Color video card

W2 Reserved
 Not connected

W3 Reserved
 Not connected

W4 CMOS memory
 Pins 1-2 Battery backed-up CMOS (default)
 Pins 2-3 Clear CMOS memory

W5 Memory type
 Pins 2-3 4Mx9 SIMMs installed
 Pins 1-2 and 3-4 4Mx9 SIMMs not installed

W6 Reserved
 Not connected

E2 Reset switch
 Pin 1 - Signal

Pin 2 - Ground

P3 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

P4 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

```
+=====+
+               +
+ MEMORY CONFIGURATION +
+               +
+=====+
```

Listed below are the possible memory configurations

Size in MB	Bank 0	Bank 1	Bank 2	Bank 3
1.0	256K	256K		
1.5	256K	256K	256K	
2.0	256K	256K	256K	256K
3.0	256K	256K	1MB	
4.0	1MB	1MB		
6.0	1MB	1MB	1MB	
8.0	1MB	1MB	1MB	1MB
9.0	256K	256K	4MB	
10.0	1MB	4MB		
16.0	4MB	4MB		

256K = Two 256Kx9 SIMMs in the bank
1MB = Two 1Mx9 SIMMs in the bank
4MB = Two 4Mx9 SIMMs in the bank

This document is for the mini-sized (23.0cm x 21.5cm) 386SX-25 non-cached motherboard.
The part number for this board is 09-00140-xx.

It's identifying features are: an LED between expansion slots #5 and #6; six 16-bit expansion slots, and two 8-bit expansion slots; eight sockets for SIMMs (four banks of 2);
a socket for a 80387SX coprocessor.

The bus speed for this motherboard is fixed at 8MHz.

```
+=====+
+               +
+ MOTHERBOARD JUMPER SETTINGS +
+               +
+=====+
```

Jumper J2 is used to configure the battery backup method. To use the on-board battery, place a jumper block connecting pins 2-3. If you wish to connect an external battery, pin 1 is the battery positive lead, and pin 4 is for battery negative.

You can clear the contents of the CMOS memory by placing a jumper block connecting pins 3-4, then turning on the power. Turn off the power, configure the jumper for either the on-board or external battery, and turn the power back on. The system will act as if it has never been turned on before.

JP2 Video type
Pins 1-2 Color video card installed
Not connected Monochrome video card installed

```
+=====+  
+ +  
+ MEMORY CONFIGURATION +  
+ +  
+=====+
```

Listed below are the possible memory configurations

Size in MB	Bank 0	Bank 1	Bank 2	Bank 3
0.5	256K			
1.0	256K	256K		
1.5	256K	256K	256K	
2.0	256K	256K	256K	256K
2.0	1MB			
2.5	256K	1MB		
3.0	256K	256K	1MB	
4.0	1MB	1MB		
4.5	256K	1MB		
5.0	256K	1MB		
6.0	1MB	1MB	1MB	
8.0	1MB	1MB	1MB	1MB
8.0	4MB			
8.5	256K	4MB		
9.0	256K	256K	4MB	
10.0	1MB	4MB		
12.0	1MB	1MB	4MB	
16.0	4MB	4MB		

256K = Two 256Kx9 SIMMs in the bank

1MB = Two 1Mx9 SIMMs in the bank

4MB = Two 4Mx9 SIMMs in the bank

This document is for the baby-sized (8.5" x 13.3") 386SX-20 and 386SX-25 non-cached motherboard. The part number for this board is 09-00105-xx.

It's identifying features are: an LED between expansion slots #5 and #6; six 16-bit expansion slots, and two 8-bit expansion slots; eight sockets for SIMMs (four banks of 2);
a socket for a 80387SX coprocessor.

The bus speed for this motherboard is fixed at 8MHz.

```
+=====+  
+ +  
+ MOTHERBOARD JUMPER SETTINGS +  
+ +  
+=====+
```

J1 External keyboard connector
Pin 1 - Keyboard clock
Pin 2 - Keyboard data
Pin 3 - no connector
Pin 4 - Ground
Pin 5 - +5 volts DC

J13 Monitor type
Not connected Color video card
Connected Monochrome video card

J14 Coprocessor configuration

Pins 1-2 Coprocessor installed
 Not connected Coprocessor not installed

J15 80386 Pipeline configuration
 Connected 80386 pipeline access
 Not connected 80386 non-pipeline access

J24 External 6-volt battery connector
 Pin 1 - Battery Positive
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Ground

J28 Turbo switch
 Pin 1 - Signal
 Pin 2 - Ground

J29 Turbo LED
 Pin 1 - Signal
 Pin 2 - Ground

J30 Reset switch
 Pin 1 - Signal
 Pin 2 - Ground

J31 External speaker
 Pin 1 - Speaker
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - +5 volts DC

J32 Keylock / Power LED
 Pin 1 - Power LED signal
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Keyboard lock signal
 Pin 5 - Ground

```

+=====+
+           +
+  MEMORY CONFIGURATION  +
+           +
+=====+
  
```

Listed below are the possible memory configurations

Size in MB	Bank 0	Bank 1	Bank 2	Bank 3
0.5	256K			
1.0	256K	256K		
1.5	256K	256K	256K	
2.0	256K	256K	256K	256K
2.0	1MB			
2.5	256K	1MB		
3.0	256K	256K	1MB	
4.0	1MB	1MB		
4.5	256K	1MB		
5.0	256K	1MB		
6.0	1MB	1MB	1MB	
8.0	1MB	1MB	1MB	1MB
8.0	4MB			
8.5	256K	4MB		
9.0	256K	256K	4MB	
10.0	1MB	4MB		

12.0 1MB 1MB 4MB
16.0 4MB 4MB

256K = Two 256Kx9 SIMMs in the bank
1MB = Two 1Mx9 SIMMs in the bank
4MB = Two 4Mx9 SIMMs in the bank

This is the list of Switcher Functions for the Mpack laptop computers:

<Ctrl><Shift><A> Toggle automap
<Ctrl><Shift> Toggle bold
<Ctrl><Shift><C> Toggle centering choices
<Ctrl><Shift><D> Toggle between CRT and flat-panel display
<Ctrl><Shift><E> Toggle between expanded and normal flat-panel display
<Ctrl><Shift><F> Toggle between color and monochrome
<Ctrl><Shift><G> Toggle reverse video in graphics
<Ctrl><Shift><R> Toggle reverse video
<Ctrl><Shift><S> Toggle screen power
<Ctrl><Shift><W> Toggle flat-panel width-compression options

The program SWITCHER.COM must be executed prior to pressing any of the above keystrokes.

CALL ATP @408-732-7093
EVEREX @

SANYO/FISCHER 310-537-5830 CUSTOMER SERVICE FOR PARTS

This document is for the baby-sized (13.3" x 8.5") 80386-25 and 80386-33 caching motherboard.

It's identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; four sockets for SIMMs (one bank of 4); a socket for an 80387 coprocessor.

The bus speed for this motherboard is fixed at 8MHz.

```
+=====+  
+                               +  
+ MOTHERBOARD SWITCH SETTINGS +  
+                               +  
+ * = Default setting          +  
+=====+
```

1	Reserved	*On
2	80387 Coprocessor installed	On
	80387 Coprocessor not installed	*Off
3	Bus speed selection (see below)	
4	Bios relocation enabled	*On
	Bios relocation disabled	Off
5	Reserved	*Off
6	Color video adapter	*On
	Monochrome video adapter	Off
7	Cache enabled	*On
	Cache disabled	Off
8	Bus speed selection (see below)	

Bus speed selection

Switch settings -- * = default

Board SW1.3=OFF SW1.3=ON SW1.3=ON SW1.3=OFF

Speed	SW1.8=OFF	SW1.8=OFF	SW1.8=ON	SW1.8=ON
-----	-----	-----	-----	-----
25MHz	6.25 Mhz	8.33 Mhz*	12.5 Mhz	Undefined
33MHz	8.33 Mhz*	11.33 Mhz	16.66 Mhz	Undefined

WARNING! Many cards are not able to run at a faster bus speed.

```

+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+

```

J5 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

J6 External keyboard connector
Pin 1 - Keyboard clock
Pin 2 - Keyboard data
Pin 3 - no connector
Pin 4 - Ground
Pin 5 - +5 volts DC

J8 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J9 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

W1 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W4 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W5 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W9 Non-cacheable region
Pin 1-2 D00000-DFFFFFF
No connection E00000-EFFFFFF

W14 Cache configuration
Pin 1-2 Direct map (32KB)
No connection Two-way set associative (64KB)

W15 Cache configuration
Pin 1-2 Direct map (32KB)
Pin 2-3 Two-way set associative (64KB)

W98 Memory configuration
Pin 1-2 Four 1Mx9 SIMMs installed

Pin 2-3 Four 256Kx9 SIMMs installed

```
+=====+
+           +
+ MEMORY CARDS +
+           +
+=====+
```

M710 memory card:
=====

This memory card may be used on this motherboard to allow up to 12MB to be added to the memory already installed on the motherboard. There are sixteen (16) SIMM sockets on the memory card (four banks of 4 sockets). The first two banks of memory can accept 256Kx9 SIMMs, or 1Mx9 SIMMs. The second two banks of memory can only accept 1Mx9 SIMMs. The four banks of memory are numbered zero, one, two, and three. Bank zero on the M710 uses the same addresses as bank zero on the motherboard (the four sockets on the motherboard). Therefore, if the motherboard memory sockets are populated, bank zero on the M710 must be left empty (or that memory will not be recognized).

There are four jumpers on the M710, which configures the type of memory installed in each of the four banks of memory. They are set as follows:

- W1 Pin 1-2 Four 1Mx9 SIMMs in bank 0 (or when empty)
Pin 2-3 Four 256Kx9 SIMMs in bank 0
W2 Pin 1-2 Four 1Mx9 SIMMs in bank 1 (or when empty)
Pin 2-3 Four 256Kx9 SIMMs in bank 1
W3 Pin 1-2 Four 1Mx9 SIMMs in bank 2 (or when empty)
W4 Pin 2-3 Four 1Mx9 SIMMs in bank 3 (or when empty)

This document is for the baby-sized (13.3" x 8.5") Baby Gemini 486-50 motherboard. The part number for this board is 09-00125-xx.

It's identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; eight sockets for SIMMs (two banks of 4); a socket for a Weitek 4167 coprocessor; one proprietary 32-bit slot which accommodates the M810 (a memory expansion card with eight sockets for SIMMs).

The bus speed for this motherboard is fixed at 8MHz.

```
+=====+
+           +
+ MOTHERBOARD SWITCH SETTINGS +
+           +
+ * = Default setting          +
+=====+
```

SW1

- 1 Reserved *Off
2 Reserved *Off
3 Reserved *On
4 Reserved *Off
5 Reserved *Off
6 Reserved *Off
7 Reserved *On
8 Reserved *Off

SW2

- 1 Memory size (see below)
2 Memory size (see below)

- 3 Memory size (see below)
- 4 Memory size (see below)
- 5 Memory size (see below)

- 6 Reserved *Off
- 7 Reserved *Off

- 8 64K external cache Off
- 256K external cache On

DIP switch settings for memory size

```

=====
Memory           Banks                DIP Switch 2
-----
MB      0      1      2      3      S1      S2      S3      S4      S5
-----
1MB     256K
2MB     256K 256K
3MB     256K 256K 256K
4MB     256K 256K 256K 256K
4MB     1MB
5MB     256K 1MB
6MB     256K 256K 1MB
7MB     256K 256K 256K 1MB
8MB     1MB 1MB
9MB     256K 1MB 1MB
10MB    256K 256K 1MB 1MB
12MB    1MB 1MB 1MB
13MB    256K 1MB 1MB 1MB
16MB    1MB 1MB 1MB 1MB
16MB    4MB
20MB    1MB 4MB
24MB    1MB 1MB 4MB
28MB    1MB 1MB 1MB 4MB
32MB    4MB 4MB
36MB    1MB 4MB 4MB
40MB    1MB 1MB 4MB 4MB
48MB    4MB 4MB 4MB
52MB    1MB 4MB 4MB 4MB
64MB    4MB 4MB 4MB 4MB
=====

```

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

Please note that Bank 0 and Bank 1 are on the motherboard. Banks 2 and 3 are found on the M810. Each bank consists of four SIMMs, and all four sockets within a bank must be filled.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F00000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```

+=====+
+                               +
+ MOTHERBOARD JUMPER SETTINGS +
+                               +
+=====+

```


+=====+

SW1

- 1 Reserved *Off
- 2 Reserved *Off
- 3 Reserved *Off
- 4 Reserved *Off
- 5 Reserved *Off
- 6 Reserved *Off

- 7 Video Bios cacheable *Off
Video Bios non-cacheable On

- 8 Reserved *Off

SW2

- 1 Memory size (See below)
- 2 Memory size (See below)
- 3 Memory size (See below)
- 4 Memory size (See below)
- 5 Memory size (See below)

- 6 80ns DRAM installed On
70ns DRAM installed *Off

- 7 64K or 256K cache Off
128K cache On

- 8 64K cache Off
128K or 256K cache On

DIP switch settings for memory size

=====

Memory	Banks				DIP Switch 2				
	0	1	2	3	S1	S2	S3	S4	S5
1MB	256K				ON	ON	ON	ON	ON
2MB	256K	256K			OFF	ON	ON	ON	ON
3MB	256K	256K	256K		ON	OFF	ON	ON	ON
4MB	256K	256K	256K	256K	OFF	OFF	ON	ON	ON
4MB	1MB				ON	ON	OFF	ON	ON
5MB	256K	1MB			ON	ON	OFF	OFF	ON
6MB	256K	256K	1MB		ON	OFF	ON	OFF	ON
7MB	256K	256K	256K	1MB	OFF	ON	ON	OFF	ON
8MB	1MB	1MB			OFF	ON	OFF	ON	ON
9MB	256K	1MB	1MB		ON	OFF	OFF	OFF	ON
10MB	256K	256K	1MB	1MB	OFF	OFF	ON	OFF	ON
12MB	1MB	1MB	1MB		ON	OFF	OFF	ON	ON
13MB	256K	1MB	1MB	1MB	OFF	OFF	OFF	OFF	ON
16MB	1MB	1MB	1MB	1MB	OFF	OFF	OFF	ON	ON
16MB	4MB				ON	ON	OFF	ON	OFF
20MB	1MB	4MB			ON	ON	OFF	OFF	OFF
24MB	1MB	1MB	4MB		ON	OFF	ON	OFF	OFF
28MB	1MB	1MB	1MB	4MB	OFF	ON	ON	OFF	OFF
32MB	4MB	4MB			OFF	ON	OFF	ON	OFF
36MB	1MB	4MB	4MB		ON	OFF	OFF	OFF	OFF
40MB	1MB	1MB	4MB	4MB	OFF	OFF	ON	OFF	OFF
48MB	4MB	4MB	4MB		ON	OFF	OFF	ON	OFF
52MB	1MB	4MB	4MB	4MB	OFF	OFF	OFF	OFF	OFF
64MB	4MB	4MB	4MB	4MB	OFF	OFF	OFF	ON	OFF

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory

configurations.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F0000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```
+=====+
+                               +
+ MOTHERBOARD JUMPER SETTINGS +
+                               +
+=====+
```

J13 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J30 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J31 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W4 Reserved
Pins 1-2

W5 Cache configuration
Installed - 128K or 256K
Not installed - 64K

W6 Cache configuration
Installed - 256K
Not installed - 64K or 128K

W7 Reserved

W9 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W10 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W11 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

This document is for the baby-sized (13.3" x 8.5") Baby Gemini 386-33 motherboard.
The part number for this board is 09-00086-xx.

It's identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; eight sockets for SIMMs (two banks of 4); a socket for a Weitek 3167

or Intel 80387 coprocessor; one proprietary 32-bit slot which accommodates the M810 (a memory expansion card with eight sockets for SIMMs).

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+           +
+ MOTHERBOARD SWITCH SETTINGS +
+           +
+ * = Default setting         +
+=====+

```

SW1

```

1 Memory size (see below)
2 Memory size (see below)
3 Memory size (see below)
4 Memory size (see below)
5 Memory size (see below)
6 Reserved          *On
7 Reserved          *Off

8 33MHz system board *On
  40MHz system board Off

```

SW2

```

1 Reserved          *Off

2 33MHz system board *On
  40MHz system board Off

3 Reserved          *Off
4 Reserved          *Off
5 Reserved          *Off
6 Reserved          *Off
7 Reserved          *Off
8 Reserved          *Off

```

NOTE: The system board is configured at the factory for either the 80386-33 or the 80386-40. It is not possible to change the CPU by configuring the switches.

DIP switch settings for memory size

```

=====
Memory          Banks          DIP Switch 1
-----
MB             0      1      2      3      S1     S2     S3     S4     S5
-----
1MB           256K
2MB           256K 256K
3MB           256K 256K 256K
4MB           256K 256K 256K 256K
4MB           1MB
5MB           256K 1MB
6MB           256K 256K 1MB
7MB           256K 256K 256K 1MB
8MB           1MB 1MB
9MB           256K 1MB 1MB
10MB          256K 256K 1MB 1MB
12MB          1MB 1MB 1MB
13MB          256K 1MB 1MB 1MB
16MB          1MB 1MB 1MB 1MB
16MB          4MB
20MB          1MB 4MB
24MB          1MB 1MB 4MB
28MB          1MB 1MB 1MB 4MB

```

Memory	Banks	DIP Switch 1							
MB	0	1	2	3	S1	S2	S3	S4	S5
1MB	256K				ON	ON	ON	ON	ON
2MB	256K	256K			OFF	ON	ON	ON	ON
3MB	256K	256K	256K		ON	OFF	ON	ON	ON
4MB	256K	256K	256K	256K	OFF	OFF	ON	ON	ON
4MB	1MB				ON	ON	OFF	ON	ON
5MB	256K	1MB			ON	ON	OFF	OFF	ON
6MB	256K	256K	1MB		ON	OFF	ON	OFF	ON
7MB	256K	256K	256K	1MB	OFF	ON	ON	OFF	ON
8MB	1MB	1MB			OFF	ON	OFF	ON	ON
9MB	256K	1MB	1MB		ON	OFF	OFF	OFF	ON
10MB	256K	256K	1MB	1MB	OFF	OFF	ON	OFF	ON
12MB	1MB	1MB	1MB		ON	OFF	OFF	ON	ON
13MB	256K	1MB	1MB	1MB	OFF	OFF	OFF	OFF	ON
16MB	1MB	1MB	1MB	1MB	OFF	OFF	OFF	ON	ON
16MB	4MB				ON	ON	OFF	ON	OFF
20MB	1MB	4MB			ON	ON	OFF	OFF	OFF
24MB	1MB	1MB	4MB		ON	OFF	ON	OFF	OFF
28MB	1MB	1MB	1MB	4MB	OFF	ON	ON	OFF	OFF

32MB	4MB	4MB			OFF	ON	OFF	ON	OFF
36MB	1MB	4MB	4MB		ON	OFF	OFF	OFF	OFF
40MB	1MB	1MB	4MB	4MB	OFF	OFF	ON	OFF	OFF
48MB	4MB	4MB	4MB		ON	OFF	OFF	ON	OFF
52MB	1MB	4MB	4MB	4MB	OFF	OFF	OFF	OFF	OFF
64MB	4MB	4MB	4MB	4MB	OFF	OFF	OFF	ON	OFF

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

Please note that Bank 0 and Bank 1 are on the motherboard. Banks 2 and 3 are found on the M810. Each bank consists of four SIMMs, and all four sockets within a bank must be filled.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F0000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```

+=====+
+               +
+ MOTHERBOARD JUMPER SETTINGS +
+               +
+=====+

```

J13 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J23 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J24 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W3 Reserved
Not installed

W6 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W7 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W8 Reset switch
Pin 1 - Signal
Pin 2 - Ground

This document is for the full-sized (13.3" x 12.025") 80486DX-33, 80486DX-50, and 80486DX2-66 EISA motherboard. The part number for this board is 09-00117-xx.

Its identifying features are: an LED between expansion slots #5 and #6; eight 32-bit expansion slots; sixteen sockets for SIMMs (four banks of 4); a socket for a Weitek 4167 coprocessor; one proprietary 32-bit slot which accommodates the MVC32LB (a video card based on the ATI Mach 32 chip).

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+           +
+ MOTHERBOARD SWITCH SETTINGS +
+           +
+ * = Default setting         +
+=====+

```

- 1 Memory size (see below)
- 2 Memory size (see below)
- 3 Memory size (see below)
- 4 Memory size (see below)
- 5 Memory size (see below)

- 6 Reserved *On
- 7 Reserved *Off

- 8 Color video adapter *On
 Mono video adapter Off

DIP switch settings for memory size

```

=====
Memory                   Banks                   DIP Switch 2
-----
MB           0    1    2    3    S1   S2   S3   S4   S5
-----
1MB    256K
2MB    256K 256K
3MB    256K 256K 256K
4MB    256K 256K 256K 256K
4MB    1MB
5MB    256K 1MB
6MB    256K 256K 1MB
7MB    256K 256K 256K 1MB
8MB    1MB 1MB
9MB    256K 1MB 1MB
10MB   256K 256K 1MB 1MB
12MB   1MB 1MB 1MB
13MB   256K 1MB 1MB 1MB
16MB   1MB 1MB 1MB 1MB
16MB   4MB
20MB   1MB 4MB
24MB   1MB 1MB 4MB
28MB   1MB 1MB 1MB 4MB
32MB   4MB 4MB
36MB   1MB 4MB 4MB
40MB   1MB 1MB 4MB 4MB
48MB   4MB 4MB 4MB
52MB   1MB 4MB 4MB 4MB
64MB   4MB 4MB 4MB 4MB

```

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F00000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```
+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+
```

J2 Keyboard connector

- Pin 1 - Keyboard clock
- Pin 2 - Keyboard data
- Pin 3 - no connector
- Pin 4 - Ground
- Pin 5 - +5 volts DC

J17 External 6-volt battery connector

- Pin 1 - Battery Positive
- Pin 2 - no connector
- Pin 3 - Ground
- Pin 4 - Ground

J22 External speaker

- Pin 1 - Speaker
- Pin 2 - no connector
- Pin 3 - Ground
- Pin 4 - +5 volts DC

J23 Keylock / Power LED

- Pin 1 - Power LED signal
- Pin 2 - no connector
- Pin 3 - Ground
- Pin 4 - Keyboard lock signal
- Pin 5 - Ground

W5 Reset switch

- Pin 1 - Signal
- Pin 2 - Ground

W6 Turbo switch

- Pin 1 - Signal
- Pin 2 - Ground

W7 Turbo LED

- Pin 1 - Signal
- Pin 2 - Ground

W11 Reserved

Pins 2-3

W12 Reserved

Pins 1-2

W13 Floppy Drive

- Pins 1-2 -- Enables on-board floppy drive
- Pins 2-3 -- Disables on-board floppy drive

W45 Reserved

Pins 1-2

W43 CPU selection

Pins 1-2 486DX2-50
Not installed 486DX-33

NOTE: The system board is configured at the factory for either the 486DX-33 or the 486DX2-50.

It is not possible to switch the 486DX-33 to the 486DX2-50 (or vice versa) by configuring the jumpers.

Serial Port configuration

I/O addresses

COM1 = 3F8-3FFh
COM2 = 2F8-2FFh

COM1	COM2	W2	W8	W9
Enabled	Enabled	1-2	1-2	1-2
Enabled	Disabled	1-2	1-2	2-3
Disabled	Enabled	2-3	1-2	1-2
Disabled	Disabled	2-3	1-2	2-3

Parallel Port configuration

Port	I/O address	W3	W4	W10
LPT1	3BC-3BEh	1-2	2-3	2-3
LPT2	378-37Ah	1-2	1-2	2-3
LPT3	278-27Ah	2-3	1-2	2-3
Disabled		2-3	2-3	2-3

Cache configuration

Cache	W20	W21	W41	W44
64K	N/C	N/C	N/C	2-3
256K	1-2	1-2	1-2	1-2

N/C = Not Connected

This document is for the full-sized (13.3" x 12.025") 80486DX-25, 80486DX-33 EISA motherboard. The part number for this board is 09-00090-xx.

It's identifying features are: an LED between expansion slots #5 and #6; eight 32-bit expansion slots; sixteen sockets for SIMMs (four banks of 4); a socket for a Weitek 4167 coprocessor.

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+                                     +
+ MOTHERBOARD SWITCH SETTINGS +
+                                     +
+ * = Default setting +
+=====+

```

SW1

```

1 External cache not invalidated *Off
  External cache invalidated      On

2 On board Bios enabled          *Off
  On board Bios disabled          On

3 64K external cache             Off
  128K or 256K external cache    On

4 33MHz system                   Off
  25MHz system                   On

5 Reserved                       *Off

6 Reserved                       *Off

7 CGA / EGA / VGA                On
  Monochrome                     Off

8 128K external cache            On
  64K or 256K external cache    Off

```

SW2

```

---
1 Memory settings (see below)
2 Memory settings (see below)
3 Memory settings (see below)
4 Memory settings (see below)
5 Memory settings (see below)

6 Cache video Bios               *Off
  Don't cache video Bios         On

7 Cache D00000-EFFFFFF region    *On
  Don't cache D00000-EFFFFFF     Off

8 Reserved                       *Off

```

DIP switch settings for memory size

```

=====
Memory          Banks          DIP Switch 2
-----
MB             0      1      2      3      S1     S2     S3     S4     S5
-----
4MB            1MB
8MB            1MB  1MB
12MB           1MB  1MB  1MB
16MB           1MB  1MB  1MB  1MB
16MB           4MB
20MB           1MB  4MB
24MB           1MB  1MB  4MB
28MB           1MB  1MB  1MB  4MB
32MB           4MB  4MB
36MB           1MB  4MB  4MB
40MB           1MB  1MB  4MB  4MB
48MB           4MB  4MB  4MB
52MB           1MB  4MB  4MB  4MB
64MB           4MB  4MB  4MB  4MB

```

In the table above, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into

RAM. The motherboard adds 15MB to these addresses (F00000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```
+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+
```

J2 Keyboard connector
Pin 1 - Keyboard clock
Pin 2 - Keyboard data
Pin 3 - no connector
Pin 4 - Ground
Pin 5 - +5 volts DC

J3 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J15 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J16 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W3 External cache configuration
Pins 1-2 64K or 128K
Pins 2-3 256K

W4 External cache configuration
Pins 1-2 64K
Pins 2-3 128K or 256K

W5 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W6 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W7 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

This document is for the full-sized (13.8" x 12.025") 486-25 ISA motherboard.
The part number for this board is 09-00025-xx.

It's identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; sixteen sockets for SIMMs (four banks of 4); a socket for a Weitek 4167 coprocessor.

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+           +
+ MOTHERBOARD SWITCH SETTINGS +
+           +
+ * = Default setting         +
+=====+

```

SW1

```

---
1  Internal cache enabled   *On
   Internal cache disabled  Off

2  Enable on-board Bios     *Off
   Enable external Bios     On

3  Reserved                 *On

4  External cache enabled   *On
   External cache disabled  Off

5  Bios relocation enabled   On
   Bios relocation disabled *Off

6  Reserved                 *Off

7  CGA / EGA / VGA         *On
   Monochrome               Off

8  Reserved                 *Off

```

SW2

```

---
1  Memory size (see below)
2  Memory size (see below)
3  Memory size (see below)
4  Memory size (see below)

5  Reserved                 *Off

6  D00000-EFFFFFF cacheable *Off
   D00000-EFFFFFF non-cacheable On

7  64K or 256K external cache Off
   128K external cache       On

8  64K external cache       Off
   128K or 256K external cache On

```

DIP switch settings for memory size

```

=====
Memory           Banks           DIP Switch 2
-----
MB              0      1      2      3      S1     S2     S3     S4
-----
1MB             256K
2MB             256K 256K
3MB             256K 256K 256K
4MB             256K 256K 256K 256K
4MB             1MB
5MB             256K 1MB
6MB             256K 256K 1MB
-----

```

Memory	0	1	2	3	S1	S2	S3	S4
1MB	256K				ON	ON	ON	ON
2MB	256K	256K			OFF	ON	ON	ON
3MB	256K	256K	256K		ON	OFF	ON	ON
4MB	256K	256K	256K	256K	OFF	OFF	ON	ON
4MB	1MB				ON	ON	OFF	ON
5MB	256K	1MB			ON	ON	OFF	OFF
6MB	256K	256K	1MB		ON	OFF	ON	OFF

7MB	256K	256K	256K	1MB	OFF	ON	ON	OFF
8MB	1MB	1MB			OFF	ON	OFF	ON
9MB	256K	1MB	1MB		ON	OFF	OFF	OFF
10MB	256K	256K	1MB	1MB	OFF	OFF	ON	OFF
12MB	1MB	1MB	1MB		ON	OFF	OFF	ON
13MB	256K	1MB	1MB	1MB	OFF	OFF	OFF	OFF
16MB	1MB	1MB	1MB	1MB	OFF	OFF	OFF	ON

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, and 1MB indicates that four 1Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

The maximum amount of memory supported by this board is 16MB.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```

+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+

```

J2 External 6-volt battery connector

Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J22 External speaker

Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J23 Keylock / Power LED

Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W2 Reserved

Pins 2-3

W4 Reset switch

Pin 1 - Signal
Pin 2 - Ground

W5 Turbo LED

Pin 1 - Signal
Pin 2 - Ground

W6 Turbo switch

Pin 1 - Signal
Pin 2 - Ground

W8 External cache configuration

Pins 1-2 - 64K
Pins 2-3 - 128K or 256K

W9 External cache configuration

Pins 1-2 - 64K or 128K
Pins 2-3 - 256K

This document is for the baby-sized (13.3" x 8.5") Baby Gemini 486-33 motherboard.

The part number for this board is 09-00081-xx, and also 09-00135-xx.

Its identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; eight sockets for SIMMs (two banks of 4); a socket for a Weitek 4167 coprocessor; one proprietary 32-bit slot which accommodates the M810 (a memory expansion card with eight sockets for SIMMs).

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+                               +
+ MOTHERBOARD SWITCH SETTINGS +
+                               +
+ * = Default setting         +
+=====+

```

SW1

```

1  Reserved          *On
2  Reserved          *Off
3  Reserved          *Off
4  Reserved          *Off
5  Reserved          *Off
6  Reserved          *Off
7  Reserved          *Off
8  Reserved          *Off

```

SW2

```

1  Memory size (see below)
2  Memory size (see below)
3  Memory size (see below)
4  Memory size (see below)
5  Memory size (see below)

6  Reserved          *On
7  Reserved          *Off

8  64K external cache  Off
   256K external cache  On

```

DIP switch settings for memory size

=====

Memory	Banks				DIP Switch 2				
	0	1	2	3	S1	S2	S3	S4	S5
1MB	256K				ON	ON	ON	ON	ON
2MB	256K	256K			OFF	ON	ON	ON	ON
3MB	256K	256K	256K		ON	OFF	ON	ON	ON
4MB	256K	256K	256K	256K	OFF	OFF	ON	ON	ON
4MB	1MB				ON	ON	OFF	ON	ON
5MB	256K	1MB			ON	ON	OFF	OFF	ON
6MB	256K	256K	1MB		ON	OFF	ON	OFF	ON
7MB	256K	256K	256K	1MB	OFF	ON	ON	OFF	ON
8MB	1MB	1MB			OFF	ON	OFF	ON	ON
9MB	256K	1MB	1MB		ON	OFF	OFF	OFF	ON
10MB	256K	256K	1MB	1MB	OFF	OFF	ON	OFF	ON
12MB	1MB	1MB	1MB		ON	OFF	OFF	ON	ON
13MB	256K	1MB	1MB	1MB	OFF	OFF	OFF	OFF	ON
16MB	1MB	1MB	1MB	1MB	OFF	OFF	OFF	ON	ON
16MB	4MB				ON	ON	OFF	ON	OFF
20MB	1MB	4MB			ON	ON	OFF	OFF	OFF
24MB	1MB	1MB	4MB		ON	OFF	ON	OFF	OFF
28MB	1MB	1MB	1MB	4MB	OFF	ON	ON	OFF	OFF

32MB	4MB	4MB			OFF	ON	OFF	ON	OFF
36MB	1MB	4MB	4MB		ON	OFF	OFF	OFF	OFF
40MB	1MB	1MB	4MB	4MB	OFF	OFF	ON	OFF	OFF
48MB	4MB	4MB	4MB		ON	OFF	OFF	ON	OFF
52MB	1MB	4MB	4MB	4MB	OFF	OFF	OFF	OFF	OFF
64MB	4MB	4MB	4MB	4MB	OFF	OFF	OFF	ON	OFF

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

Please note that Bank 0 and Bank 1 are on the motherboard. Banks 2 and 3 are found on the M810. Each bank consists of four SIMMs, and all four sockets within a bank must be filled.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F0000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```

+=====+
+                               +
+ MOTHERBOARD JUMPER SETTINGS +
+                               +
+=====+

```

J11 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J23 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J24 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W3 External cache configuration
Not installed - 64K
Installed - 256K

W4 External cache configuration
Not installed - 64K
Installed - 256K

W5 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W6 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W7 Turbo switch
 Pin 1 - Signal
 Pin 2 - Ground

W15 External cache configuration
 Pins 1-2 - 256K
 Pins 2-3 - 64K

This document is for the baby-sized (13.3" x 8.5") Baby Gemini 486DX2-50 motherboard.
 The part number for this board is 09-00135-xx.

It's identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; eight sockets for SIMMs (two banks of 4); a socket for a Weitek 4167 coprocessor; one proprietary 32-bit slot which accommodates the M810 (a memory expansion card with eight sockets for SIMMs).

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+                                     +
+ MOTHERBOARD SWITCH SETTINGS +
+                                     +
+ * = Default setting           +
+=====+
  
```

SW1

```

1 Reserved      *On
2 Reserved      *Off
3 Reserved      *Off
4 Reserved      *On
5 Reserved      *Off
6 Reserved      *Off
7 Reserved      *Off
8 Reserved      *Off
  
```

SW2

```

1 Memory size (see below)
2 Memory size (see below)
3 Memory size (see below)
4 Memory size (see below)
5 Memory size (see below)

6 Reserved      *On
7 Reserved      *Off

8 64K external cache Off
   256K external cache On
  
```

DIP switch settings for memory size

```

=====
Memory      Banks      DIP Switch 2
-----
MB          0         1         2         3         S1        S2        S3        S4        S5
-----
1MB        256K
2MB        256K 256K
3MB        256K 256K 256K
4MB        256K 256K 256K 256K
4MB        1MB
5MB        256K 1MB
6MB        256K 256K 1MB
7MB        256K 256K 256K 1MB
  
```

Memory	0	1	2	3	S1	S2	S3	S4	S5
1MB	256K				ON	ON	ON	ON	ON
2MB	256K	256K			OFF	ON	ON	ON	ON
3MB	256K	256K	256K		ON	OFF	ON	ON	ON
4MB	256K	256K	256K	256K	OFF	OFF	ON	ON	ON
4MB	1MB				ON	ON	OFF	ON	ON
5MB	256K	1MB			ON	ON	OFF	OFF	ON
6MB	256K	256K	1MB		ON	OFF	ON	OFF	ON
7MB	256K	256K	256K	1MB	OFF	ON	ON	OFF	ON

8MB	1MB	1MB			OFF	ON	OFF	ON	ON
9MB	256K	1MB	1MB		ON	OFF	OFF	OFF	ON
10MB	256K	256K	1MB	1MB	OFF	OFF	ON	OFF	ON
12MB	1MB	1MB	1MB		ON	OFF	OFF	ON	ON
13MB	256K	1MB	1MB	1MB	OFF	OFF	OFF	OFF	ON
16MB	1MB	1MB	1MB	1MB	OFF	OFF	OFF	ON	ON
16MB	4MB				ON	ON	OFF	ON	OFF
20MB	1MB	4MB			ON	ON	OFF	OFF	OFF
24MB	1MB	1MB	4MB		ON	OFF	ON	OFF	OFF
28MB	1MB	1MB	1MB	4MB	OFF	ON	ON	OFF	OFF
32MB	4MB	4MB			OFF	ON	OFF	ON	OFF
36MB	1MB	4MB	4MB		ON	OFF	OFF	OFF	OFF
40MB	1MB	1MB	4MB	4MB	OFF	OFF	ON	OFF	OFF
48MB	4MB	4MB	4MB		ON	OFF	OFF	ON	OFF
52MB	1MB	4MB	4MB	4MB	OFF	OFF	OFF	OFF	OFF
64MB	4MB	4MB	4MB	4MB	OFF	OFF	OFF	ON	OFF

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

Please note that Bank 0 and Bank 1 are on the motherboard. Banks 2 and 3 are found on the M810. Each bank consists of four SIMMs, and all four sockets within a bank must be filled.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F00000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```

+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+

```

J11 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J23 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J24 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W3 External cache configuration
Not installed - 64K
Installed - 256K

W4 External cache configuration

Not installed - 64K
Installed - 256K

W5 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W6 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W7 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W15 External cache configuration
Pins 1-2 - 256K
Pins 2-3 - 64K

This document is for the baby-sized (13.3" x 8.5") Baby Gemini 486SX-25 motherboard. It is also known as the "Upgradeable" board because it can accommodate the Intel OverDrive CPU. The part number for this board is 09-00145-xx.

It's identifying features are: an LED between expansion slots #5 and #6; eight 16-bit expansion slots; four sockets for SIMMs (using 72-pin SIMMs); one proprietary 80-pin SIMM socket which accommodates a Micronics External Cache Card.

The bus speed for this motherboard is fixed at 8MHz.

```
+=====+
+                                     +
+ MOTHERBOARD SWITCH SETTINGS +
+                                     +
+ * = Default setting           +
+=====+
```

SW1

1 Memory size (see below)
2 Memory size (see below)
3 Memory size (see below)
4 Memory size (see below)

5 Reserved *Off
6 Reserved *Off
7 Reserved *Off
8 Reserved *On

DIP switch settings for memory size

```
=====
```

Memory	Banks				DIP Switch 2			
	0	1	2	3	S1	S2	S3	S4
4MB	4M				ON	ON	ON	ON
8MB	4M	4M			OFF	ON	ON	ON
12MB	4M	4M	4M		ON	OFF	ON	ON
16MB	4M	4M	4M	4M	OFF	OFF	ON	ON
16MB	16M				ON	ON	OFF	ON
20MB	4M	16M			ON	ON	OFF	OFF
24MB	4M	4M	16M		ON	OFF	ON	OFF
28MB	4M	4M	4M	16M	OFF	ON	ON	OFF
32MB	16M	16M			OFF	ON	OFF	ON
36MB	4M	16M	16M		ON	OFF	OFF	OFF
40MB	4M	4M	16M	16M	OFF	OFF	ON	OFF

48MB	16M	16M	16M		ON	OFF	OFF	ON
52MB	4M	16M	16M	16M	OFF	OFF	OFF	OFF
64MB	16M	16M	16M	16M	OFF	OFF	OFF	ON

In the table above, 4M indicates that one 1Mx36 SIMM is installed in the socket, 16M indicates that one 4Mx36 SIMM is installed in the socket. The above shows all of the possible memory configurations.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F00000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following 1Mx36 memory brands: Micron Technologies, Mitsubishi, Samsung, Texas Instruments, Toshiba

Micronics Computers has tested and verified the following 4Mx36 memory brands: Mitsubishi, Samsung, Toshiba

```

+=====+
+                               +
+ MOTHERBOARD JUMPER SETTINGS +
+                               +
+=====+

```

J5 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J7 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

J8 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

W1 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W2 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W3 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

This document is for the baby-sized (13.3" x 8.5") Baby Gemini 486-25SX motherboard. The part number for this board is 09-00093-xx.

It's identifying features are: an LED between expansion slots #5 and #6; six 16-bit expansion slots; two 8-bit expansion slots; eight sockets for SIMMs (two banks of 4); one proprietary 32-bit slot which accommodates the Micronics External Cache Card (see below).

The bus speed for this motherboard is fixed at 8MHz.

```

+=====+
+               +
+ MOTHERBOARD SWITCH SETTINGS +
+               +
+   * = Default setting       +
+=====+

```

SW1

```

1  Reserved          *Off
2  Reserved          *Off
3  Reserved          *Off
4  Reserved          *Off
5  Reserved          *Off
6  Reserved          *Off
7  Reserved          *Off
8  Reserved          *Off

```

SW2

```

1  Memory size (see below)
2  Memory size (see below)
3  Memory size (see below)
4  Memory size (see below)
5  Memory size (see below)

6  Reserved          *Off
7  Reserved          *Off

8  CGA / EGA / VGA   *On
   Monochrome        Off

```

DIP switch settings for memory size

=====

Memory	Banks		DIP Switch 2				
	0	1	S1	S2	S3	S4	S5
1MB	256K		ON	ON	ON	ON	ON
2MB	256K	256K	OFF	ON	ON	ON	ON
4MB	1MB		ON	ON	OFF	ON	ON
5MB	256K	1MB	ON	ON	OFF	OFF	ON
8MB	1MB	1MB	OFF	ON	OFF	ON	ON
16MB	4MB		ON	ON	OFF	ON	OFF
20MB	1MB	4MB	ON	ON	OFF	OFF	OFF
32MB	4MB	4MB	OFF	ON	OFF	ON	OFF

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

Please note that there are only two banks of memory. Each bank consists of four SIMMs, and all four sockets within a bank must be filled.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F00000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```

+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+

```

J19 External 6-volt battery connector
 Pin 1 - Battery Positive
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Ground

J22 External speaker
 Pin 1 - Speaker
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - +5 volts DC

J23 Keylock / Power LED
 Pin 1 - Power LED signal
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Keyboard lock signal
 Pin 5 - Ground

W1 CPU type
 Not installed - 486SX
 Installed - 487SX

W2 CPU type
 Not installed - 487SX
 Installed - 486SX

W4 Reset switch
 Pin 1 - Signal
 Pin 2 - Ground

W5 Turbo switch
 Pin 1 - Signal
 Pin 2 - Ground

W6 Turbo LED
 Pin 1 - Signal
 Pin 2 - Ground

```

+=====+
+                                     +
+ External Cache Card +
+                                     +
+=====+

```

The External Cache Card allows the addition of 64K, 128K, or 256K of external cache to the motherboard. It also provides a Weitek 4167 socket for a co-processor installation.

64K external cache
 =====

Install eight 8Kx8 SRAM chips into U1, U2, U5, U6, U9, U10, U14, and U15. The chips must be 25ns or faster. Make sure that W1, W2, W3, and W4 on the card are not jumpered.

128K external cache
 =====

Install four 32Kx8 SRAM chips into U1, U2, U5, and U6. The chips must be 25ns or faster. Make sure that W1, W2, and W3 on the card have jumper blocks installed, and that W4 is not jumpered.

256K external cache
 =====

Install eight 32Kx8 SRAM chips into U1, U2, U5, U6, U9, U10, U14, and U15. The chips must be 25ns or faster. Make sure that W1 on the card is not jumpered, and that W2, W3, and W4 have jumper blocks installed.

After completing the cache installation on the card, insert the External Cache Card into the special slot on the motherboard. To activate the cache, set the External Cache feature to Enabled in the CMOS setup screen. Press <Ctrl><Alt><Esc> after booting, then press <PgUp> to get to the second setup screen. After setting the parameter, press <Esc> to save the settings and reboot the system. If you press <F10> instead of <Esc>, the system will not reboot, and the settings will not be saved.

This document is for the baby-sized (13.3" x 8.5") Gemini VL-Bus motherboard. The part number for this board is 09-00144-xx.

It's identifying features are: an LED between expansion slots #5 and #6; six 16-bit expansion slots; two 16-bit/VL-Bus expansion slots; four sockets for SIMMs; a socket for an OverDrive CPU; two IDE interface connectors; one floppy connector; two serial port connectors; one parallel port connector.

The ISA bus speed for this motherboard is fixed at 8MHz. The VL-Bus bus speed is determined by the CPU speed. If the CPU is a 486SX-25, or 486DX2-50, the VL-Bus bus speed is 25MHz. If the CPU is a 486SX-33, 486DX-33, or 486DX2-66, the VL-Bus bus speed is 33MHz.

```

+=====+
+           +
+ MOTHERBOARD SWITCH SETTINGS +
+           +
+ * = Default setting          +
+=====+
  
```

SW1

- 1 Memory size (see below)
- 2 Memory size (see below)
- 3 Memory size (see below)
- 4 Memory size (see below)

- 5 CPU selection (see below)
- 6 CPU selection (see below)
- 7 CPU selection (see below)
- 8 CPU selection (see below)

DIP switch settings for memory size
 =====

Memory	Banks				DIP Switch 1			
	0	1	2	3	S1	S2	S3	S4
4MB	4M				ON	ON	ON	ON
8MB	4M	4M			OFF	ON	ON	ON
12MB	4M	4M	4M		ON	OFF	ON	ON
16MB	4M	4M	4M	4M	OFF	OFF	ON	ON
16MB	16M				ON	ON	OFF	ON
20MB	4M	16M			ON	ON	OFF	OFF
24MB	4M	4M	16M		ON	OFF	ON	OFF

28MB	4M	4M	4M	16M	OFF	ON	ON	OFF
32MB	16M	16M			OFF	ON	OFF	ON
36MB	4M	16M	16M		ON	OFF	OFF	OFF
40MB	4M	4M	16M	16M	OFF	OFF	ON	OFF
48MB	16M	16M	16M		ON	OFF	OFF	ON
52MB	4M	16M	16M	16M	OFF	OFF	OFF	OFF
64MB	16M	16M	16M	16M	OFF	OFF	OFF	ON

In the table above, 4M indicates that one 1Mx36 SIMM is installed in the socket, 16M indicates that one 4Mx36 SIMM is installed in the socket. The above shows all of the possible memory configurations.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F00000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following 1Mx36 memory brands: Micron Technologies, Mitsubishi, Samsung, Texas Instruments, Toshiba

Micronics Computers has tested and verified the following 4Mx36 memory brands: Mitsubishi, Samsung, Toshiba

DIP switch settings for CPU selection
=====

CPU Speed	DIP Switch 1			
	S5	S6	S7	S8
33MHz or 66MHz	Off	On	Off	Off
25MHz or 50MHz	On	Off	On	Off

```

+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+

```

- J11 Com Port A
- J12 Parallel Port
- J14 Com Port B
- J15 Floppy connector
- J16 Primary IDE connector
- J24 External 6-volt battery connector
 - Pin 1 - Battery Positive
 - Pin 2 - no connector
 - Pin 3 - Ground
 - Pin 4 - Ground
- J28 External speaker
 - Pin 1 - Speaker
 - Pin 2 - no connector
 - Pin 3 - Ground
 - Pin 4 - +5 volts DC
- J29 Keylock / Power LED
 - Pin 1 - Power LED signal
 - Pin 2 - no connector

Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

J30 Secondary IDE connector

W13 CPU selection
Pins 1-2 486DX, 486DX2
Pins 2-3 486SX

W15 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W16 Parallel port I/O direction
Pins 1-2 Input mode
Pins 2-3 Output mode (default)

W17 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W18 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W19 IDE LED
Pin 1 - Signal
Pin 2 - Ground

W20 Flash ROM operation (see note below)
Pins 1-2 Recovery
Pins 2-3 Normal operation (default)

DO NOT change jumper W20 unless instructed by a Micronics Technical Support Engineer. Changing the jumper will result in the Bios being erased. You must have a Flash recovery floppy diskette before attempting to recover. The jumper is NOT moved when updating the Flash ROM.

```
+=====+  
+           +  
+ Additional Information +  
+           +  
+=====+
```

I/O Port addresses

```
-----  
COM1 3F8h  
COM2 2F8h  
COM3 3E8h  
COM4 2E8h  
LPT1 3BCh  
LPT2 378h  
LPT3 278h
```

IRQ list

```
-----  
IRQ 6 Floppy controller  
IRQ 14 Primary IDE controller  
IRQ 15 Secondary IDE controller
```

When using the on-board I/O ports, the interrupts used cannot be shared with another device. IRQ14 and IRQ15 cannot be shared, regardless of whether or not IDE drives are attached to the on-board connectors.

This document is for the full-sized (13.3" x 12.025") 80486DX-50 EISA motherboard. The part number for this board is 09-00128-xx.

It's identifying features are: an LED between expansion slots #5 and #6; eight 32-bit expansion slots; sixteen sockets for SIMMs (four banks of 4); a socket for a Weitek 4167 coprocessor; one proprietary 32-bit slot which accommodates the MVC32LB (a video card based on the ATI Mach 32 chip).

The bus speed for this motherboard is fixed at 8MHz.

RTC MC146818AP U74

EISA CMOS TC5563APL-10 U73

```

+=====+
+                                     +
+ MOTHERBOARD SWITCH SETTINGS +
+                                     +
+ * = Default setting           +
+=====+

```

- 1 Memory size (see below)
- 2 Memory size (see below)
- 3 Memory size (see below)
- 4 Memory size (see below)
- 5 Memory size (see below)
- 6 Reserved *On
- 7 Reserved *Off
- 8 Color video adapter *On
Mono video adapter Off

DIP switch settings for memory size

```

=====
Memory          Banks                DIP Switch 2
-----
MB      0      1      2      3      S1      S2      S3      S4      S5
-----
1MB     256K
2MB     256K 256K
3MB     256K 256K 256K
4MB     256K 256K 256K 256K
4MB     1MB
5MB     256K 1MB
6MB     256K 256K 1MB
7MB     256K 256K 256K 1MB
8MB     1MB 1MB
9MB     256K 1MB 1MB
10MB    256K 256K 1MB 1MB
12MB    1MB 1MB 1MB
13MB    256K 1MB 1MB 1MB
16MB    1MB 1MB 1MB 1MB
16MB    4MB
20MB    1MB 4MB
24MB    1MB 1MB 4MB
28MB    1MB 1MB 1MB 4MB
32MB    4MB 4MB
36MB    1MB 4MB 4MB
40MB    1MB 1MB 4MB 4MB
48MB    4MB 4MB 4MB
52MB    1MB 4MB 4MB 4MB
64MB    4MB 4MB 4MB 4MB

```

In the table above, 256K indicates that four 256Kx9 SIMMs are installed in the bank, 1MB indicates that four 1Mx9 SIMMs are installed in the bank, and 4MB indicates that

four 4Mx9 SIMMs are installed in the bank. The above shows all of the possible memory configurations.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F00000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```
+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+
```

J12 Keyboard connector
Pin 1 - Keyboard clock
Pin 2 - Keyboard data
Pin 3 - no connector
Pin 4 - Ground
Pin 5 - +5 volts DC

J18 External 6-volt battery connector
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J20 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J21 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W1 Reserved
Pins 1-2

W3 Floppy Drive
Pins 1-2 -- Enables on-board floppy drive
Pins 2-3 -- Disables on-board floppy drive

W9 Reserved
Pins 2-3

W10 Reserved
Pins 1-2

W11 Reserved
Pins 1-2

W12 Reserved
Pins 1-2

W13 Reset switch
Pin 1 - Signal

Pin 2 - Ground

W15 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W16 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W11 Reserved
Pins 2-3

W12 Reserved
Pins 1-2

Serial Port configuration
=====

I/O addresses

COM1 = 3F8-3FFh
COM2 = 2F8-2FFh

COM1	COM2	W2	W6	W8
Enabled	Enabled	1-2	1-2	1-2
Enabled	Disabled	1-2	1-2	2-3
Disabled	Enabled	2-3	1-2	1-2
Disabled	Disabled	2-3	1-2	2-3

Parallel Port configuration
=====

Port	I/O address	W4	W7	W5
LPT1	3BC-3BEh	1-2	2-3	2-3
LPT2	378-37Ah	1-2	1-2	2-3
LPT3	278-27Ah	2-3	1-2	2-3
Disabled		2-3	2-3	2-3

Cache configuration
=====

Cache	W17	W18	W19	W14
64K	N/C	N/C	N/C	2-3
256K	1-2	1-2	1-2	1-2

N/C = Not Connected

This document is for the XCP Mini-sized (9.5" x 8.5") ISA-Bus motherboard.
The part number for this board is 09-00164-xx.

It's identifying features are: an LED at the end of expansion slots #7 ; six 16-bit expansion slots; one 8-bit expansion slot; four sockets for SIMMs; a socket for an OverDrive CPU

The ISA bus speed for this motherboard is set at 8.33MHz. The CPU clock speed is determined by the Oscillator. If the CPU is a 486SX-25, or 486DX2-50, the Bus clock speed is 1/3. For the 486SX-33, 486DX-33, or 486DX2-66, CPUs the Bus clock speed is 1/4 and the 486DX50 requires 1/6 bus clock speed.

The following shows all of the possible memory configurations.

MEMORY CHART CONFIGURATION

```

=====
Memory          Banks
-----
MB             0     1     2     3
-----
1MB           1M
2MB           1M   1M
4MB           4M
6MB           1M   1M   4M
8MB           4M   4M
10MB          1M   1M   4M   4M
12MB          4M   4M   4M
16MB          4M   4M   4M   4M
16MB          16M
18MB          1M   1M  16M
20MB          4M  16M
24MB          4M   4M  16M
32MB          16M  16M
36MB          4M  16M  16M
40MB          4M   4M  16M  16M
48MB          16M  16M  16M
64MB          16M  16M  16M  16M

```

In the table above, 1M indicates that one 256x36 SIMM is installed in the socket, 4M indicates that one 1Mx36 SIMM is installed in the socket, 16M indicates that, one 4Mx36 SIMM is installed in the socket.

Micronics Computers has tested and verified the following 1Mx36 memory brands: Micron Technologies, Mitsubishi, Samsung, Texas Instruments, Toshiba

Micronics Computers has tested and verified the following 4Mx36 memory brands: Mitsubishi, Samsung, Toshiba

```

+=====+
+                                     +
+ MOTHERBOARD JUMPER SETTINGS +
+                                     +
+=====+

```

J18 External speaker
 Pin 1 - Speaker
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - +5 volts DC

J19 Keylock / Power LED
 Pin 1 - Power LED signal
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Keyboard lock signal
 Pin 5 - Ground

W12 CPU selection
 Pins 1-2 i487SX , Overdrive SX
 Pins 2-3 i486SX, i486DX, i486DX2

W13 Reset switch
 Pin 1 - Signal
 Pin 2 - Ground

W14 Turbo LED
 Pin 1 - Signal
 Pin 2 - Ground

W15 Turbo switch
 Pin 1 - Signal
 Pin 2 - Ground

W1 Clearing CMOS Setup
 Temporarily install jumper to Pins 2-3, normal settings are 1-2

W3 Color / Monochrome Display
 COLOR - Installed *
 MONO - Open

```

+=====+
+           +
+ Cache Configuration +
+           +
+=====+
64K Cache      W7      W9      W10     W17     W18
                2-3     1-2     2-3     1-2     1-2   (9) 8k X8 Sram -20Ns for U1, U2,
U9, U10, U16, U17, U18, U19 & U45
128k           1-2     2-3     1-2     2-3     1-2   (5) 32kX8 Sram -20Ns for U1, U2,
U9, U10 & U45
256k           2-3     2-3     2-3     2-3     2-3   (9) 32kX8 Sram -20ns for U1, U2,
U9, U10, U16, U17, U18, U19 & U45

+=====+
+           +
+ Additional Information +
+           +
+=====+
  
```

The Mini 486 Motherboard does not require an external battery to be installed.
 The Dallas / Benchmark Real Time Clock Chip contains an internal battery for an
 approximate lifetime of 8-10 years.
 This document is for the baby-sized (13.3" x 8.5") JX30 VL-Bus motherboard.
 The part number for this board is 09-00183-xx.

Its identifying features are: an LED between expansion slots #5 and #6; seven 16-bit
 expansion slots; two 16-bit/VL-Bus expansion slots; four sockets for SIMMs; a ZIF
 socket
 for an OverDrive CPU; IDE interface connector; one floppy connector; two serial
 port connectors; one parallel port connector.

The VESA Local Bus speed is determined by the CPU speed. If the CPU is a 486SX-25, or
 486DX2-50, the VL-Bus
 bus speed is 25MHz. If the CPU is a 486SX-33, 486DX-33, or 486DX2-66, the VL-Bus
 bus speed is 33MHz. A 50 MHz CLK is not yet a current VESA standard specification

The ISA bus speed for this motherboard is set at 8.33MHz. The CPU clock speed is
 determined by the Oscillator. If the CPU is a 486SX-25, or 486DX2-50, the Bus
 clock speed is 1/3. For the 486SX-33, 486DX-33, or 486DX2-66 CPUs, the Bus
 clock speed is 1/4.

The following shows all of the possible memory configurations.

MEMORY CHART CONFIGURATION

```

=====
Memory          Banks
-----
MB             0    1    2    3
-----
1MB            1M
2MB            1M   1M
4MB            4M
6MB            1M   1M   4M
8MB            4M   4M
10MB           1M   1M   4M   4M
12MB           4M   4M   4M
16MB           4M   4M   4M   4M
16MB           16M
18MB           1M   1M  16M
20MB           4M  16M
24MB           4M   4M  16M
  
```

32MB	16M	16M		
36MB	4M	16M	16M	
40MB	4M	4M	16M	16M
48MB	16M	16M	16M	
64MB	16M	16M	16M	16M

In the table above, 1M indicates that one 256x36 SIMM is installed in the socket, 4M indicates that one 1Mx36 SIMM is installed in the socket, 16M indicates that, one 4Mx36 SIMM is installed in the socket.

Micronics Computers has tested and verified the following 1Mx36 memory brands: Micron Technologies, Mitsubishi, Samsung, Texas Instruments, Toshiba

Micronics Computers has tested and verified the following 4Mx36 memory brands: Mitsubishi, Samsung, Toshiba

```

+=====+
+                                     +
+ MOTHERBOARD SWITCH & JUMPER SETTINGS +
+                                     +
+=====+

```

DIP switch settings for CPU selection

```

=====
                                DIP Switch 1
                                -----
CPU Speed                       S1    S2    S3    S4
-----
33MHz or DX2/ 66MHz            Off   On    Off   Off
25MHz or DX2/ 50MHz            On    On    Off   Off

```

W70 CPU selection
Pins 2-3 486DX, 486DX2 & P24T
Pins 1-2 486SX

W71 PQFP Surface mounted 486SX
Pins 1-2 PQFP 486SX with Overdrive SX Installed
Pins 2-3 PQFP 486SX with DX, or DX2 CPU Installed

W40 When Local Bus Master controllers are installed {VL SCSI},
jumper W40 must be removed to support local bus DMA.

J12 Serial 16450 Port A

J16 Serial 16450 Port B

J15 Parallel Printer Port

W5 Parallel port I/O direction
Pins 2-3 Output mode (default)
Pins 1-2 Input mode (Scanner)

I/O Port addresses / CMOS Setup

```

-----
COM1  3F8h    IRQ 4
COM2  2F8h    3
COM3  3E8h    4
COM4  2E8h    3

LPT1  3BCh    7
LPT2  378h    7
LPT3  278h    7

```

IRQ in use

```

-----
IRQ 6 Floppy controller
IRQ 14 Primary IDE controller

```

J18 Floppy connector

J17 Primary IDE connector

W11 IDE LED
Pin 1 - Signal
Pin 2 - Ground

W31 Clearing CMOS Setup
Temporarily install jumper, normal settings are open.

J6 Optional External 4.5-6.0 volt battery connector {Motorola 146818AP RTC Only}
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

The JX30 Motherboard does not require an external battery to be installed.
The Dallas / Benchmarq Real Time Clock Chip contains an internal battery for an approximate lifetime of 8-10 years.

W6 Color / Monochrome Display
COLOR - Installed *
MONO - Open

J33 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J34 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W12 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W13 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W14 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W8 Flash ROM operation (see note below)
Pins 1-2 Recovery mode
Pins 2-3 Normal operation (default)

DO NOT change jumper W8 unless instructed by a Micronics Technical Support Engineer.
Changing the jumper will result in the Bios being Erased. You must have a Flash recovery floppy diskette before attempting to recover. The jumper is NOT moved when updating the Flash ROM.

```

+=====+
+                               +
+   Cache Configuration         +
+ Direct Mapped Write Through +
+                               +
+=====+
                W64      W65      W66      W67      W68

```

64K Cache 1-2 1-2 2-3 2-3 1-2 (9) 8k X8 Sram -20Ns for U202,
 U203, U204, U205, U206, U207, U208, U209 & U201
 128k 2-3 1-2 1-2 1-2 2-3 (5) 32kX8 Sram -20Ns for U202,
 U203, U204, U205, & U201
 256k 2-3 2-3 2-3 2-3 2-3 (9) 32kX8 Sram -20ns for U202,
 U203, U204, U205, U206, U207, U208, U209 & U201

This document is for the baby-sized (13.3" x 8.5") 80486DX-33, DX2/66, DX-50, and 80486SX-25 EISA motherboard. The part number for this board is 09-00159-xx.

It's identifying features are: an LED between expansion slots #5 and #6; eight 32-bit expansion slots; four sockets for SIMMs (four banks); a ZIF socket for any DX, DX2, SX & Intel P24T Overdrive. The First 6 EISA slots support Bus Mastering Controllers.

The Standard EISA bus clock is fixed at 8.3MHz.

```

+=====+
+                +
+      MEMORY CHART      +
+                +
+                +
+=====+
  
```

The following chart shows all of the possible memory configurations

```

=====
Memory          Banks
-----
MB             0   1   2   3
-----
4MB            1MB
8MB            1MB 1MB
12MB           1MB 1MB 1MB
16MB           1MB 1MB 1MB 1MB
16MB           4MB
20MB           1MB 4MB
24MB           1MB 1MB 4MB
32MB           4MB 4MB
36MB           1MB 4MB 4MB
40MB           1MB 1MB 4MB 4MB
48MB           4MB 4MB 4MB
52MB           1MB 4MB 4MB 4MB
64MB           4MB 4MB 4MB 4MB
  
```

In the table above 70ns or 60ns access time for DRAM /SIMMs is required, 1MB indicates that a 1Mx36 SIMM is installed in the bank, and 4MB indicates that a 4Mx36 SIMMs are installed in the bank.

(1Mx36) = 4MB / 4096Kb of RAM and (4Mx36) = 16MB / 15360Kb of RAM

Micronics Computers has tested and verified the following memory brands:
 Toshiba, Siemens, Mitsubishi, NEC & Micron

```

+=====+
+                +
+ MOTHERBOARD JUMPER SETTINGS +
+                +
+=====+
  
```

J23 Keyboard connector
 Pin 1 - Keyboard clock
 Pin 2 - Keyboard data
 Pin 3 - no connector

Pin 4 - Ground
 Pin 5 - +5 volts DC

J3 External 6-volt battery connector

Pin 1 - Battery Positive
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Ground

J13 External speaker

Pin 1 - Speaker
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - +5 volts DC

J11 Keylock / Power LED

Pin 1 - Power LED signal
 Pin 2 - no connector
 Pin 3 - Ground
 Pin 4 - Keyboard lock signal
 Pin 5 - Ground

J9 Reset switch

Pin 1 - Signal
 Pin 2 - Ground

J8 Turbo switch

Pin 1 - Signal
 Pin 2 - Ground

J5 Turbo LED

Pin 1 - Signal
 Pin 2 - Ground

J12 Video mode

Color - INSTALLED {Default}
 MONO - OPEN

CPU SELECTION

i486SX	ZIF Socket			
PQFP Surface mounted	CPU Selection	JP1	JP2	JP3
None	i486SX	1-2	3-4	2-3
None	i486DX or I486DX2	2-3	1-2	1-2 & 3-4
i486SX	NONE	1-2	3-4	2-3
i486SX	i486DX OR DX/2	2-3	1-2	1-2 & 3-4
i486SX	i487SX	1-2	1-2	1-2 & 3-4
i486SX	i486SX Overdrive	1-2	2-3	1-2 & 3-4
For Earlier Revisions Ax	J6			
i486SX	2-3			
i486DX	1-2 & 3-4			

CPU Clock Speed

J7

J10

33Mhz	OFF	ON	i486DX/33, DX2/66, SX/33
25Mhz	ON	ON	i486SX/25, DX2/50
50Mhz	OFF	OFF	i486DX/50

Cache configuration

=====

Cache J15 J16 J17 J18 J19 J20 J21 J22

```

-----
64K    1-2  1-2  1-2  1-2    1-2    1-2    2-3    3-4
(8)   8Kx8 -20ns SRAM for U110-U116 & U118
(1)  64Kx1 -20ns SRAM for U103
(1)  32Kx8 -20NS SRAM for U104

128K   2-3  1-2  1-2  2-3    1-2    1-2    1-2    4-5
(4)  32Kx8 -20ns SRAM for U110-U112 & U118
(1)  64Kx1 -20ns SRAM for U103
(1)  32Kx8 -20NS SRAM for U104

256K   2-3  2-3  1-2  1-2    1-2    1-2    1-2    1-2
(8)  32Kx8 -20ns SRAM for U110-U116 & U118
(1)  64Kx1 -20ns SRAM for U103
(1)  16Kx4 -20NS SRAM for U101 & U102

512K   2-3  2-3  2-3  2-3    2-3    2-3    1-2    4-5
(4)  128Kx8 -20ns SRAM for U105-U108
(1)  64Kx1 -20ns SRAM for U103
(1)  32Kx8 -20ns SRAM for U104
U101 & U102 SRAM must be removed from a 256k cache configuration.

```

This document is for the baby-sized (13.3" x 8.5") JX30G VL-Bus motherboard.
The part number for this board is 09-00189-xx.

It's identifying features are: an LED between expansion slots #5 and #6; seven 16-bit expansion slots; two 16-bit/VL-Bus expansion slots; four sockets for SIMMs; a ZIF socket for an OverDrive CPU; IDE interface connector; one floppy connector; two serial port connectors; one parallel port connector.

The VESA Local Bus speed is determined by the CPU speed. If the CPU is a 486SX-25, or 486DX2-50, the VL-Bus bus speed is 25MHz. If the CPU is a 486SX-33, 486DX-33, or 486DX2-66, the VL-Bus bus speed is 33MHz. A 50 MHZ CLK is not yet a current VESA standard specification

The ISA bus speed for this motherboard is set at 8.33MHz. The CPU clock speed is determined by the Oscillator. If the CPU is a 486SX-25, or 486DX2-50, the Bus clock speed is 1/3. For the 486SX-33, 486DX-33, or 486DX2-66 CPUs, the Bus clock speed is 1/4.

The following shows all of the possible memory configurations.

MEMORY CHART CONFIGURATION

=====

Memory	Banks			
	0	1	2	3
1MB	1M			
2MB	1M	1M		
4MB	4M			
6MB	1M	1M	4M	
8MB	4M	4M		
10MB	1M	1M	4M	4M
12MB	4M	4M	4M	
16MB	4M	4M	4M	4M
16MB	16M			
18MB	1M	1M	16M	
20MB	4M	16M		
24MB	4M	4M	16M	
32MB	16M	16M		
36MB	4M	16M	16M	
40MB	4M	4M	16M	16M
48MB	16M	16M	16M	

64MB 16M 16M 16M 16M

In the table above, 1M indicates that one 256x36 SIMM is installed in the socket, 4M indicates that one 1Mx36 SIMM is installed in the socket, 16M indicates that, one 4Mx36 SIMM is installed in the socket.

Micronics Computers has tested and verified the following 1Mx36 memory brands: Micron Technologies, Mitsubishi, Samsung, Texas Instruments, Toshiba

Micronics Computers has tested and verified the following 4Mx36 memory brands: Mitsubishi, Samsung, Toshiba

```
+=====+
+
+ MOTHERBOARD SWITCH & JUMPER SETTINGS +
+
+=====+
```

DIP switch settings for CPU selection

```
=====
DIP Switch 1
-----
CPU Speed      S1   S2   S3   S4
-----
33MHz or DX2/ 66MHz  On   On   Off  Off
25MHz or DX2/ 50MHz  Off  On   Off  Off
```

W12 CPU selection
Pins 2-3 486DX, 486DX2 & P24T
Pins 1-2 486SX

W13 PQFP Surface mounted 486SX
Pins 1-2 PQFP 486SX Enabled
Pins 2-3 PQFP 486SX Disabled

W4 When Local Bus Master controllers are installed {VL SCSI},
jumper W4 must be removed to support local bus DMA.

J14 Serial 16550 Port A National Semiconductor Super i/o PC87312

J9 Serial 16550 Port B National Semiconductor Super i/o PC87312

J16 Parallel Printer Port

W7 Parallel port I/O direction
Pins 2-3 Output mode (default)
Pins 1-2 Input mode (Tape Backup /Scanner)

I/O Port addresses / CMOS Setup

```
-----
COM1 3F8h IRQ 4
COM2 2F8h 3
COM3 3E8h 4
COM4 2E8h 3

LPT1 3BCh 7
LPT2 378h 7
LPT3 278h 7
```

IRQ in use

```
-----
IRQ 6 Floppy controller
IRQ 14 Primary IDE controller
```

J Floppy connector

J Primary IDE connector

W21 IDE LED
Pin 1 - Signal
Pin 2 - Ground

W5 Clearing CMOS Setup
Temporarily install jumper, normal settings are open.

J8 Optional External 4.5-6.0 volt battery connector {Motorola 146818AP RTC Only}
Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

The JX30 Motherboard does not require an external battery to be installed.
The Dallas / Benchmark Real Time Clock Chip contains an internal battery for an approximate lifetime of 8-10 years.

W2 Color / Monochrome Display
COLOR - Installed *
MONO - Open

W3 PS/2 Mouse @ IRQ 12
IRQ 12 enabled - Installed (NEXTStep O/S Installation)
Disabled - open

J30 External speaker
Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J31 Keylock / Power LED
Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W20 Reset switch
Pin 1 - Signal
Pin 2 - Ground

W18 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

W19 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W8 Flash ROM operation (see note below)
Pins 1-2 Recovery mode
Pins 2-3 Normal operation (default)

DO NOT change jumper W8 unless instructed by a Micronics Technical Support Engineer.
Changing the jumper will result in the Bios being Erased. You must have a Flash recovery floppy diskette before attempting to recover. The jumper is NOT moved when updating the Flash ROM.

```
+=====+
+                               +
+   Cache Configuration         +
+ Direct Mapped Write Through +
+                               +
+=====+
                W10      W11      W22      W23      W24
```

```

64K Cache      1-2    1-2    2-3    2-3    1-2    (9) 8k X8 Sram -20Ns for U56-U60,
U67-U70, & U34 / TAG
128k           1-2    2-3    1-2    1-2    2-3    (5) 32kX8 Sram -20Ns for U56-U60,
& U34
256k           2-3    2-3    2-3    2-3    2-3    (9) 32kX8 Sram -20ns for U56-U60,
U67-U70, & U34

```

```

+=====+
+                               +
+   Cache Configuration       +
+ Direct Mapped Write Back   +
+                               +
+=====+

```

```

                W16    W17
64K Cache      1-2    2-3    (1) 8k X8 Sram -20Ns for U61
128k           1-2    2-3    (1) 32kX8 Sram -20Ns for U61
256k           2-3    2-3    (1) 32kX8 Sram -20ns for U61

```

This document is for the full-sized (13.3" x 12.025") 80486DX-33, 80486DX2-50, and 80486DX2-66 EISA motherboard. The part number for this board is 09-00173-xx.

Its identifying features are: an LED between expansion slots #5 and #6; eight 32-bit EISA expansion slots; 4 sockets for SIMMs (four banks). The EISA Slots are numbered 1, 7, 8, 2, 3, 4, 5, & 6. EISA Slots 7,8 are VESA Slots which support Bus mastering VESA SCSI controllers only. EISA slots 1 to 6 support EISA Bus mastering controllers.

The Bus clock speed EISA standard is fixed at 8.3MHz.

```

+=====+
+                               +
+ MOTHERBOARD SWITCH SETTINGS +
+                               +
+ *   Default setting         +
+=====+

```

- 1 Memory size (see below)
- 2 Memory size (see below)
- 3 Memory size (see below)
- 4 Memory size (see below)
- 5 Memory size (see below)
- 6 CPU Speed 33Mhz On / 25Mhz Off
- 7 CPU Speed 33MHZ Off / 25Mhz Off
- 8 Color video adapter *On
- Mono video adapter Off

DIP switch settings for memory size

```

=====
Memory          Banks                DIP Switch 2
-----
MB             0   1   2   3   S1  S2  S3  S4  S5
-----
1MB           256K
2MB           256K 256K
3MB           256K 256K 256K
4MB           256K 256K 256K 256K
4MB           1MB
5MB           256K 1MB
6MB           256K 256K 1MB
7MB           256K 256K 256K 1MB
8MB           1MB 1MB

```

Memory	Banks	S1	S2	S3	S4	S5
1MB	256K	ON	ON	ON	ON	ON
2MB	256K 256K	OFF	ON	ON	ON	ON
3MB	256K 256K 256K	ON	OFF	ON	ON	ON
4MB	256K 256K 256K 256K	OFF	OFF	ON	ON	ON
4MB	1MB	ON	ON	OFF	ON	ON
5MB	256K 1MB	ON	ON	OFF	OFF	ON
6MB	256K 256K 1MB	ON	OFF	ON	OFF	ON
7MB	256K 256K 256K 1MB	OFF	ON	ON	OFF	ON
8MB	1MB 1MB	OFF	ON	OFF	ON	ON

9MB	256K	1MB	1MB		ON	OFF	OFF	OFF	ON
10MB	256K	256K	1MB	1MB	OFF	OFF	ON	OFF	ON
12MB	1MB	1MB	1MB		ON	OFF	OFF	ON	ON
13MB	256K	1MB	1MB	1MB	OFF	OFF	OFF	OFF	ON
16MB	1MB	1MB	1MB	1MB	OFF	OFF	OFF	ON	ON
16MB	4MB				ON	ON	OFF	ON	OFF
20MB	1MB	4MB			ON	ON	OFF	OFF	OFF
24MB	1MB	1MB	4MB		ON	OFF	ON	OFF	OFF
28MB	1MB	1MB	1MB	4MB	OFF	ON	ON	OFF	OFF
32MB	4MB	4MB			OFF	ON	OFF	ON	OFF
36MB	1MB	4MB	4MB		ON	OFF	OFF	OFF	OFF
40MB	1MB	1MB	4MB	4MB	OFF	OFF	ON	OFF	OFF
48MB	4MB	4MB	4MB		ON	OFF	OFF	ON	OFF
52MB	1MB	4MB	4MB	4MB	OFF	OFF	OFF	OFF	OFF
64MB	4MB	4MB	4MB	4MB	OFF	OFF	OFF	ON	OFF

In the table above, 256K indicates that (1) 256Kx36 SIMM is installed in the bank, 1MB indicates that (1) 1Mx36 SIMM is installed in the bank, and 4MB indicates that 4Mx36 SIMM is installed in the bank. The above shows all of the possible memory configurations.

When installing more than 16MB of memory, BIOS relocation must be disabled. Bios relocation copies the video Bios (C0000-C7FFF) and the system ROM Bios (F0000-FFFFF) into RAM. The motherboard adds 15MB to these addresses (F0000) to be able to differentiate between the ROM and RAM. Enabling the relocation feature causes the memory above 16MB to become non-contiguous and therefore inaccessible.

Micronics Computers has tested and verified the following memory brands:
Toshiba, Siemens, Mitsubishi, NEC

```

+=====+
+                               +
+ MOTHERBOARD JUMPER SETTINGS +
+                               +
+=====+

```

J1 Keyboard connector

Pin 1 - Keyboard clock
Pin 2 - Keyboard data
Pin 3 - no connector
Pin 4 - Ground
Pin 5 - +5 volts DC

J17 External 6-volt battery connector

Pin 1 - Battery Positive
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Ground

J22 External speaker

Pin 1 - Speaker
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - +5 volts DC

J23 Keylock / Power LED

Pin 1 - Power LED signal
Pin 2 - no connector
Pin 3 - Ground
Pin 4 - Keyboard lock signal
Pin 5 - Ground

W5 Reset switch

Pin 1 - Signal
Pin 2 - Ground

W6 Turbo switch
Pin 1 - Signal
Pin 2 - Ground

W7 Turbo LED
Pin 1 - Signal
Pin 2 - Ground

J62 Floppy Controller IRQ 6, DMA CH 2, I/O 3F0-3F7H {AUTO DISABLE}

J30 IDE Interface IRQ 14, I/O 1F0-1F7h {AUTO DISABLE}

W36 IDE Hard Drive LED
1 - Signal
2 - GND
3 - GND
4 - Signal

J63 Serial A 16450 UART IRQ 4 COM 1 or COM3

J64 Serial B 16450 UART IRQ 3 COM 2 or COM4

{ A 16550 UART is present only if the Super I/O Chip is National PC87312 }

J16 Parallel Port connector IRQ 7, @3BCh or @378h

W16 Printer Port mode
Pin 2-3 - Output Mode
Pin 1-2 - Input Mode {scanner}

CPU Clock Speed	W54	W55	SW2 #6	SW2 #7
25Mhz	ON	ON	OFF	OFF
33Mhz	ON	OFF	ON	OFF

PQFP i486SX Surface Mounted	ZIF Socket	W50	W66	W67
None	i486SX	1-2	2-3	3-4
None	i486DX /DX2	2-3	1-2 & 3-4	1-2
i486SX	None	1-2	2-3	3-4
i486SX	i487SX	1-2	1-2 & 3-4	3-4
i486SX	i486DX /DX2	2-3	1-2 & 3-4	1-2
i486SX	OverDRIVE	1-2	1-2 & 3-4	2-3

W68 When Local Bus Master Controllers are installed {VL SCSI},
jumper W68 must be placed on Pins 1-2 to support local bus DMA.

Default 2-3

W69 Write protect Flash BIOS programing : W69 - installed
Update Flash BIOS Programming : W69 - open

W65 BIOS Recovery {DO NOT MOVE ! Removing this jumper will erase the BIOS !}

Cache configuration
Direct Mapped Write Through
=====

Cache	W20	W21	W52	W44
64K	N/C	N/C	N/C	2-3
256K	1-2	1-2	1-2	1-2

N/C = Not Connected