

```
1 connector for the front panel
2 JFRNT
3 A: Green LED
4 B: Reset
5 C: IDE LED
6 D: PWR BTN
7 E: SMI S/W
8 F: Key Lock
9 G: PWR LED
10 H: SPEAKER
11
12 FSBCLK: AUTO | 133 | 100 | 66
13 JFSB0: NC | 1-2 | 1-2 | 2-3
14 JFSB1: NC | 1-2 | 2-3 | 2-3
15
16 RATIO | JF0 | JF1 | JF2 | JF 3
17 3.0 | 1-2 | 2-3 | 1-2 | 1-2
18 3.5 | 1-2 | 2-3 | 2-3 | 1-2
19 4.0 | 2-3 | 1-2 | 1-2 | 1-2
20 4.5 | 2-3 | 1-2 | 2-3 | 1-2
21 5.0 | 2-3 | 2-3 | 1-2 | 1-2
22 5.5 | 2-3 | 2-3 | 2-3 | 1-2
23 6.0 | 1-2 | 1-2 | 1-2 | 2-3
24 6.5 | 1-2 | 1-2 | 2-3 | 2-3
25 7.0 | 1-2 | 2-3 | 1-2 | 2-3
26 7.5 | 1-2 | 2-3 | 2-3 | 2-3
27 8.0 | 2-3 | 1-2 | 1-2 | 2-3
```