

NAVIGATOR

- Data Sheet
- BIOS Upgrades
- Driver Upgrades
- Jumper Settings
- Online Manual
- FAQs

PRODUCTS

HOME



Jumper Settings

- [SW1-SW8: CPU Frequency Selection](#)
- [Drawing of TD6NF motherboard, with the location of jumper settings.](#)

SW1-SW8: CPU Frequency Selection

SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	CPU Frequency
ON	OFF	ON	OFF	OFF	ON	ON	ON	Pentium Pro 150MHz
OFF	ON	OFF	ON	OFF	ON	ON	ON	Pentium Pro 166MHz
ON	OFF	ON	OFF	ON	OFF	ON	ON	Pentium Pro 180MHz
OFF	ON	OFF	ON	ON	OFF	ON	ON	Pentium Pro 200MHz

[Go to Top of Page](#)