

NAVIGATOR

- Data Sheet
- BIOS Upgrades
- Driver Upgrades
- Jumper Settings
- Online Manual
- FAQs

PRODUCTS

HOME



Jumper Settings

- [SW2\(1-5\): CPU Frequency Select](#)
- [SW2\(6\): AT Bus Clock Select](#)
- [SW3\(1-4\): CPU Voltage Selector](#)
- [JP1-JP2: CPU Type Select](#)
- [Drawing of TI5TH motherboard, with the location of jumper settings.](#)

SW2(1-5): CPU Frequency Select

For Intel Pentium CPUs

1	2	3	4	5	Bus Clock	CPU Frequency
ON	ON	ON	OFF	OFF	50MHz	75MHz
ON	OFF	ON	OFF	OFF	60MHz	90MHz
OFF	ON	OFF	OFF	OFF	66MHz	100MHz
ON	OFF	ON	ON	OFF	60MHz	120MHz
OFF	ON	OFF	ON	OFF	66MHz	133MHz
ON	OFF	ON	ON	ON	60MHz	150MHz
OFF	ON	OFF	ON	ON	66MHz	166MHz
ON	OFF	ON	OFF	ON	60MHz	180MHz
OFF	ON	OFF	OFF	ON	66MHz	200MHz

For Cyrix Pentium CPUs

1	2	3	4	5	Bus Clock	CPU Frequency
ON	ON	ON	ON	OFF	66MHz	100MHz/120+
OFF	OFF	OFF	ON	OFF	55MHz	110MHz/130+
ON	OFF	ON	ON	OFF	60MHz	120MHz/150+
OFF	ON	OFF	ON	OFF	66MHz	133MHz/166+

For AMD Pentium CPUs

1	2	3	4	5	Bus Clock	CPU Frequency
ON	ON	ON	OFF	OFF	50MHz	75MHz/P75
ON	OFF	ON	OFF	OFF	60MHz	90MHz/P90/PR120
OFF	ON	OFF	OFF	OFF	66MHz	100MHz/PR133

[Go to Top of Page](#)

SW2(6): AT Bus Clock Select

PCI Clock/4 (default setting)

SW2(6)	AT Clock
OFF	PCI Clock/3
ON	

[Go to Top of Page](#)

SW3(1-4): CPU Voltage Selector

SW3	ON	OFF
1	3.3-3.52V	OTHER
2	2.9V	OTHER
3	2.8V	OTHER
4	2.5V	OTHER

[Go to Top of Page](#)

JP1-JP2: CPU Type Select

JP1	JP2	CPU Type
ON	ON	P54C
OFF	OFF	P55C

[Go to Top of Page](#)

Copyright 1996 Taiwan Mycomp Co, Ltd. All Rights Reserved. Pentium and Pentium Pro are registered trademarks of Intel Corp. All other product and brand names are trademarks and/or registered trademarks of their respective companies.