

CPU Support and Jumper Setting for P/I-XP55T2P4 Motherboard

M/B Rev. 1.2 CPU Internal Clock Setting

CPU internal clock	JP12	JP13
1.5 x External Clock	open	open
2 x External Clock	open	short
2.5 x External Clock	short	short
3 x External Clock	short	open

M/B Rev. 1.3 CPU Internal Clock Setting

CPU internal clock	JP14	JP15
1.5 x External Clock	open	open
2 x External Clock	open	short
2.5 x External Clock	short	short
3 x External Clock	short	open

M/B Rev. 1.2 CPU External Clock Setting

CPU	Ext. clk	JP17	JP18	Int. clk
200Mhz	66Mhz	1&2	2&3	3x
180Mhz	60Mhz	2&3	1&2	3x
166Mhz	66Mhz	1&2	2&3	2.5x
150Mhz	60Mhz	2&3	1&2	2.5x
133Mhz	66Mhz	1&2	2&3	2x
120Mhz	60Mhz	2&3	1&2	2x
100Mhz	66Mhz	1&2	2&3	1.5x
90Mhz	60Mhz	2&3	1&2	1.5x
75Mhz	50Mhz	2&3	2&3	1.5x

M/B Rev. 1.3 CPU External Clock Setting

CPU	Ext. clk	JP18	JP19	Int. clk
200Mhz	66Mhz	1&2	2&3	3x
180Mhz	60Mhz	2&3	1&2	3x
166Mhz	66Mhz	1&2	2&3	2.5x
150Mhz	60Mhz	2&3	1&2	2.5x
133Mhz	66Mhz	1&2	2&3	2x
120Mhz	60Mhz	2&3	1&2	2x
100Mhz	66Mhz	1&2	2&3	1.5x
90Mhz	60Mhz	2&3	1&2	1.5x
75Mhz	50Mhz	2&3	2&3	1.5x

M/B Rev 1.2 CPU Volatge Setting

Voltage Type	JP3
STD/VR 3.3V -3.465V	2&3
VRE 3.4V - 3.6V	1&2

Voltage Type	JP4
STD/VR 3.3V -3.465V	2&3
VRE 3.4V - 3.6V	1&2