

Release Note

CPU Update

This release note contains general update information and CPU installation instructions for the following systems:

- Altos 500
- Altos 1100E
- Altos 12000
- Altos 21000
- Altos 9100B
- Altos 330
- Altos 1100

Before proceeding to the installation section for your system, read the following section for important general information that applies to all systems.

BU Code Utility Installation



You should only run the BU code utility when your BIOS does not support the CPU that you want to upgrade.

If, after you have upgraded your system, you consistently get the "CPU Clock Mismatch" and "Equipment Configuration Error" message during system boot up, check the CPU frequency multiplier in the BIOS. If the CPU frequency multiplier is correct, and you still get the error messages, follow the instructions below.

1. From your browser, go to the URL <http://www.acersupport.com> and click on downloads.
2. Select a server that matches your server model.
3. Click on BIOSUP6.EXE and save the file to your hard drive.
4. Insert a formatted, bootable floppy disk into the A:\ drive.
5. From the hard drive, execute BIOSUP6.EXE. This will extract the necessary files to the floppy disk.

