COLOR GRAPHICS DISPLAY ADAPTER - ASSY # 12-10067-XX

There are no switches to set on the Color graphics adapter.

CHARACTER SET JUMPER

E1-E2 Character set has vertical lines that are 2 dots wide

Remove E1-E2 for character set with vertical lines that are 1 dot wide