CN1	RESET SW
CN2	?
CN3	TURBO LED
CN4	TURBO
CN5	?
CN6	SPKR
CN7	PWR LED (1-3), KEY LCK (4-5)

CLK:	2MHz	4MHz	4MHz	8MHz	8MHz	16MHz	20MHz	25MHz	33MHz	40MHz	40MHz	50MHz	50MHz	66MHz	80MHz	100MHz
LCLK:	2MHz	2MHz	4MHz	4MHz	8MHz	8MHz	20MHz	25MHz	33MHz	20MHz	40MHz	25MHz	50MHz	33MHz	40MHz	50MHz
JP8	open	open	closed	closed	closed	closed	open	closed	closed	open	open	closed	open	closed	open	open
JP9	open	open	open	open	closed	closed	closed	open	closed	closed	open	open	closed	closed	open	closed
JP10	open	open	open	open	closed	closed	closed	closed	open	closed	closed	closed	open	open	closed	open
JP15	2-3	1-2	2-3	1-2	2-3	1-2	2-3	2-3	2-3	1-2	2-3	1-2	2-3	1-2	1-2	1-2

Vcc	5,2V	3,45V
JP44	1-2	2-3
JP45	1-2	2-3
JP46	1-2	2-3