SUPER P54CI-PCI

CPU	75	90	100	120	133
JP8	OFF	ON	ON	ON	ON
JP10	OFF	OFF	ON	OFF	ON
JP18	OFF	OFF	OFF	ON	ON