

***MS - 9245***  
***1U Rackmount Server***  
***User's Guide***

Version 1.0  
G52-S9245X1

Manual Rev: 1.0  
Release Date: August 2003



## **FCC-A Radio Frequency Interference Statement**

---

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.


### **Notice 1**

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Notice 2**

Shielded interface cables and A.C. power cord, if any, must be used in order to comply with the emission limits.

**VOIR LA NOTICE D'INSTALLATION AVANT DE RACCORDER AU RESEAU.**



## Copyright Notice

---

The material in this document is the intellectual property of **MICRO-STAR INTERNATIONAL**. We take every care in the preparation of this document, but no guarantee is given as to the correctness of its contents. Our products are under continual improvement and we reserve the right to make changes without notice.

## Trademarks

---

All trademarks are the properties of their respective owners.

AMD, Athlon™, Athlon™ XP, Thoroughbred™, Duron™ and Opteron™ are registered trademarks of AMD Corporation.

Intel® and Pentium® are registered trademarks of Intel Corporation.

PS/2 and OS®/2 are registered trademarks of International Business Machines Corporation.

Windows® 95/98/2000/NT/XP/2003 are registered trademarks of Microsoft Corporation.

Netware® is a registered trademark of Novell, Inc.

Award® is a registered trademark of Phoenix Technologies Ltd.

AMI® is a registered trademark of American Megatrends Inc.

## Revision History

---

Revision	Revision History	Date
V1.0	First Release	August 2003

## Technical Support

---

If a problem arises with your system and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please try the following help resources for further guidance.

- 🔍 Visit the MSI website for FAQ, technical guide, BIOS updates, driver updates, and other information: <http://www.msi.com.tw/>
- 📧 Contact our technical staff at: [support@msi.com.tw](mailto:support@msi.com.tw)

## Safety Instructions

---

1. Always read the safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Keep this equipment away from humidity.
4. Lay this equipment on a reliable flat surface before setting it up.
5. The openings on the enclosure are for air convection hence protects the equipment from overheating. **DO NOT COVER THE OPENINGS.**
6. Make sure the voltage of the power source and adjust properly 110/220V before connecting the equipment to the power inlet.
7. Place the power cord such a way that people can not step on it. Do not place anything over the power cord.
8. Always Unplug the Power Cord before inserting any add-on card or module.
9. All cautions and warnings on the equipment should be noted.
10. Never pour any liquid into the opening that could damage or cause electrical shock.
11. If any of the following situations arises, get the equipment checked by a service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the equipment.
  - The equipment has been exposed to moisture.
  - The equipment has not work well or you can not get it work according to User's Manual.
  - The equipment has dropped and damaged.
  - The equipment has obvious sign of breakage.
12. **DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT UNCONDITIONED, STORAGE TEMPERATURE ABOVE 60°C (140°F), IT MAY DAMAGE THE EQUIPMENT.**



**CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

# CONTENTS

FCC-B Radio Frequency Interference Statement .....	ii
Copyright Notice .....	iii
Revision History .....	iii
Technical Support .....	iii
Safety Instructions .....	iv
<b>Chapter 1 Getting Started .....</b>	<b>1-1</b>
System Specifications .....	1-2
Mainboard Layout .....	1-6
Packing Checklist .....	1-7
System Configuration .....	1-8
Front View .....	1-8
Rear View .....	1-9
Top View .....	1-14
<b>Chapter 2 Hardware Setup .....</b>	<b>2-1</b>
Central Processing Unit: CPU .....	2-2
Thermal Issue for CPU .....	2-2
CPU Installation Procedures for Socket 940 .....	2-3
Memory .....	2-4
DIMM Module Combination .....	2-4
Installing DDR Modules .....	2-5
Power Supply .....	2-6
18-pin Main Power Supply Connector: J10 .....	2-6
14-pin Standby and Status Control Connector: J11 .....	2-6
24-pin SCSI Power and I2C Connectors: J12 .....	2-6
4-pin CD-ROM Power Connector: J14 .....	2-6
6-pin Front Plane USB Connector: J15 .....	2-6
Connectors .....	2-8
SM Card 3rd I2C Bus Connector: JSMB1 .....	2-8
Front Panel Connector: J13 .....	2-8
Hard Disk Connectors: IDE1 & IDE 2 .....	2-9
Fan Power Connectors .....	2-10

Ultra320 SCSI Connector: SCSI11 .....	2-11
Server Management Card Connectors: J16 .....	2-12
Rear Status LED: J20 .....	2-13
Jumpers .....	2-14
Clear CMOS Jumper: JBAT1 .....	2-14
Boot Block Jumper: JBBF1 .....	2-14
Slots .....	2-15
PCI Slot .....	2-15
PCI Interrupt Request Routing .....	2-15
<b>Chapter 3 BIOS Setup .....</b>	<b>3-1</b>
Entering Setup .....	3-2
Control Keys .....	3-2
Getting Help .....	3-3
The Menu Bar .....	3-4
The Main Menu .....	3-6
The Advanced Menu .....	3-8
The Security Menu .....	3-18
The Power Menu .....	3-20
The Boot Menu .....	3-22
The Exit Menu .....	3-23
<b>Chapter 4 Chassis Installation .....</b>	<b>4-1</b>
System Assembly .....	4-2
Chassis Cover .....	4-2
CPU and Heatsink .....	4-3
DIMM .....	4-5
PCI Cards .....	4-6
IDE Hard Disks .....	4-8
Hot Swap SCSI Hard Disks .....	4-12
Rack Mounting .....	4-14



# *Getting Started*

Congratulations on your purchase of the MS-9245 1U Rackmount Server Barebone! Designed to fit the dual AMD Opteron processors in Socket 940, the MS-9245 1U Rackmount Server provides the most efficient and professional solution to meet your needs.

## System Specifications

### Mainboard

- MSI-9145 mainboard

### CPU

- Supports Dual AMD Opteron DP or Single Opteron UP up to 2.4GHz with 800MHzFSB

### Chipset

- AMD 8111 I/O bridge
- AMD 8131 PCI-X Hub

### 2D/3D graphics controller

- ATI Rage XL Video Controller with 8 MB of memory

### Memory

- Supports up to 6 Registered ECC DDR200/266/333 DIMMs
- 2GB per DIMM for a maximum memory size of 12 GB

### PCI Slot

- PCI-X 64-bit 100MHz x 2
  - one full length and one half length PCI slots

### Drive Bays

- 2 Hot-Swap SCSI (or Non-hotswap IDE) HDD
- 1 Slim CD-ROM

### Front I/O

- 2 USB ports

### Rear I/O

- 2 USB ports
- 1 VGA port
- 1 serial port
- 2 RJ-45 LAN jacks

**SCSI (optional)**

- ▶ Single channel SCSI Ultra320 (LSI 1020)

**LAN**

- ▶ Broadcom 2 ports Gigabit LAN (BCM5704C)

**IDE**

- ▶ 2 IDE connectors, supporting up to 4 ATA-100/133 compatible devices

**MSI Server Management IPMI 1.5 (optional)**

- ▶ MSI-9549 BMC card (with QLogic Zircon UL BMC) and MSI iConsole 1.5 AP support IPMI 1.5 (option)

**FAN**

- ▶ 4 pcs, 40 x 20 mm system fan
- ▶ 1 pc, 40 x 20mm I/O fan
- ▶ 3 pcs integrated into power supply

**Power Supply**

- ▶ 411W max.
- ▶ Active PFC
- ▶ Full range 100 ~ 240V AC

**Dimension (WxDxH)**

- ▶ 440(W) x 660(D) x 43(H) mm

**Others**

- ▶ High Performance Thermal Solution

## **MS-9549 BMC Card Specification**

BMC Chip :

- Qlogic Zircon UL ( ARM7 TDMI 40M RISC ), 128pin PQFP
- Host hardware interface : LPC interface
- Host software interface : KCS interface

Memory Size

- 256 X 16 Bits SRAM
- 4M Bits Flash

Form Factor:

- Add-on Card on SO-DIMM (144 pin , Key position in 50)

On-board I2Cmux

- 9545

On board Connector/Header:

- JTAG header (14 pin) for debugging

Key Features:

- IPMI 1.5 Compliant
- Out-of-band LAN based management using RMCP
- FRU/SEL access
- Remote out-of-band alerts
- Event log
- Support for CLI (command line interface) over Serial or shared NIC (RMCP)
- Ability to update firmware inband unattended
- Remote access security
- Out-of-band environmental monitoring and alerting
- Secure remote power control and system reset over Serial or shared NIC (RMCP)
- Support Microsoft EMS
- Support on-board I2C ADM 1027 to extend Hardware monitor feature
- Virtual Storage ( Optional)

System Management:

Two SMBus 2.0 (I2C)

One SMBus for Broadcom 5704C

One SMBus for ADM 1027 , EEPROM access , CPU thermal sensor

CPU Fan speed control dependent on System Temperature  
System Fan speed control dependent on System Temperature

Sensor Management

Monitored Voltage: +12V, +5V, +3.3V, Vcore, 5V standby, +2.5V

Thermal protection (CPU/System overheat shut down through BMC)


No Chassis Intrusion

LED x 6 ( Power , DASD , Fault , ID\_LED , BMC Heartbeat )

On-Board Diagnostic LED ( 6X Memory DIMM ,2X CPU , 5XFAN )

Support shared NIC (Broadcom 5704C)

# Mainboard Layout




MS-9145 v1.X Mainboard



## System Configuration


This section shows the configuration of the MS-9245 from different angles, and the connectors and buttons on the front and back panel.

### Front View



1. Slim CD-ROM (optional)
2. **Hot Swap 80-pin SCSI HDD:** HDD 1 (ID0)  
**IDE HDD:** HDD 2 (Primary Slave)
3. **Hot Swap 80-pin SCSI HDD:** HDD 2 (ID1)  
**IDE HDD:** HDD 1 (Primary Master)
4. USB Port 1
5. USB Port 2
6. (from left to right) IDE HDD Activity LED, Location LED, Info LED & Error LED\*\*
7. Reset Button
8. Power Button
9. Power LED\*

## Rear View



1. AC Power Connector
2. Half Length PCI Slot 2
3. Full Length PCI Slot 1
4. Serial Port
5. VGA Port
6. (from left to right) USB Port 3 & USB Port 4
7. (from left to right) Gbit Port 2 & Gbit Port 1
8. Power LED\*
9. NMI Switch
10. ErrorLED\*\*



### NOTE

\* Please refer to Table 1. MS-9245 Front Bezel & Rear I/O LEDs Definitions for more information on Power LED.

\*\* Please refer to Table 2. MS-9245 System Error and Diagnostic LEDs Definitions for more information on Error LED.

**Table 1. MS-9245 Front Bezel & Rear I/O LEDs Definitions**

<b>LED</b>	<b>Color</b>	<b>State</b>	<b>Description</b>
Power	Green	ON	System operating
		Blink	System main power off and standby power on
	OFF	OFF	AC power removed
IDE HDD Activity	Green	Random blink	IDE HDD access activity
	OFF	OFF	No disk activity
Error	Amber	ON	Some component error/failure
	OFF	OFF	System normal operation
Location (Controlled by MSI iConsole AP only)	Blue	ON	Identify active via iConsole command
	OFF	OFF	No identification
Information	Amber		Reserved for new BIOS function upgrade
Swappable SCSI HDD Access	Green	Random blink	HDD access activity
	OFF	OFF	No disk activity
Swappable SCSI HDD Diagnostic	Red	ON	HDD failure
	OFF	OFF	HDD normal operation

**Table 2. MS-9245 System Error and Diagnostic LEDs Definitions**

<b>Item</b>	<b>Error LED</b>	<b>Diagnostic LED</b>	<b>Description/Symptoms</b>
1	OFF	OFF	Normal operation
2	ON	CPU Error LED ON	Processor related problems
3	ON	SCSI Error LED ON	SCSI hard drive Error/failure
4	ON	FAN Error LED ON	Fan failure
5	ON	Memory Error LED ON	Memory error/failure
6	ON	N/A	Power supply error/failure


### **Diagnostic LEDs**

Diagnostic LEDs use signal display to help users understand their system. When POST or Service Processor detects an error, the corresponding LEDs light up to alert the user to the condition and help service personnel identify the failing component. A system error single LED on the front panel and in the rear of the system first alerts the users that an error has occurred. Service personnel next check inside the system to determine which subsystem has an error LED lit. This information helps the service personnel to locate the failing component for replacement. The full failing path remains lit until POST no longer exists or the error is fixed.

The Rear Panel provides the following connectors:

### LAN (RJ-45) Jacks: Giga-bit LAN

The mainboard provides two standard RJ-45 jacks for connection to Local Area Network (LAN). Giga-bit LAN enables data to be transferred at 1000, 100 or 10Mbps. You can connect a network cable to either LAN jack.




Giga-bit LAN Pin Definition

PIN	SIGNAL	DESCRIPTION
1	D0P	Differential Pair 0+
2	D0N	Differential Pair 0-
3	D1P	Differential Pair 1+
4	D2P	Differential Pair 2+
5	D2N	Differential Pair 2-
6	D1N	Differential Pair 1-
7	D3P	Differential Pair 3+
8	D3N	Differential Pair 3-

### USB Connectors

The mainboard provides a UHCI (Universal Host Controller Interface) Universal Serial Bus root for attaching USB devices such as keyboard, mouse or other USB-compatible devices. You can plug the USB device directly into this connector.




USB Port

USB Port Description

PIN	SIGNAL	DESCRIPTION
1	VCC	+5V
2	-Data 0	Negative Data Channel 0
3	+Data0	Positive Data Channel 0
4	GND	Ground


## Serial Port Connectors: COM 1 & COM 2 (optional)

The mainboard offers two 9-pin DIN connectors for serial ports COM 1 and COM 2. The ports are 16550A high speed communication ports that send/receive 16 bytes FIFOs. You can attach a serial mouse or other serial devices directly to them.



**COM 1 Pin Definition**

PIN	SIGNAL	DESCRIPTION
1	DCD	Data Carry Detect
2	SIN	Serial In or Receive Data
3	SOUT	Serial Out or Transmit Data
4	DTR	Data Terminal Ready)
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicate




**COM 2 Pin Definition**

PIN	DESCRIPTION	PIN	DESCRIPTION
1	Data Carrier Detect	2	Receive Data
3	Transmit Data	4	Data Terminal Ready
5	Ground	6	Data Set Ready
7	Request to Send	8	Clear to Send
9	Ring Indicator	10	Ground

## VGA Connector

The mainboard provides a DB 15-pin female connector to connect a VGA monitor.



Pin	Signal Description
1	RED
2	GREEN
3	BLUE
4	N/C
5	GND
6	GND
7	GND
8	GND
9	+5V
10	GND
11	N/C
12	SDA
13	Horizontal Sync
14	Vertical Sync
15	SCL

## Top View



1. Proprietary Power Supply
2. Slim CD-ROM Drive
3. DIMM Slots
4. PCI Slots
5. CPU Sockets
6. Fan Duct
7. AC Power Connector

# 2

## *Hardware Setup*


This chapter tells you how to install the CPU, memory modules, and expansion cards, as well as how to setup the jumpers on the mainboard. Also, it provides the instructions on connecting the peripheral devices, such as the mouse, keyboard, etc.

While doing the installation, be careful in holding the components and follow the installation procedures.

## Central Processing Unit: CPU

The mainboard supports **Single** AMD® Opteron UP or **Dual** AMD® Opteron DP™ processor(s). The mainboard uses two CPU sockets called Socket 940 for easy CPU installation. You can install SINGLE or DUAL CPUs on the mainboard to meet your own needs. Keep the following points in mind before installing CPU(s):

1. If **SINGLE** CPU is intended, always install the CPU on the **U1** socket.



2. To install **DUAL** CPUs on the board, you must use **the same type/stepping of AMD Opteron DP™ CPUs running at the same frequency**.



### **WARNING!** Thermal Issue for CPU

As processor technology pushes to faster speeds and higher performance, thermal management becomes increasingly crucial when building computer systems. Maintaining the proper thermal environment is key to reliable operation. As such, the processor must be maintained in the specified thermal requirements.





AMD Opteron UP or Opteron DP processor(s) with a speed of **600MHz and above** requires a **LARGER** heatsink and fan. You also need to add thermal grease between the CPU and heatsink to improve heat dissipation. Then, make sure that the CPU and heatsink are securely fastened and in good contact with each other. These are needed to prevent damaging the processor and ensuring reliable operation. If you want to get more information on the proper cooling, you can visit AMD's website for reference.

## CPU Installation Procedures for Socket 940

1. Make sure that the computer is turned off, and the power cord disconnected before installing the CPU.
2. Pull the lever sideways away from the socket, and raise it up to a 90-degree angle.
3. Locate the cut edge of the CPU. When the CPU is installed into the socket, this cut edge should be aligned with the corner marking an arrow on the Socket 940.


Please note that the CPU can only fit in a correct orientation, **DO NOT** use force to install the CPU into the socket.

4. Place the CPU onto the socket and press it down firmly into the socket. The pins of the CPU should be embedded into the socket completely.
5. Close the lever to secure the CPU. Do not close the level until the CPU's pins are fully inserted; otherwise, the pins may be damaged.



## Memory

The mainboard supports up to six registered ECC DDR200/266/333 DIMMs providing up to 12GB of memory. Each DIMM slot supports up to a maximum size of 2GB. You can install either single- or double-sided modules to meet your own needs.



DDR DIMM Slots

### DIMM Module Combination

You can install either one or two DIMM modules on the slots. **Use Slot 1, 3 or 6 for single DDR module installation.** If the DDR module(s) is(are) installed on Slot 5 or(and) 6, CPU2 must be installed.

Memory modules can be installed in any combination as follows:

Slot	Memory Modules						
DDR6	Install	Install	Install			Install	
DDR5	Install	Install	Install			Install	
DDR4		Install	Install	Install			Install
DDR3		Install	Install	Install			Install
DDR2			Install		Install	Install	Install
DDR1			Install		Install	Install	Install




**NOTE**

Memory modules “in pairs” must be of the same type and size.

## Installing DDR Modules

1. The DDR DIMM has only one notch on the center of module. The module will only fit in the right orientation.
2. Insert the DIMM memory module vertically into the DIMM slot. Then push it in until the golden finger on the memory module is deeply inserted in the socket.
3. The plastic clip at each side of the DIMM slot will automatically close.



### NOTE

*You can barely see the golden finger if the module is properly inserted in the socket.*

## Power Supply

The mainboard supports SSI power supply for the power system. Before inserting the power supply connector, always make sure that all components are installed properly to ensure that no damage will be caused.

### 18-Pin Main Power Supply Connector: J10

This connector provides power supply to the system board.

### 14-Pin Standby and Status Control Connector: J11

This connector provides power supply to the system board.

### 24-Pin SCSI Power and I2C Connector: J12


This connector is an optional power connector to provide power output to the SCSI HDD.





### 4-Pin CD-ROM Power Connector: J14

This connector provides power supply to the CD-ROM Drive.

### 6-Pin Front Plane USB Connector: J15

This connector provides power supply to the front USB ports.








## Hard Disk Connectors: IDE1 & IDE2

The mainboard has a 32-bit Enhanced PCI IDE and Ultra DMA 33/66/100/133 controller that provides PIO mode 0~4, Bus Master, and Ultra DMA 33/66/100/133 function. You can connect up to four hard disk drives, CD-ROM, 120MB Floppy (reserved for future BIOS) and other devices.



### IDE1 (Primary IDE Connector)

The first hard drive should always be connected to IDE1. IDE1 can connect a Master and a Slave drive. You must configure second hard drive to Slave mode by setting the jumper accordingly.

### IDE2 (Secondary IDE Connector)

IDE2 can also connect a Master and a Slave drive.




#### NOTE

*If you install two hard disks on cable, you must configure the second drive to Slave mode by setting its jumper. Refer to the hard disk documentation supplied by hard disk vendors for jumper setting instructions.*

## Fan Power Connectors: SFAN1/SFAN2/SFAN3/SFAN4/SFAN5

The SFAN1/SFAN2/SFAN3/SFAN4/SFAN5 (system fans) support system cooling fan with +12V. It supports three-pin head connector. When connecting the wire to the connectors, always take note that the red wire is the positive and should be connected to the +12V, the black wire is Ground and should be connected to GND. If the mainboard has a System Hardware Monitor chipset on-board, you must use a specially designed fan with speed sensor to take advantage of the CPU fan control.




### NOTE

1. Always consult the vendors for proper CPU cooling fan.
2. SFAN supports the fan control. MS-9245 will automatically control the CPU fan speed according to the system temperature.

## Ultra320 SCSI Connector: SCSI 1

SCSI (Small Computer System Interface) is a hardware interface that allows for connection of up to 15 peripheral devices. The mainboard provides one SCSI channel (SCSI 1) for you to connect SCSI devices such as SCSI hard disks.



**68-Pin Ultra320 SCSI Connector**

Pin	Description	Pin	Description
1	+DB(12)	35	-DB(12)
2	+DB(13)	36	-DB(13)
3	+DB(14)	37	-DB(14)
4	+DB(15)	38	-DB(15)
5	+DB(P1)	39	-DB(P1)
6	+DB(0)	40	-DB(0)
7	+DB(1)	41	-DB(1)
8	+DB(2)	42	-DB(2)
9	+DB(3)	43	-DB(3)
10	+DB(4)	44	-DB(4)
11	+DB(5)	45	-DB(5)
12	+DB(6)	46	-DB(6)
13	+DB(7)	47	-DB(7)
14	+DB(P)	48	-DB(P)
15	GROUND	49	GROUND
16	DIFFSENS	50	GROUND
17	TERMPWR	51	TERMPWR
18	TERMPWR	52	TERMPWR
19	RESERVED	53	RESERVED
20	GROUND	54	GROUND
21	+ATN	55	-ATN
22	GROUND	56	GROUND
23	+BSY	57	-BSY
24	+ACK	58	-ACK
25	+RST	59	-RST
26	+MSG	60	-MST
27	+SEL	61	-SEL
28	+C/D	62	-C/D
29	+REQ	63	-REQ
30	+I/O	64	-I/O
31	+DB(8)	65	-DB(8)
32	+DB(9)	66	-DB(9)
33	+DB(10)	67	-DB(10)
34	+DB(11)	68	-DB(11)

## Server Management Card Connector: J16

This connector allows you to insert a Server Management Card.




J16

1	COM1_DI(I)	LPC_AD0	2
3	COM1_RST#(O)	LPC_AD1	4
5	COM1_DCD#(I)	LPC_AD2	6
7	COM1_RI#(I)	LPC_AD3	8
9	COM1_CTS#(I)	GND	10
11	COM1_DO(O)	(I)LPC_CLK	12
13	COM1_DTR#(O)	LPC_RST#	14
15	COM1_DSR#(I)	LPC_FRAME#	16
X 17	COM1_ENSW#(O)	GND	18
19	COM2_ENSW#(O)	(O)LPC_INT#	20
21	COM_BUS_EXCH(O)	(O)LPC_DRQ#	22
23	POST/I2C_ACK#(O)	(I)POST/I2C_REQ#	24
25	SVSB_VDD_ANALOG	5VSB	26
27	FAN_TACH0(I)	(O)FAN_PWM0	28
29	FAN_TACH1(I)	(O)FAN_PWM1	30
31	FAN_TACH2(I)	(O)FAN_PWM2	32
33	FAN_TACH3(I)	(O)FAN_PWM3	34
35	FAN_TACH4(I)	(O)FAN_PWM4	36
37	FAN_TACH5(I)	(O)FAN_PWM5	38
39	NC	NC	40
41	NC	NC	42
43	NC	NC	44
45	NC	(I)GP_INT1#	46
47	NC	(I)GP_INT2#	48
49	NC	(I)GP_INT3#	50
NC	(I)GP_INT4#	52	X
51	GND_ANALOG	GND	54
53	I2C_0_SDA	I2C_1_SDA	56
55	I2C_0_SCL	I2C_1_SCL	58
57	I2C_0_INT#	(I)I2C_1_INT#	60
59	3VSB_ANALOG	3.3VSB	62
61	I2C_2_SDA	I2C_3_SDA	64
63	I2C_2_SCL	I2C_3_SCL	66
65	I2C_2_INT#(I)	(I)I2C_3_INT#(I)	68
67	SB_PWR_PG(I)	EPW#	70
69	Main_PWR_PG(I)	(I)SYS_RST#	72
71	ANALOG_VOLT0(I)	(O)SYS_RST_OUT	74
73	ANALOG_VOLT1(I)	(O)SYS_PWRON_OUT	76
75	ANALOG_VOLT2(I)	(I)SYS_PWRON_IN	78
77	ANALOG_VOLT3(I)	(O)BMC_WD#	80
79	ANALOG_VOLT4(I)	(I)FEA_DET0	82
81	ANALOG_VOLTS(I)	(I)FEA_DET1	84
83	ANALOG_VOLTS6(I)	(O)I2C_0_RST#	X 86
85	ANALOG_VOLT7(I)_BAT	(O)I2C_2_RST#	88
87	RTS_SEN#(O)	(O)I2C_2_MUX_DIS#	90
89	3.3VSB_ANALOG	3.3VSB	92
X 91	NC	NC	X 94
93	INSERT_DET(I)	LED0	96
95	BMC_VER#(O)	LED1	98
97	BMC_VER#(O)	LED2	100
99	PLAN_LVL0(I)	LED3	102
101	PLAN_LVL1(I)	LED4	104
103	PLAN_LVL2(I)	LED5	106
105	PLAN_LVL3(I)	LED6	108
107	SYS_ID0(I)	LED7	110
109	SYS_ID1(I)	NC	X 112
111	SYS_ID2(I)	NC	X 114
113	SYS_ID3(I)	NC	X 116
115	SYS_ID4(I)	NC	X 118
X 117	NC	NC	X 120
X 119	NC	NC	X 122
X 121	NC	NC	X 124
123	GND	GND	126
X 125	485+	NC	X 128
X 127	GND	GND	X 130
129	PWR_BTN_IN(I)	NC	X 132
131	PWR_BTN_OUT(O)	NC	134
133	BMC_Heartbeat(O)	(I)SYS_RTC	136
135	BMC_SMI#	(I)REM_BTN_IN	138
137	SYS_NMI#(I)	(I)HD_ACT#	140
139	COM_EXCH_DIS(O)	(I)I2C_DIS_ALL	142
141	COM_SHUT(O)	(I)I2C_MEM_SW	144
143	5VSB	5VSB	

SODIMM144\_8MMP

## **Rear Status LED: J20**

The LED shows the error and power status.



## Jumpers

### Clear CMOS Jumper: JBAT1

If you want to clear the system configuration, use the JBAT1 (Clear CMOS Jumper) to clear data.



**JBAT1**



Keep Data



Clear Data



#### NOTE

*You can clear CMOS by shorting 2-3 pin while the system is off. Then return to 1-2 pin position. Avoid clearing the CMOS while the system is on; it will damage the mainboard.*

### Boot Block Jumper: JBBF1

User can short connect pin#2-3 to recover the system BIOS with a Recovery Floppy. When the system is done with the job, the buzzer will notice the user and set the jumper to its normal state (pin#1-2 short connected).



**JBBF1**



Normal



Recovery

## Slots

The motherboard provides two PCI-X 64/100MHz slots. One is full length and the other is half length.

### PCI Slots

Two PCI slots allow you to insert the expansion cards to meet your needs. When adding or removing expansion cards, make sure that you unplug the power supply first. Meanwhile, read the documentation for the expansion card to make any necessary hardware or software settings for the expansion card, such as jumpers, switches or BIOS configuration.

### PCI Interrupt Request Routing

The IRQ, abbreviation of interrupt request line and pronounced I-R-Q, are hardware lines over which devices can send interrupt signals to the microprocessor. The PCI IRQ pins are typically connected to the PCI bus INT A# ~ INT D# pins as follows:

**IRQ Routing**

Devices	Order 1	Order 2	Order 3	Order 4
PCI Slot 1	INT A#	INT B#	INT C#	INT D#
PCI Slot 2	INT D#	INT A#	INT B#	INT C#
LAN	INT A#	INT B#	\	
VGA	INT A#			
SCSI	INT A#			

Primary IDE Interrupt: IRQ14 (for AMD8111)

Secondary IDE Interrupt: IRQ15 (for AMD8111)

# 3

## ***BIOS Setup***

This chapter provides information on the BIOS Setup program and allows you to configure the system for optimum use. You may need to run the Setup program when:

- ◆ An error message appears on the screen during the system booting up, and requests you to run SETUP.
- ◆ You want to change the default settings for customized features.

## Entering Setup

Power on the computer and the system will start POST (Power On Self Test) process. When the message below appears on the screen, press <F2> key to enter Setup.

Press F2 to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system by turning it OFF and On or pressing the RESET button. You may also restart the system by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

## Control Keys

Key	Function
<F1> or <Alt-H>	General Help window
<Esc>	Exit this menu
← or → arrow keys	Select a different menu
↑ or ↓ arrow keys	Move cursor up and down
<Tab> or <Shift-Tab>	Cycle cursor up and down
<Home> or <End>	Move cursor to top or bottom of window
<PgUp> or <PgDn>	Move cursor to next or previous page
<F5> or <->	Select the Previous Value for the field
<F6> or <+> or <Space>	Select the Next Value for the field
<F9>	Load the Default Configuration values for this menu
<F10>	Save and exit
<Enter>	Execute Command or Enter Submenu

## Getting Help

After entering the Setup menu, the first menu you will see is the Main Menu.

### Main Menu

The main menu lists the setup functions you can make changes to. You can use the arrow keys (↑↓) to select the item. The on-line description of the highlighted setup function is displayed at the bottom of the screen.

### Sub-Menu

If you find a right pointer symbol (as shown in the right view) appears to the left of certain fields that means a sub-menu can be launched from this field. A sub-menu contains additional options for a field parameter. You can use arrow keys (↑↓) to highlight the field and press <Enter> to call up the sub-menu. Then you can use the control keys to enter values and move from field to field within a sub-menu. If you want to return to the main menu, just press the <Esc>.

- IDE Primary Master
- IDE Primary Slave
- IDE Secondary Master
- IDE Secondary Slave

### General Help <F1>

The BIOS setup program provides a General Help screen. You can call up this screen from any menu by simply pressing <F1>. The Help screen lists the appropriate keys to use and the possible selections for the highlighted item. Press <Esc> to exit the Help screen.



#### **MSI Reminds You...**

*The items under each BIOS category described in this chapter are under continuous update for better system performance. Therefore, the description may be slightly different from the latest BIOS and should be held for reference only.*

## The Menu Bar

Once you enter **PhoenixBIOS Setup Utility**, the Main Menu will appear on the screen. On the Main Menu screen, you will see basic BIOS settings including system time & date, and the setup categories the BIOS supplies. Use Arrow keys to move among the items and menus, and make changes to the settings.

PhoenixBIOS Setup Utility			
Main	Advanced	Security	Power Boot Exit
			Item Specific Help
System Time		[09:10:11]	<Tab>, <Shift+Tab>, or <Enter>selects field.
System Date		[05/25/2003]	
▶ IDE Primary Master		[None]	
▶ IDE Primary Slave		[None]	
▶ IDE Secondary Master		[CD-ROM]	
▶ IDE Secondary Slave		[None]	
Large Disk Access Mode :		[DOS]	
Boot Summary Screen :		[Disabled]	
System Memory :		624KB	
Extended Memory :		510MB	
F1 Help	↑↓ Select Item	-/+ Change Values	F9 Setup Defaults
Esc Exit	←→ Select Menu	Select ▶ Sub-Menu	F10 Save and Exit

### Main Menu

Use this menu for basic system configurations, such as time, date etc.

### Advanced Menu

Use this menu to set up the items of special enhanced features available on your system's chipset.

### Security Menu

Use this menu to set Supervisor and User Passwords and the Backup and Virus-Check reminders.

**Power Menu**

Use this menu to specify your settings for power management.

**Boot Menu**

Use this menu to specify the priority of boot devices.

**Exit Menu**

This menu allows you to load the BIOS default values or factory default settings into the BIOS and exit the BIOS setup utility with or without changes.

## The Main Menu

The items inside the Main menu are for basic system information and configuration. Each item includes none, one or more setup items. Use the Up/Down arrow keys or <Tab> to highlight the item or field you want to modify and use the <+> or <-> key to switch to the value you prefer.

PhoenixBIOS Setup Utility			
Main	Advanced	Security	Power Boot Exit
System Time [09:10:11] System Date [05/25/2003]			Item Specific Help
▶ IDE Primary Master [None] ▶ IDE Primary Slave [None] ▶ IDE Secondary Master [CD-ROM] ▶ IDE Secondary Slave [None] Large Disk Access Mode : [DOS]			<Tab>, <Shift+Tab>, or <Enter> selects field.
Boot Summary Screen : [Disabled]			
System Memory : 624KB Extended Memory : 510MB			
F1 Help	↑↓ Select Item	-/+ Change Values	F9 Setup Defaults
Esc Exit	↔ Select Menu	Select ▶ Sub-Menu	F10 Save and Exit

### System Time

The time format is <HH> <MM> <SS>.

### System Date

The date format is <MM> <DD> <YYYY>.

### Primary/Secondary Master/Slave

Press PgUp/<+> or PgDn/<-> to select *Manual*, *None* or *Auto* type. Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category. If your hard disk drive type is not matched or listed, you can use *Manual* to define your own drive type manually.

If you select *Manual*, related information is asked to be entered to the following items. Enter the information directly from the keyboard. This information should be provided in the documentation from your hard disk vendor or the system manufacturer.

Type	Select how to define the HDD parameters
Multi-Sector Transfers	Any selection except Disabled determines the number of sectors transferred per block
LBA Mode Control	Enabling LBA causes Logical Block Addressing to be used in place of Cylinders, Heads and Sectors.
32-Bit I/O	Enables 32-bit communication between CPU and IDE card
Transfer Mode	Selects the method for transferring the data between the hard disk and system memory
Ultra DMA Mode	Indicates the type of Ultra DMA.

**Large Disk Access Mode**

Select DOS if you have DOS. Select Other if you have another operating system such as UNIX. A large disk is one that has more than 1024 cylinders, more than 16 heads, or more than 63 tracks per sector. Options: DOS, Other.

**Boot Summary Screen**

Selecting Enabled displays system summary screen during boot up. Options: Enabled, Disabled.

**System Memory**


It displays amount of conventional memory detected during boot up.

**Extended Memory**

It displays the amount of extended memory detected during boot up.

## The Advanced Menu

Items in the menu are divided into 7 sub-menus. Each sub-menu provides more settings. To enter the sub-menu, highlight the sub-menu you want to configure and press <Enter>.



### Install O/S

Select the operating system installed on your system which you will use most commonly. Options: Other, Win95, Win98, WinMe, Win2000.

### Reset Configuration Data

Select Yes if you want to clear the Extended System configuration Data (ESCD) area. Options: Yes, No.

### Multiprocessor Specification

This item allows you to configure the MP Specification revision level. Some operating systems will require 1.1 for compatibility reason. Options: 1.4, 1.1.

### Quick Boot Mode

This feature allows the system skip certain tests while booting. This will decrease the time needed to boot the system. Options: Enabled, Disabled.

### Chipset Configuration

The sub-menu is used to configure chipset features for optimal system performance.

PhoenixBIOS Setup Utility	
Advanced	
Chipset Configuration	Item Specific Help
<p>Setup Warning</p> <p>Setting items on this menu to incorrect values may cause your system to malfunction.</p> <p>Dram Bank Interleave : [AUTO]</p> <p>Node Memory Interleave : [Disabled]</p> <p>HPET Timer : [Enabled]</p> <p>ECC : [Enabled]</p> <p>Dram ECC : [Enabled]</p> <p>ECC Scrub Redirection : [Disabled]</p> <p>Chip-Kill: [Enabled]</p> <p>DCACHE ECC Scrub CTL [Disabled]</p> <p>L2 ECC Scrub CTL [Disabled]</p> <p>Dram ECC Scrub CTL [Disabled]</p>	
<p>Interleave memory blocks across dram chip selects.</p> <p>BIOS will AUTO detect capability on each Node.</p>	
<p>F1 Help      ↑↓ Select Item      -/+ Change Values      F9 Setup Defaults</p> <p>Esc Exit      ←→ Select Menu      Select ▸ Sub-Menu      F10 Save and Exit</p>	

#### Dram Bank Interleave

Interleave memory blocks across dram chip selects. Options: Auto, Disabled.

#### Node Memory Interleave

Interleave memory blocks across Processor Nodes. BIOS will AUTO detect the capability of Memory System. Options: Disabled, AUTO.

### **HPETTimer**

This item allows you to enable/disable HPET high precision event timer. Setting to Disabled will turn off the device and remove it from the ACPI namespace. Options: Enabled, Disabled.

### **ECC**

This is a global enable function for all blocks within CPU core and North Bridge. After loading setup defaults, restart and enter setup to access Dram ECC setup options. Options: Enabled, Disabled.

### **DramECC**

If all memory in the system supports ECC, enabling this will initial scrub dram and enable system requests to dram to be checked and/or corrected. Options: Enabled, Disabled.

### **ECC Scrub Redirection**

Enable Scrubber to correct errors detected in Dram during normal CPU requests (Foreground scrubbing). Options: Enabled, Disabled.

### **Chip-Kill**

This item allows you to enable/disable Chip-Kill ECC on Nodes with all x4 ECC capable dimms. Options: Enabled, Disabled.

### **DCACHEECCScrub CTL**

This feature sets the rate of background scrubbing for DCACHE lines. Options: Disabled, 40 ns, 80 ns, 160 ns, 320 ns, 640 ns, 1.28 us, 2.56 us.

### **L2ECCScrub CTL**

This feature sets the rate of background scrubbing for L2 cache lines. Options: Disabled, 40 ns, 80 ns, 160 ns, 320 ns, 640 ns, 1.28 us, 2.56 us.

### **Dram ECCScrub CTL**

This feature sets the rate of BACKGROUND scrubbing for Dram. (In addition to normal ECC scrubbing from system requests.) Options: Disabled, 1.31 ms, 2.62 ms, 5.24 ms, 10.49 ms, 20.97 ms, 42.0 ms, 84.0 ms.

**Note: BACKGROUND agent works independently of CPU requests and bus masters, but cannot be enabled without first enabling Dram ECC.**

## Keyboard Configuration

The sub-menu is used to configure keyboard features for optimal system performance.

PhoenixBIOS Setup Utility			
Advanced			
Keyboard Configuration		Item Specific Help	
NumLock :	[On]	Selects Power-on State for NumLock.	
Keyboard auto-repeat rate :	[30/sec]		
Keyboard auto-repeat delay :	[1/4 sec]		
F1 Help      ↑↓ Select Item      -/+ Change Values      F9 Setup Defaults Esc Exit      ←→ Select Menu      Select ▸ Sub-Menu      F10 Save and Exit			

### NumLock

On or Off turns NumLock on or off at boot up. auto turns NumLock on if it finds a numeric key pad. Options: On, Off.

### Keyboard auto-repeat rate

It sets the number of times a second to repeat a keystroke when you hold the key down. Options: 30/sec, 26.7/sec, 21.0/sec, 18.5/sec, 13.3/sec, 10/sec, 6/sec, 2/sec.

### Keyboard auto-repeat delay

It sets the delay time after the key is held down before it begins to repeat the keystroke. Options: 1/4 sec, 1/2 sec, 3/4 sec, 1 sec.

### I/O Device Configuration

The sub-menu is used to configure I/O Devices for optimal system performance.

PhoenixBIOS Setup Utility	
Advanced	
I/O Device Configuration	Item Specific Help
Serial port A : [Enabled] Base I/O address : [3F8] Interrupt : [IRQ 4] Serial port B : [Enabled] Base I/O address : [2F8] Interrupt : [IRQ 3]	Configure serial port A using options:  [Disabled] No configuration  [Enabled] User configuration  [Auto] BIOS or OS chooses configuration  (OS Controlled) Displayed when controlled by OS
F1 Help	↑↓ Select Item    -/+ Change Values    F9 Setup Defaults
Esc Exit	←→ Select Menu    Select ▸ Sub-Menu    F10 Save and Exit

#### Serial port A/B

Setting to Enabled allows users to configure the base I/O address and IRQ of Port A/Port B manually. Selecting Auto allows BIOS to automatically determine the correct base I/O port address. Options: Enabled, Disabled, Auto.

#### Base I/O address

It specifies the base I/O address for Port A/Port B. Options: 3F8, 2F8, 3E8, 2E8.

#### Interrupt

It specifies the interrupt for Port A/Port B. Options: IRQ 3, IRQ 4.

**PCI Configuration**

Press PgUp/<+> or PgDn/<-> to Console Redirection. The following submenu will appear.

PhoenixBIOS Setup Utility		
Advanced		
PCI Configuration		Item Specific Help
Onboard LAN Device	[Enabled]	Onboard LAN Device Enable/Disable.
Onboard SCSI Device	[Enabled]	
F1 Help      ↑↓ Select Item      -/+ Change Values      F9 Setup Defaults Esc Exit      ←→ Select Menu      Select ▸ Sub-Menu      F10 Save and Exit		

**Onboard LAN Device**

This feature allows you to enable/disable the onboard LAN device.  
Options: Enabled, Disabled.

**Onboard SCSI Device**

This feature allows you to enable/disable the onboard SCSI device.  
Options: Enabled, Disabled.

**Console Redirection**

Press PgUp/<+> or PgDn/<-> to Console Redirection. The following submenu will appear.

PhoenixBIOS Setup Utility	
Advanced	
Console Redirection	Item Specific Help
Com Port Address : [Disabled]	If enabled, it will use a port on the motherboard.
Console connection : [Direct]	
Baud Rate : [19.2K]	
Flow Control : [CTS/RTS]	
Console Type : [vt1008bit]	
Continue C.R. after POST : [On]	
F1 Help      ↑↓ Select Item      -/+ Change Values      F9 Setup Defaults Esc Exit      ←→ Select Menu      Select ▸ Sub-Menu      F10 Save and Exit	

**Com Port Address**

This feature allows you to enable/disable the Com port on the motherboard. Options: Disabled, On-board COM A.

**Console connection**

This feature indicates whether the console is connected directly to the system or a modem is used for connection. Options: Direct, Via modem.

**Baud Rate**

It allows you to select delay before key repeat. Options: 1/4 sec, 1/2 sec, 3/4 sec, 1 sec.

**Flow Control**

This feature allows you to enable flow control. Options: None, XON/

XOFF, CTS/RTS.

**Console Type**

This feature allows you to enable the specified console type. Options: vt100, vt100 8bit, ANSI 7bit, ANSI, ut100 plus, UTF8.

**Continue C. R. after POST**

Selecting On will enable Console Redirection after OS has loaded. Options: On, Off.

**POST Error Log**

Press PgUp/<+> or PgDn/<-> to POST Error Log. The following submenu will appear.

PhoenixBIOS Setup Utility	
Advanced	
POST Error Log	Item Specific Help
View DMI event log [Enter]	View the contents of the DMI event log.
Clear all DMI event logs [No]	
Event Logging [Enabled]	
F1 Help      ↑↓ Select Item      -/+ Change Values      F9 Setup Defaults Esc Exit      ←→ Select Menu      Select ▸ Sub-Menu      F10 Save and Exit	

**View DMI event log**

Press Enter to view the contents of the DMI event log.

**Clear all DMI event logs**

Setting this to Yes will clear the DMI event log after rebooting. Options: Yes, No.

**Event Logging**

Select Enabled to allow logging of DMI events. Options: Enabled, Disabled.

**IPMI**

Press PgUp/<+> or PgDn/<-> to IPMI. The following submenu will appear.

PhoenixBIOS Setup Utility		
Advanced		
IPMI		Item Specific Help
IPMI Specification Version	1.5	Select this line to en/disable COM port on BMC .
BMC Firmware Version	1.16	
COM port on BMC	[Disabled]	
Clear System Event Log	[Disabled]	
Existing Event Log number	127	
Remaining Event Log number	0	
SYS Firmware Progress	[Enabled]	
BIOS POST Watchdog	[Enabled]	
▶ System Event Log		
F1 Help	↑↓ Select Item	-/+ Change Values
Esc Exit	←→ Select Menu	Select ▶ Sub-Menu
		F9 Setup Defaults
		F10 Save and Exit

**IPMI Specification Version**

It shows the support version of IPMI specification. (read only)

**BMC Firmware Version**

It shows the current BMC firmware version.

**COM port on BMC**

Select this line to enable/disable COM port on BMC. Options: Disabled, IPMI, CLI.

**Clear System Event Log**

Enabling this selection will force the BIOS to clear the System Event Log on the next boot. Options: Disabled, Enabled.

**Existing Event Log number/Remaining Event Log number**

It shows the number of existing/remaining event log.

**SYS Firmware Progress**

Enabling this selection will log POST Progress. Options: Enabled, Disabled.

**BIOS POST Watchdog**

Enabling this selection will enable POST watchdog. Options: Enabled, Disabled.

**System Event Log**

Press Enter to display the System Event Log.

PhoenixBIOS Setup Utility	
Advanced	
System Event Log	Item Specific Help
SEL Entry Number = 1 SEL Record ID = 0010 SEL Record Type = 02 - System Event Record Timestamp = 07.29.2003 10:50:08 Generator Id = 20 00 SEL Message Rev = 04 Sensor Type = 01 - Temperature -- Sensor Number = 32 - TMP_S2 SEL Event Type = 81 - Upper Non-critical Going SEL Event Data = 57 24 2A	This is an entry in the System Event Log
F1 Help      ↑↓ Select Item      -/+ Change Values      F9 Setup Defaults Esc Exit      ← Select Menu      Select ▸ Sub-Menu      F10 Save and Exit	

## The Security Menu

This section lets you set security passwords to control access to the system at boot time and/or when entering the BIOS setup program. It also allows you to set virus protection at hard disk boot sector.

PhoenixBIOS Setup Utility			
Main	Advanced	Security	Power Boot Exit
Supervisor Password Is : Clear User Password Is : Clear  Set Supervisor Password : [Enter] Set User Password : [Enter]  Password on boot : [Disabled] Fixed disk boot sector : [Normal] Diskette access : [Supervisor]			Item Specific Help  Supervisor Password controls access to the setup utility.
F1 Help	↑↓ Select Item	-/+ Change Values	F9 Setup Defaults
Esc Exit	←→ Select Menu	Select ▸ Sub-Menu	F10 Save and Exit

### Supervisor Password Is/User Password Is

It shows the preset supervisor/user password. (read only)

### SetSupervisor/User Password

Enabling “Supervisor Password” requires a password for entering Setup. The passwords are not case sensitive. Pressing <Enter> at either Set Supervisor Password or Set User Password displays the following message:

Set Supervisor Password	
Enter New Password:	[       ]
Confirm New Password:	[       ]

Type the password and press <Enter>. Repeat.

**Password on boot**

Choosing Enabled requires a password on boot. It requires prior setting of the Supervisor password. If supervisor password is set and this option is disabled, BIOS assumes user is booting. Options: Enabled, Disabled.

**Fixed disk boot sector**

Write protects the boot sector on the hard disk for virus protection. It requires a password to format the hard disk. Options: Normal, Write Protect.

**Diskette access**

Selecting Enabled requires a password to boot from or access the floppy disk. Options: Enabled, Disabled.

## The Power Menu

Use this menu to specify your settings for Power Management. Remember that the options available depend upon the hardware installed in your system.

PhoenixBIOS Setup Utility				
Main	Advanced	Security	Power	
Power Savings : [Disabled]			Item Specific Help	
Standby Timeout : Off			Maximum Power Savings conserves the greatest amount of system power. Maximum Performance conserves power but allows greatest system performance. To alter these settings, choose Customized. To turn off power management, choose Disabled.	
Auto Suspend Timeout : Off				
Resume On Modem Ring : [Off]				
Resume On LAN : [On]				
Resume On Time : [Off]				
Resume Time : [00:00:00]				
Resume Date : [00/00/0000]				
After Power Failure : [Last State]				
F1 Help      ↑↓ Select Item      -/+ Change Values      F9 Setup Defaults				
Esc Exit      ← Select Menu      Select ▸ Sub-Menu      F10 Save and Exit				

### Power Savings

This item allows you to select Power Management Mode. Select Customized to make your own selections from the following fields. Disabled turns off all power management. Maximum Power Savings conserves the greatest amount of system power. Maximum Performance conserves power but allows greatest system performance. Options: Disabled, Customized, Maximum Power Savings, Maximum Performance.

### Standby Timeout

This feature allows you to specify the inactivity period required to put system in Standby (partial power shutdown). Options: Off, 1 min, 2 min, 4 min, 6 min, 8 min, 12 min, 16 min.

**Auto Suspend Timeout**

This feature allows you to specify the inactivity period required after Standby to Suspend (maximum power shutdown). Options: Disabled, 5 min, 10 min, 15 min, 20 min, 30 min, 40 min, 60 min.

**Resume On Modem Ring**

Select On to wake up system when an incoming call is detected on the modem. Options: On, Off.

**Resume On LAN**

Select On to wake up system by LAN devices. Options: On, Off.

**Resume On Time**

Select On to wake up system at predetermined time. Options: On, Off.

**Resume Time**

The time format is <HH> <MM> <SS>.

**Resume Date**

The date format is <MM> <DD> <YYYY>.

**After Power Failure**

This setting specifies whether your system will reboot after a power failure or interrupt occurs. Available settings are:

- Stay Off* Returns the system to an off state.
- Power On* Returns the system to a full on state.
- Last State* Restores the system to the previous status before power failure or interrupt occurred.

## The Boot Menu

Use this menu to arrange to specify the priority of the devices from which the BIOS will attempt to boot the Operating System.

Phoenix BIOS Setup Utility					
Main	Advanced	Security	Power	Boot	Exit
CD-ROM Drive Removable Devices +Hard Drive MBA v6.2.11 Slot 0208 MBA v6.2.11 Slot 0209				Item Specific Help Keys used to view or configure devices: <Enter> expands or collapses devices with a + or - <Ctrl+Enter> expands all	
F1 Help	↑↓ Select Item		-/+ Change Values	F9 Setup Defaults	
Esc Exit	←→ Select Menu		Select ▸ Sub-Menu	F10 Save and Exit	


### CD-ROM Drive, Removable Devices, Hard Drive

These are the generic types of devices on your system from which you can boot an operating system. You may have more than one device of each type. If so, the generic type is marked with a plus or minus sign. Use the <Enter> key to expand or collapse the devices marked with <+> or <->. Press <Ctrl+Enter> to expand all such devices.

To change a device's priority, first select it with the up-or-down arrows, and move it up or down using the <+> and <-> keys.

## The Exit Menu

The following sections describe each of the options on this menu. Note that <Esc> does not exit this menu. You must select one of the items from the menu or menu bar to exit.



### Exit Saving Changes

When you want to quit the Setup menu, you can select this option to save the changes and quit.

### Exit Discarding Changes

When you want to quit the Setup menu, you can select this option to abandon the changes.

### Load Setup Defaults

The option allows users to restore all of the BIOS settings to the Optimal Defaults. The Setup Defaults are the default values set by the mainboard manufacturer specifically for the optimized performance of the mainboard.

**Discard Changes**

The option allows users to restore all of the BIOS settings to previous values.


**Save Changes**

The option allows users to save the changes without exiting Setup.

# 4

## *Chassis Installation*

This chapter provides instructions on the hardware installation of the MS-9245 in two sections. **System Assembly** illustrates how to assembly each component of the MS-9245. **Rack Mounting** describes the procedures for mounting the unit into the rack in details. You can use the system assembly flowchart and the chart below to determine the proper sequence for removing or installing components to the server.



## System Assembly

### Chassis Cover



Locate the release button on the chassis cover.



Lift the release button to the upright position. Push the chassis cover forward.




Lift the chassis cover to remove it from the system.




#### NOTE

*Before you remove or install these modules, make sure the server is not turned on or connected to the AC power.*

## CPU and Heatsink



Locate the First and Second CPU sockets.



(If you plan on installing single CPU, use the first CPU socket.)

Lift the CPU lever up to a 90 degree angle.



Place the CPU on top of the socket with the cut edge pointing to the arrow sign.

## **CPU and Heatsink (continued)**



Push the lever down to secure the CPU in place.



Place the heatsink on top of CPU.



Screw the heatsink to the chassis.

## DIMM



Locate the DIMM slots.


Install at least two DDR modules on the slots. The plastic clip at each side of the DIMM slot will automatically close.




### NOTE

*Memory modules “in pairs” must be of the same type and size. Please refer to **DIMM Module Combination** on page 2-4 for more information.*

## PCI Cards



Remove the clip from the chassis.




Take out the I/O shield on the first PCI slot.




Insert the add-on card to the PCI slot.



Replace the clip.




Follow the procedures described earlier to install the second PCI Card.



## IDE Hard Disks




Take out the hard disk and HDD trays.




Screw the HDD trays to the hard disk.



Press the release button to pull out the USB tray **completely** from the chassis.



Remove the front bezel by pressing the release buttons (point 1~4) simultaneously.



Pull the rings inward to push the hard disk back into the hard disk drive bay.

Follow the same procedures mentioned earlier to install the second hard disk.




Replace the front bezel for IDE HDD.

Replace the USB tray and pull it open to rest any USB device on it.



Connect the ATA100 cable to the first hard disk.



Connect the power cord to the first hard disk.




Connect the ATA100 cable and power cord to the second hard disk.

## Hot Swap SCSI Hard Disks




Unlock the HDD device holder and pull it out from the chassis.




Screw the hard disk to the HDD device holder.





Slide the HDD device holder into the chassis and push it backward until you hear a “click” sound to secure the holder.



You may pull the USB tray open to rest any USB device on it.

## Rack Mounting




**rail set**

Take out the rail set for rack mounting.




Position the rail to the rack cabin.




Press the button to push the locking tab forward. The rail will secure itself to the cabin.




Screw to secure the rail on the rear.



Position the rail to the rack cabin.




Press the button to push the locking tab forward. The rail will secure itself to the cabin.




Screw to secure the rail on the front.



Follow the same procedures as mentioned earlier in this section to screw the left rail on the front and rear.



Align the 1U rackmount server to the rails and push it backward until it reaches the end.



Screw the system to the cabin.