

VIA SATA/USB 2.0

Combo Card

User Manual

## 1. Hardware Installation

To install the Combo card, follow this procedure:

1. Make sure the computer is turned off;
2. Gain access to the interior of the PC;
3. Insert the Combo card in an empty PCI slot;
4. Press the card gently but firmly into the slot and check to see that all contacts are fully seated in the connector.;
5. Attach the bracket screws that secure the card to the chassis;
6. Reinstall the covers on the PC.

## 2. SATA Installation driver

**Windows 98/98SE ,Windows ME,Windows NT 4.0, Windows XP**

1. Start Windows
2. The "Update Device Driver Wizard" will appear, informing you that it has found a "PCI RAID Controller", click the "Next" button.
3. Insert the Driver CD in the CDROM drive and click on the "Browse" button.
4. At the "Browse" option:

Select CDROM driver

Select folder "SATA\VIARAID\driver"

- a) Windows 98/98SE or Windows ME user - Select folder "win9x"
  - b) Windows NT 4.0 user - Select folder "winnt40"
  - c) Windows XP user - Select folder "winxp"
5. Click the "Next" button.
  6. Follow the instructions to finish up the driver installation.

## 3. USB Driver Installation (Windows XP)

1. Place the Driver CD into the CD-Rom driver. Click the Start button on the taskbar and click **Run**. Type "**D:\Usb\Setup.exe**". (assuming you have placed the CD in CD-RM driver labeled as D);
2. Follow any on-screen instructions to complete the software inatallation;
3. Restart your system;
4. Onec you have rebooted the computer, this Combo card is ready to be used.