


CNET TECHNOLOGY, INC.
CN160AB

NIC Type ARCnet
Transfer Rate 2.5Mbps
Data Bus 16-bit ISA
Topology Linear Bus
Wiring Type RG-62/U 93ohm coaxial
Boot ROM Available



NODE ADDRESS								
Node	SW2/1	SW2/2	SW2/3	SW2/4	SW2/5	SW2/6	SW2/7	SW2/8
0	-	-	-	-	-	-	-	-
1	Off	On						
2	On	Off	On	On	On	On	On	On
3	Off	Off	On	On	On	On	On	On
4	On	On	Off	On	On	On	On	On
251	Off	Off	On	Off	Off	Off	Off	Off
252	On	On	Off	Off	Off	Off	Off	Off
253	Off	On	Off	Off	Off	Off	Off	Off
254	On	Off						
255	Off							

Note: Node address 0 is used for messaging between nodes and must not be used.
 A total of 255 node address settings are available. The switches are a binary representation of the decimal node addresses. Switch 1 is the Least Significant Bit and switch 8 is the Most Significant Bit. The switches have the following decimal values: switch 1=1, 2=2, 3=4, 4=8, 5=16, 6=32, 7=64, 8=128. Turn off the switches and add the values of the off switches to obtain the correct node address. (On=0, off=1)

RESPONSE/RECONFIGURATION TIMEOUTS			
Response Time	Reconfiguration Time	JP1	JP2
74.7µs	840ms	Open	Open
283.4µs	1680ms	Closed	Open
561.8µs	1680ms	Open	Closed
1118.6µs	1680ms	Closed	Closed

Note: All NICs on the network must have this option set the same.

Continued on next page . . .

CNET TECHNOLOGY, INC.
CN160AB

... continued from previous page

INTERRUPT REQUEST											
IRQ	JP3	JP4	JP5	JP6	JP7	JP8	JP9	JP10	JP11	JP12	JP13
i2	Open	Open	Open	Open	Open	Open	Open	Open	Open	Open	Close d
3	Open	Open	Open	Open	Open	Close d	Open	Open	Open	Open	Open
4	Open	Open	Open	Open	Open	Open	Close d	Open	Open	Open	Open
5	Open	Open	Close d	Open	Open	Open	Open	Close d	Open	Open	Open
7	Open	Open	Open	Open	Open	Open	Open	Open	Open	Close d	Open
10	Open	Open	Open	Open	Close d	Open	Open	Open	Open	Open	Open
11	Open	Open	Open	Close d	Open	Open	Open	Open	Open	Open	Open
12	Open	Open	Close d	Open	Open	Open	Open	Open	Open	Open	Open
15	Open	Close d	Open	Open	Open	Open	Open	Open	Open	Open	Open

ONBOARD TERMINATOR	
Setting	JP14
iDisabled	Pins 1 & 2 closed
Enabled	Pins 2 & 3 closed
Note: If the card is on either end of a linear bus network segment, the onboard terminator may be used instead of using an external terminator.	

I/O BASE ADDRESS						
Address	SW1/1	SW1/2	SW1/3	SW1/4	SW1/5	SW1/6
260h	Off	On	On	Off	Off	On
290h	Off	On	Off	On	On	Off
i2E0h	Off	On	Off	Off	Off	On
2F0h	Off	On	Off	Off	Off	Off
300h	Off	Off	On	On	On	On
350h	Off	Off	On	Off	On	Off
380h	Off	Off	Off	On	On	On
3E0h	Off	Off	Off	Off	Off	On

BASE MEMORY ADDRESS & BOOT ROM ADDRESS (VER: A 05-01-0005-04 OR AB(VE)						
Base Address	Base ROM Address	SW1/7	SW1/8	SW1/9	SW1/10	
C0000h	C2000h	On	On	On	On	
C4000h	C6000h	On	On	On	Off	
CC000h	CE000h	On	On	Off	Off	
iD0000h	D2000h	On	Off	On	On	
D4000h	D6000h	On	Off	On	Off	
D8000h	DA000h	On	Off	Off	On	
DC000h	DE000h	On	Off	Off	Off	
E0000h	E2000h	Off	On	On	On	

... continued from previous page

BASE MEMORY ADDRESS & BOOT ROM ADDRESS (REV.D, VER: A 05-01-0005-(3))					
Base Address	Base ROM Address	SW1/7	SW1/7	SW1/9	SW1/10
C0000h	C8000h	Off	Off	On	On
D0000h	D8000h	Off	Off	On	Off
E0000h	E8000h	Off	Off	Off	On

DIAGNOSTIC LED(S)		
LED	Status	Condition
LED1	On	Data is being transmitted
LED1	Off	Data is not being transmitted
LED2	On	Data is being received
LED2	Off	Data is not being received