



AGP slot	AGP	IDE interface 2	J18
ATX power connector	ATX	Floppy drive interface	J19
PS/2 mouse port	J1	Speaker	J20
Serial port 1	J2	Reset switch	J21
Serial port 2	J3	Power LED	J22
USB port 1	J4	IDE interface LED	J23
Parallel port	J5	IR connector	J24
USB port 2	J6	Green PC connector	J25
Wake on LAN connector	J11	Power switch	J26
CPU fan power	J13	SB-Link connector	J27
IDE interface 1	J14	Modem ring connector	J28
Chassis fan power	J16	32-bit PCI slots	PC1 - PC5
Power LED & keylock	J17		

### USER CONFIGURABLE SETTINGS

Function		Label	Position
	Password normal operation	JP1	Open
	Password clear	JP1	Closed

### DIMM CONFIGURATION

Size	Bank 0	Bank 1	Bank 2
8MB	(1) 1M x 64	None	None
16MB	(1) 1M x 64	(1) 1M x 64	None
16MB	(1) 2M x 64	None	None
24MB	(1) 1M x 64	(1) 1M x 64	(1) 1M x 64
32MB	(1) 2M x 64	(1) 2M x 64	None
32MB	(1) 4M x 64	None	None

32MB	(1) 2M x 64	(1) 1M x 64	(1) 1M x 64
48MB	(1) 2M x 64	(1) 2M x 64	(1) 2M x 64
48MB	(1) 4M x 64	(1) 1M x 64	(1) 1M x 64
64MB	(1) 4M x 64	(1) 4M x 64	None
64MB	(1) 8M x 64	None	None
64MB	(1) 4M x 64	(1) 2M x 64	(1) 2M x 64
80MB	(1) 8M x 64	(1) 1M x 64	(1) 1M x 64
96MB	(1) 4M x 64	(1) 4M x 64	(1) 4M x 64
96MB	(1) 8M x 64	(1) 2M x 64	(1) 2M x 64
128MB	(1) 8M x 64	(1) 8M x 64	None
128MB	(1) 16M x 64	None	None
128MB	(1) 8M x 64	(1) 4M x 64	(1) 4M x 64
144MB	(1) 16M x 64	(1) 1M x 64	(1) 1M x 64
160MB	(1) 16M x 64	(1) 2M x 64	(1) 2M x 64
192MB	(1) 8M x 64	(1) 8M x 64	(1) 8M x 64
192MB	(1) 16M x 64	(1) 4M x 64	(1) 4M x 64
256MB	(1) 16M x 64	(1) 16M x 64	None
256MB	(1) 32M x 64	None	None
256MB	(1) 16M x 64	(1) 8M x 64	(1) 8M x 64
272MB	(1) 32M x 64	(1) 1M x 64	(1) 1M x 64
288MB	(1) 32M x 64	(1) 2M x 64	(1) 2M x 64
320MB	(1) 32M x 64	(1) 4M x 64	(1) 4M x 64
384MB	(1) 16M x 64	(1) 16M x 64	(1) 16M x 64
384MB	(1) 32M x 64	(1) 8M x 64	(1) 8M x 64
512MB	(1) 32M x 64	(1) 32M x 64	None
512MB	(1) 32M x 64	(1) 16M x 64	(1) 16M x 64
768MB	(1) 32M x 64	(1) 32M x 64	(1) 32M x 64

Note: Board supports EDO & SDRAM memory.

## CACHE CONFIGURATION

Note: 256KB/512KB cache is located on the Pentium II CPU. 128KB cache is located on the Celeron 300A and greater Celerons.

## CPU SPEED SELECTION (INTEL)

CPU speed	Clock speed	Multiplier	JP2/Pins 1 & 2	JP2/Pins 3 & 4	JP2/Pins 5 & 6	JP2/Pins 7 & 8
233MHz	66MHz	3.5x	Open	Closed	Open	Closed
266MHz	66MHz	4x	Closed	Open	Closed	Closed
300MHz	66MHz	4.5x	Closed	Open	Open	Closed
333MHz	66MHz	5x	Open	Open	Closed	Closed
300MHz	100MHz	3x	Open	Closed	Closed	Closed
350MHz	100MHz	3.5x	Open	Closed	Open	Closed
400MHz	100MHz	4x	Closed	Open	Closed	Closed
450MHz	100MHz	4.5x	Closed	Open	Open	Closed