



CPU FSB Select - JP9 and JP10

CPU/DIMM	JP9	JP10
Auto*	1-2 On	1-2 On
66/100MHz	2-3 On	2-3 On
100/100MHz	All Off	2-3 On
133/100MHz	All Off	All Off
133/133MHz	2-3 On	All Off

* denotes default setting

Onboard Audio Codec Settings - JP7

1-2 On: Enable the onboard audio codec (default)

2-3 On: Disable the onboard audio codec

Wake-On-USB Keyboard - JP12 : 1-2 On: Disabled (default); 2-3 On: Enabled

Boot Block Lock/Unlock - JP6 (For factory use only)

1-2 On: Unlock boot block (default); 2-3 On: Lock boot block

Clear CMOS Data - JP2 : 1-2 On: Normal (default); 2-3 On: Clear CMOS Data

If you forget the supervisor/user password or the CPU's clock/ratio was incorrectly set in the BIOS, clear the CMOS data by setting this jumper to 2-3 On. Make sure to power-off the system prior to clearing the CMOS data.

Wake-On-KB/Mouse - JP5 : 1-2 On: Disabled (default); 2-3 On: Enabled

If you wish to disable the password set in the "KB Power On Password" field, make sure to set the "Keyboard/Mouse Power On" field to Disabled prior to setting JP5 to disabled. You will not be able to boot up the system if you fail to do so.

System's Beep Message Output Select - JP8

1-2 On: The system's beep message will come from the external speaker that is connected to the Line-out jack.

2-3 On: The system's beep message will come from the PC's speaker. (default)

3.3VSB Standby for PCI - J18

On: Provides 3.3VSB standby power to the PCI slots. (default)

Off: For PCI modem cards that does not comply to PCI 2.2 specification.

LEDs: The DIMM Standby Power LED will turn red when the system's power is on or when it is in the Suspend state (Power On Suspend or Suspend to RAM). It will not light when the system is in the Soft-Off state. The PCI Standby Power LED will turn red when the system is in the power-on, Soft-Off or Suspend (Power On Suspend or Suspend to RAM) state. Lighted LEDs serve as a reminder that you must power-off the system then turn off the power supply's switch or unplug the power cord prior to installing any DIM modules or add-in cards.

Important:

- If you are using the (1) Wake-On-KB/Mouse, (2) Wake-On-LAN and/or (3) Wake-On-Ring (internal modem) functions, the 5VSB power source of your power supply must support $\geq 720\text{mA}$.
- If you are using the Suspend to RAM function, the 5VSB power source of your power supply must support $\geq 1\text{A}$.
- If you are using the Wake-On-USB Keyboard function, the 5VSB power source of your power supply must support $\geq 1.5\text{A}$.