

NEED HELP?

 [Email Us](#)

 [Find service locations](#)


The following table shows the supported CPUs for this motherboard [Click here to search other motherboards.](#)

CPU	Validated since PCB	Validated since BIOS	Note
Celeron 420(1.60GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0302 GO	
Celeron 430(1.80GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0302 GO	
Celeron 440(2.00GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0302 GO	
Celeron 450(2.2GHz,800 FSB,L2 512KB,LGA775,revA1)	ALL	0902 GO	
Celeron Dual Core E1200(revM0,1.6GHz,800 FSB,L2:512K)	ALL	0503 GO	
Celeron Dual Core E1500(revM0,2.2GHz,800 FSB,L2: 512K)	ALL	0503 GO	
Core 2 Duo E4300 (1.8GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0302 GO	
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.L2)	ALL	0302 GO	
Core 2 Duo E4400 (2.0GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0302 GO	
Core 2 Duo E4600 (2.4GHz,800FSB,L2:2MB,65W,rev.M0)	ALL	0302 GO	
Core 2 Duo E4700 (2.6GHz,800FSB,L2:2MB,revG0)	ALL	0503	


			GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.B2)	ALL	0302	GO
Core 2 Duo E6300 (1.86GHz,1066FSB,L2:2MB,rev.L2)	ALL	0302	GO
Core 2 Duo E6320 (1.86GHz,1066FSB,L2:4MB,rev.B2)	ALL	0302	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.B2)	ALL	0302	GO
Core 2 Duo E6400 (2.13GHz,1066FSB,L2:2MB,rev.L2)	ALL	0302	GO
Core 2 Duo E6420 (2.13GHz,1066FSB,L2:4MB,rev.B2)	ALL	0302	GO
Core 2 Duo E6540 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0302	GO
Core 2 Duo E6550 (2.33GHz,1333FSB,L2:4MB,rev.G0)	ALL	0302	GO
Core 2 Duo E6600 (2.40GHz,1066FSB,L2:4MB,rev.B2)	ALL	0302	GO
Core 2 Duo E6700 (2.66GHz,1066FSB,L2:4MB,rev.B2)	ALL	0302	GO
Core 2 Duo E6750 (2.66GHz,1333FSB,L2:4MB,rev.G0)	ALL	0302	GO

Core 2 Duo E6850 (3.00GHz,1333FSB,L2:4MB,rev.G0)	ALL	0302 GO
Core 2 Duo E7200(2.53GHz,1066FSB,L2:3MB,rev.M0)	ALL	1102 GO
Core 2 Duo E7400(2.80GHz,1066FSB,L2:3MB,rev.R0)	ALL	0902 GO
Core 2 Duo E7500(2.93GHz,1066FSB,L2:3MB,rev.R0)	ALL	1001 GO
Core 2 Duo E7600(3.06GHz,1066FSB,L2:3MB,rev.R0)	ALL	1102 GO
Core 2 Duo E8400 (3.00GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0805 GO
Core 2 Duo E8500 (3.16GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0805 GO
Core 2 Duo E8600 (3.33GHz,1333FSB,L2:6MB,65W,rev.E0)	ALL	0805 GO
Core 2 Extreme QX6700(revB3,2.66GHz,1066FSB,L2:2X4MB)	ALL	0302 GO
Core 2 Extreme QX6800 (rev.G0,2.93GHz,1066FSB,L2:2X4MB,4 cores)	ALL	0302 GO
Core 2 Extreme QX6800(revB3,2.93GHz,1066FSB,L2:2X4MB)	ALL	0302 GO
Core 2 Extreme QX6850(revG0,3.00GHz,1333FSB,L2:2X4MB)	ALL	0302 GO


Core 2 Extreme QX9650 (rev.C1,3.00GHz,1333FSB,L2:2X6MB,4 cores)	ALL	0604 
Core 2 Extreme QX9650(rev.C0,3.00GHz,1333FSB,L2:2X6MB)	ALL	0303 
Core 2 Extreme QX9770(rev.C1,3.2GHz,1600FSB,L2:2X6MB)	ALL	0604 
Core 2 Extreme X6800(2.93GHz,1066FSB,L2:4MB,rev.B2)	ALL	0302 
Core 2 Quad Q6400 (2.13GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0302 
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.B3,4 cores)	ALL	0302 
Core 2 Quad Q6600 (2.40GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0302 
Core 2 Quad Q6700 (2.66GHz,1066FSB,L2:2X4MB,rev.G0,4 cores)	ALL	0302 
Core 2 Quad Q8200 (rev.M1,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1102 
Core 2 Quad Q8200 (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1102 
Core 2 Quad Q8200S (rev.R0,2.33GHz,1333FSB,L2:4MB,4 cores)	ALL	1102 
Core 2 Quad Q8300 (rev.R0,2.50GHz,1333FSB,L2:4MB,4 cores)	ALL	0902 

Core 2 Quad Q8400 (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	1102 
Core 2 Quad Q8400S (rev.R0,2.66GHz,1333FSB,L2:4MB,4 cores)	ALL	1102 
Core 2 Quad Q9400 (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	0805 
Core 2 Quad Q9400S (rev.R0,2.66GHz,1333FSB,L2:6MB)	ALL	1102 
Core 2 Quad Q9450 (2.66GHz,1333FSB,L2:12MB,rev.C1)	ALL	0604 
Core 2 Quad Q9550(2.83GHz,1333FSB,L2:12MB,rev.C1)	ALL	0604 
Core 2 Quad Q9550(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	0805 
Core 2 Quad Q9550S(rev.E0,2.83GHz,1333FSB,L2:12MB)	ALL	1102 
Core 2 Quad Q9650(rev.E0,3.00GHz,1333FSB,L2:12MB)	ALL	0805 
P4-3.20F GHz (EM64T)	ALL	0302 
P4-3.40F GHz (EM64T)	ALL	0302 
P4-3.40GHz(FSB800, revR0)	ALL	0302 


P4-3.60F GHz (EM64T)	ALL	0302 
P4-3.73 GHz Extreme Ed. (1066 FSB, HT, revN0, LGA775)	ALL	0302 
P4-3.80F GHz (EM64T)	ALL	0302 
P4-3.80GHz(FSB800, revR0)	ALL	0302 
P4-520/520J (2.8E GHz) (800 FSB) (D0)	ALL	0302 
P4-520/520J (2.8E GHz) (800 FSB) (E0)	ALL	0302 
P4-521(2.8GHz, 800 FSB,HT, L2 1MB)(D0,E0)	ALL	0302 
P4-530/530J (3E GHz) (800 FSB) (D0,E0)	ALL	0302 
P4-531(3GHz, 800 FSB, L2 1MB)(D0,E0)	ALL	0302 
P4-540/540J (3.2E GHz) (800 FSB) (E0,D0)	ALL	0302 
P4-541(3.2GHz, 800 FSB, L2 1MB)(E0,D0)	ALL	0302 
P4-550/550J (3.4E GHz) (800 FSB) (D0.E0)	ALL	0302 

P4-551(3.4GHz, 800 FSB, L2 1MB,D0,E0)	ALL	0302 
P4-560/560J (3.6 GHz) (800 FSB) (D0,E0)	ALL	0302 
P4-561(3.6GHz, 800 FSB, L2 1MB)	ALL	0302 
P4-561(3.6GHz, 800 FSB, L2 1MB)(E0,D0)	ALL	0302 
P4-570J (3.8 GHz) (800 FSB) (D0,E0)	ALL	0302 
P4-571(3.8GHz, 800 FSB, L2 1MB V E0)	ALL	0302 
P4-630 (3.0E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0302 
P4-631(65nm,3.0GHz, 800 FSB, L2:2MB, revB1)	ALL	0302 
P4-631(65nm,3.0GHz, 800 FSB, L2:2MB, revC1)	ALL	0302 
P4-631(65nm,3.0GHz, 800 FSB, L2:2MB, revD0)	ALL	0302 
P4-640 (3.2E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0302 
P4-641(65nm,3.2GHz, 800 FSB, L2:2MB, revB1)	ALL	0302 

P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revC1)	ALL	0302 
P4-641 (65nm,3.2GHz, 800 FSB, L2:2MB, revD0)	ALL	0302 
P4-650 (3.4E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0302 
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revB1)	ALL	0302 
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revC1)	ALL	0302 
P4-651 (65nm,3.4GHz, 800 FSB, L2:2MB, revD0)	ALL	0302 
P4-660 (3.6E GHz, 800 FSB, L2:2MB, EM64T, HT)	ALL	0302 
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revB1)	ALL	0302 
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revC1)	ALL	0302 
P4-661 (65nm,3.6GHz, 800 FSB, L2:2MB, revD0)	ALL	0302 
P4-662 (3.6 GHz, 800 FSB, L2:2MB, EM64T, HT, revR0)	ALL	0302 
P4-670 (3.8 GHz, 800 FSB, L2:2MB,N0)	ALL	0302 

P4-672 (3.8 GHz, 800 FSB, L2:2MB, revR0)	ALL	0302 
Pentium D 820 (2.8 GHz, 800 FSB, revA0)	ALL	0302 
Pentium D 820 (2.8 GHz, 800 FSB, revB0)	ALL	0302 
Pentium D 830 (3.0 GHz, 800 FSB, revA0)	ALL	0302 
Pentium D 830 (3.0 GHz, 800 FSB, revB0)	ALL	0302 
Pentium D 840 (3.2 GHz, 800 FSB, revA0)	ALL	0302 
Pentium D 840 (3.2 GHz, 800 FSB, revB0)	ALL	0302 
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0302 
Pentium D 915(2.8GHz, 800 FSB, L2 4MB, revD0,without VT function)	ALL	0302 
Pentium D 920(2.8GHz, 800 FSB, L2 4MB, revB1)	ALL	0302 
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0302 
Pentium D 925(3.0GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0302 

Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revB1)	ALL	0302 
Pentium D 930(3.0GHz, 800 FSB, L2 4MB, revC1)	ALL	0302 
Pentium D 935(3.2GHz, 800 FSB, L2 4MB, 95W, revD0)	ALL	0302 
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revB1)	ALL	0302 
Pentium D 940(3.2GHz, 800 FSB, L2 4MB, revC1)	ALL	0302 
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revC1, without VT function)	ALL	0302 
Pentium D 945(3.4GHz, 800 FSB, L2 4MB, revD0, without VT function)	ALL	0302 
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revB1)	ALL	0302 
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revC1)	ALL	0302 
Pentium D 950(3.4GHz, 800 FSB, L2 4MB, revD0)	ALL	0302 
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revC1)	ALL	0302 
Pentium D 960(3.6GHz, 800 FSB, L2 4MB, revD0)	ALL	0302 

Pentium Dual Core E2140(1.6GHz, 800FSB, L2 1MB,L2)	ALL	0302 
Pentium Dual Core E2140(1.6GHz,800FSB,L2 1MB,M0)	ALL	0302 
Pentium Dual Core E2160(1.8GHz, 800FSB, L2 1MB,L2)	ALL	0302 
Pentium Dual Core E2160(1.8GHz,800FSB,L2 1MB,M0)	ALL	0302 
Pentium Dual Core E2180(2.0GHz,800FSB,L2 1MB,M0)	ALL	0302 
Pentium Dual Core E2220(2.4GHz,800FSB,L2 1MB,M0)	ALL	0403 
Pentium Dual Core E5200 (2.50GHz,800FSB,L2:2MB,rev.M0)	ALL	1102 
Pentium Dual Core E5200(2.50GHz,800FSB,L2:2MB,rev.R0)	ALL	1102 
Pentium Dual Core E5300 (2.60GHz,800FSB,L2:2MB,rev.R0)	ALL	1001 
Pentium Dual Core E6300 (2.8GHz,1066FSB,L2:2MB,rev.R0)	ALL	1102 
Pentium Extreme Ed-840 (3.2 GHz, 800 FSB, revA0)	ALL	0302 
Pentium Extreme Ed-840 (3.2 GHz, 800 FSB, revB0)	ALL	0302 

Pentium Extreme ED-955(3.46GHz, rev A0,B1)

ALL

0302

GO

Pentium Extreme ED-965(3.73GHz, rev C1)

ALL

0302

GO

Shop and Learn

Mobile

Phones

Accessories

Laptops

For Home

For Work

For Creators

For Students

For Gaming

Accessories

Displays / Desktops

Monitors

Projectors

All-in-One PCs

Tower PCs

Gaming Tower PCs

Mini PCs

Workstations

Accessories

Motherboards / Components

Motherboards

Graphics Cards

Gaming Cases

Cooling

Power Supply Units

Sound Cards

Optical Drives

Data Storage

External Graphics Docks

Networking / IoT / Servers

WiFi 7

WiFi 6

WiFi Routers

Whole Home Mesh WiFi
System

Business Network Solutions

Wired Networking

Intelligent Robots

AIoT & Industrial Solutions

Servers

Smart Home

Accessories

Keyboards

Mice and Mouse Pads

Headsets and Audio

Streaming Kits

Apparel Bags and Gear

Cases and Protection

Adapters and Chargers

Docks Dongles and Cable

Power Banks

Controller

Gimbal

Learn More

Asus Design Center

ASUSPRO

Automotive Solutions

AVC Licensing Notice

ASUS Blog

Support

Check Repair Status

Find Service Locations

Product Registration

Email Us

Call Us

Security Advisory

ASUS Support Videos

MyASUS

