

## voltage settings:

description	CPU voltage	JPW1	JV1	JV2
3.3 V single power	V-core: 3,3 V V I/O: same	1-2	OPEN	1-2, 3-4
3,52 V single power	V-core 3.52 V V I/O: same	3-4	OPEN	1-2, 3-4
2.8 V dual power	V-core 2.8 V V I/O: 3.3V	5-6	1-2, 3-4	OPEN
2.5 V dual power	V-core 2.5 V V I/O: 3.3V	7-8	1-2, 3-4	OPEN

default JV1: OPEN, JV1 1-2, 3-4

## Intel CPU

CPU speed	JC2	JC3	JC4	JP1		clock	factor
				1-2	3-4		
75 Mhz	2-3	2-3	2-3	OFF	OFF	50 Mhz	1,5
90 Mhz	1-2	2-3	2-3	OFF	OFF	60 Mhz	1,5
100 Mhz	2-3	1-2	2-3	OFF	OFF	66 Mhz	1,5
120 Mhz	1-2	2-3	2-3	ON	OFF	60 Mhz	2
133 Mhz	2-3	1-2	2-3	ON	OFF	66 Mhz	2
150 Mhz	1-2	2-3	2-3	ON	ON	60 Mhz	2,5
166 Mhz	2-3	1-2	2-3	ON	ON	66 Mhz	2,5
180 Mhz	1-2	2-3	2-3	OFF	ON	60 Mhz	3
200 Mhz	2-3	1-2	2-3	OFF	ON	66 Mhz	3

## Cyrix/IBM 6x86 CPU

CPU speed	JC2	JC3	JC4	JP1		clock	factor
				1-2	3-4		
6x86-p120+	2-3	2-3	2-3	ON	OFF	50 Mhz	2
6x86-p133+	2-3	2-3	1-2	ON	OFF	60 Mhz	2
6x86-p150+	1-2	1-2	2-3	ON	OFF	66 Mhz	2
6x86-p166+	2-3	1-2	2-3	ON	OFF	60 Mhz	2
6x86-p200+	1-2	2-3	1-2	ON	OFF	66 Mhz	2

## AMD K5 CPU

CPU speed	JC2	JC3	JC4	JP1		clock	factor
				1-2	3-4		
K5-P75 (75 Mhz)	2-3	2-3	2-3	OFF	OFF	50 Mhz	1,5
K5-P90 (90 Mhz)	1-2	2-3	2-3	OFF	OFF	60 Mhz	1,5
K5-P100 (100 Mhz)	2-3	1-2	2-3	OFF	OFF	66 Mhz	1,5
K5-PR133 (100 Mhz)	2-3	1-2	2-3	OFF	OFF	60 Mhz	1,5

## Extra settings:

	JV1	JV2	JC2	JC3	JC4	JP1		JPW1	Clock	Factor
						1-2	3-4			
Intel 233 Mhz	1-2, 3-4	OFF	2-3	1-2	2-3	OFF	OFF	5-6	66 Mhz	3,5
AMD K6 233	OFF	1-2, 3-4	2-3	1-2	2-3	OFF	OFF	1-2	66 Mhz	3,5
Cyrix/IBM PR200	1-2, 3-4	OFF	2-3	1-2	2-3	ON	ON	5-6	66 Mhz	2,5
Cyrix/IBM PR200	1-2, 3-4	OFF	1-2	2-3	1-2	ON	OFF	5-6	75 Mhz	2
Cyrix/IBM M2 233	1-2, 3-4	OFF	2-3	1-2	2-3	OFF	ON	5-6	66 Mhz	3